

**PRINTRONIX®** **PSA3**  
*P7000 User's Manual*



## READ THIS SOFTWARE LICENSE AGREEMENT BEFORE USING THIS PRINTER

### Software License Agreement

CAREFULLY READ THE FOLLOWING TERMS AND CONDITIONS BEFORE USING THIS PRINTER. USING THIS PRINTER INDICATES YOUR ACCEPTANCE OF THESE TERMS AND CONDITIONS. IF YOU DO NOT AGREE TO THESE TERMS AND CONDITIONS, PROMPTLY RETURN THE PRINTER AND ALL ACCOMPANYING HARDWARE AND WRITTEN MATERIALS TO THE PLACE YOU OBTAINED THEM, AND YOUR MONEY WILL BE REFUNDED.

### Definitions.

"Software" shall mean the digitally encoded, machine-readable data and program. The term "Software Product" includes the Software resident in the printer and its documentation. The Software Product is licensed (not sold) to you, and Printronix, Inc. either owns or licenses from other vendors who own, all copyright, trade secret, patent and other proprietary rights in the Software Product.

### License.

1. Authorized Use. You agree to accept a non-exclusive license to use the Software resident in the printer solely for your own customary business or personal purposes.
2. Restrictions.
  - a. To protect the proprietary rights of Printronix, Inc., you agree to maintain the Software Product and other proprietary information concerning the typefaces in strict confidence.
  - b. You agree not to duplicate or copy the Software Product.
  - c. You shall not sublicense, sell, lease, or otherwise transfer all or any portion of the Software Product separate from the printer, without the prior written consent of Printronix, Inc.
  - d. You may not modify or prepare derivative works of the Software Product.
  - e. You may not transmit the Software Product over a network, by telephone, or electronically using any means; or reverse engineer, decompile or disassemble the Software.
  - f. You agree to keep confidential and use your best efforts to prevent and protect the contents of the Software Product from unauthorized disclosure or use.
3. Transfer. You may transfer the Software Product with the printer, but only if the recipient agrees to accept the terms and conditions of this Agreement. Your license is automatically terminated if you transfer the Software Product and printer.

### Limited Software Product Warranty

Printronix, Inc. warrants that for ninety (90) days after delivery, the Software will perform in accordance with specifications published by Printronix, Inc. Printronix, Inc. does not warrant that the Software is free from all bugs, errors and omissions.

### Remedy

Your exclusive remedy and the sole liability of Printronix, Inc. in connection with the Software is replacement of defective software with a copy of the same version and revision level.

### Disclaimer of Warranties and Limitation of Remedies

1. THE PARTIES AGREE THAT ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY ARE EXCLUDED. Printronix, Inc. does not warrant that the functions contained in the Software will meet your requirements or that the operation of the Software will be uninterrupted or error free. Printronix, Inc. reserves the right to make changes and/or improvements in the Software without notice at any time.
2. IN NO EVENT WILL PRINTRONIX, INC. BE LIABLE FOR LOST PROFITS, LOST DATA, BUSINESS INTERRUPTIONS, OR ANY OTHER DIRECT, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF OR INABILITY TO USE THIS PRODUCT, EVEN IF PRINTRONIX, INC. HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR ANY DAMAGES CAUSED BY THE ABUSE OR MANIPULATION OF THE SOFTWARE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.
3. Printronix, Inc. will not be liable for any loss or damage caused by delay in furnishing a Software Product or any other performance under this Agreement.
4. Our entire liability and your exclusive remedies for our liability of any kind (including liability for negligence except liability for personal injury caused solely by our negligence) for the Software Product covered by this Agreement and all other performance or nonperformance by us under or related to this Agreement are limited to the remedies specified by this Agreement.
5. California law governs this Agreement.

### Termination of License Agreement

This License shall continue until terminated. This license may be terminated by agreement between you and Printronix, Inc. or by Printronix, Inc. If you fail to comply with the terms of this License and such failure is not corrected within thirty (30) days after notice. When this License is terminated, you shall return to the place you obtained them, the printer and all copies of the Software and documentation.

### U.S. Government Restricted Rights

Use, duplication or disclosure by the Government is subject to restrictions as set forth in the Rights in Technical Data and Computer Software clause at FAR 242.227-7013, subdivision (b) (3) (ii) or subparagraph (c) (1) (ii), as appropriate. Further use, duplication or disclosure is subject to restrictions applicable to restricted rights software as set forth in FAR 52.227-19 (c) (2).

### Acknowledgement of Terms and Conditions

YOU ACKNOWLEDGE THAT YOU HAVE READ THIS AGREEMENT, UNDERSTAND IT, AND AGREE TO BE BOUND BY ITS TERMS AND CONDITIONS. NEITHER PARTY SHALL BE BOUND BY ANY STATEMENT OR REPRESENTATION NOT CONTAINED IN THIS AGREEMENT. NO CHANGE IN THIS AGREEMENT IS EFFECTIVE UNLESS WRITTEN AND SIGNED BY PROPERLY AUTHORIZED REPRESENTATIVES OF EACH PARTY. BY USING THIS PRINTER, YOU AGREE TO ACCEPT THE TERMS AND CONDITIONS OF THIS AGREEMENT.

# *User's Manual*

*The Printronix P7000 Series PSA3™ Printers*

**PRINTRONIX®** **PSA3**

---

This document contains proprietary information protected by copyright. No part of this document may be reproduced, copied, translated, or incorporated in any other material in any form or by any means, whether manual, graphic, electronic, mechanical, or otherwise, without the prior written consent of Printronix.

Printronix makes no representations or warranties of any kind regarding this material, including, but not limited to, implied warranties of merchantability and fitness for a particular purpose. Printronix shall not be held responsible for errors contained herein or any omissions from this material or for any damages, whether direct or indirect, incidental or consequential, in connection with the furnishing, distribution, performance, or use of this material. The information in this manual is subject to change without notice.

COPYRIGHT 1997, 2008 PRINTRONIX, INC.

## Trademark Acknowledgements

---

IBM, AS/400, and Proprinter are registered trademarks, and Intelligent Printer Data Stream and IPDS are trademarks of International Business Machines Corporation.

Printronix, PGL, LinePrinter Plus, and IGP are registered trademarks, and P7005, P7010, P7015, P7205, P7210, P7215, P7220, and SureStak are trademarks of Printronix, Inc.

ANSI is a registered trademark of the American National Standards Institute, Inc.

Centronics is a registered trademark of Genicom Corporation.

CSA is a registered certification mark of the Canadian Standards Association.

Dataproducts is a registered trademark of Dataproducts Corporation.

EIA is a registered service mark of the Electronic Industries Association.

Epson is a registered trademark of Seiko Epson Corporation.

Ethernet is a trademark of Xerox Corporation.

IEEE is a registered service mark of the Institute of Electrical and Electronics Engineers, Inc.

QMS is a registered trademark, and Code V is a trademark of Quality Micro Systems, Inc.

TUV is a registered certification mark of TUV Rheinland of North America, Inc.

UL is a registered certification mark of Underwriters Laboratories, Inc.

ENERGY STAR is a registered trademark of the United States Environmental Protection Agency. As an ENERGY STAR<sup>®</sup> Partner, Printronix has determined that this product meets the ENERGY STAR guidelines for energy efficiency.



# Table of Contents

<b>1</b>	<b>Introduction .....</b>	<b>11</b>
	Printer Overview .....	11
	Printronix P7000 Series Printers .....	11
	Integrated Print Management System .....	12
	Graphics Enhancements .....	14
	Taking Care Of Your Printer .....	14
	.....	14
	Conventions In This Manual .....	15
	Warnings And Special Information .....	15
	Related Documents .....	15
	Contact Information .....	16
	Printronix Customer Support Center .....	16
	Printronix Supplies Department .....	16
	Corporate Offices .....	17
<b>2</b>	<b>Setting Up The Printer .....</b>	<b>19</b>
	Before You Begin .....	19
	Power Requirements .....	19
	Select A Site .....	19
	Printer Dimensions .....	20
	Printer Component Locations .....	23
<b>3</b>	<b>Operating The Printer .....</b>	<b>25</b>
	Powering On The Printer .....	25
	Operating Modes .....	25
	The Control Panel .....	26
	Control Panel Keys .....	26
	Operational Procedures .....	30
	Reload Paper .....	30
	Unload Paper .....	39
	Integrated Print Management System .....	42
	Lighter Or Darker Print .....	42
	Changing Ribbons .....	43
	Cancel A Print Job .....	46

4	The Configuration Menus .....	47
	Configuration Overview .....	47
	Changing Parameter Settings .....	47
	Saving Parameter Settings .....	47
	Default And Custom Configurations .....	48
	Navigating The Menus .....	48
	Changing Parameters Example .....	49
	Auto Save Configuration .....	52
	Saving Your New Configuration .....	52
	Optimizing Print Quality .....	57
	Optimizing Print Speed .....	58
	Main Menu .....	59
	QUICK SETUP .....	62
	ZTP SETTINGS .....	68
	CONFIG. CONTROL .....	69
	HOST INTERFACE .....	72
	Auto Switching Submenu .....	73
	IEEE 1284 Parallel (Bidirectional) Submenu .....	75
	Centronics (Parallel) Submenu .....	76
	Dataproducts Submenu .....	79
	Serial Submenu .....	81
	E-Net Adapter Submenu .....	86
	Ethernet Submenu .....	86
	NETWORK SETUP MENU .....	87
	ADAPTER ADDRESS .....	87
	ADAPTER PARAMS .....	88
	ETHERNET ADDRESS .....	91
	ETHERNET PARAMS .....	92
	WLAN ADDRESS .....	94
	WLAN PARAMS .....	95
	WLAN KERBEROS .....	99
	WLAN LEAP .....	101
	ACTIVE IGP EMUL .....	102
	ACTIVE EMULATION .....	103
	EMULATION .....	103
	Coax/Twinax (CTHI) Emulation .....	104
	Standard .....	104
	Simple Prot Conv .....	105
	Coax Emulation .....	106
	Twinax Params .....	115
	3270 Params .....	121
	5250 Params .....	128

SPC Coax Params .....	132
SPC Twx Params .....	135
LinePrinter Plus Emulation .....	137
LinePrinter Plus Emulation (With PCL-II).....	139
P-Series Emulation .....	144
P-Series Emulation (with PCL-II).....	144
P-Series Emulation (With LG) .....	145
P-Series XQ Emulation .....	152
Serial Matrix Emulation .....	154
Proprinter XL Emulation .....	159
Epson FX Emulation .....	163
ANSI Emulation .....	168
IGP/PGL Emulation .....	175
Features .....	175
Configuring The Emulation With The Control Panel.....	176
IGP/PGL Submenu .....	177
IGP/PGL Submenu (With PCL-II).....	178
IGP/PGL Submenu (With LG) .....	179
IGP/VGL Emulation .....	189
Features .....	189
Configuring The Emulation With The Control Panel.....	190
IGP/VGL Submenu .....	190
IGP/VGL Submenu (with PCL-II).....	192
IGP/VGL Submenu (with LG) .....	194
IPDS Emulation .....	205
PCL - II Emulation.....	209
LG Emulation .....	213
PRINTER CONTROL .....	218
ADVANCED USER.....	221
DIAGNOSTICS .....	227
DATE .....	230
Printer MGMT .....	231
<b>5 Interfaces .....</b>	<b>233</b>
Overview .....	233
Dataproducts Parallel Interface .....	234
Dataproducts Parallel Interface Signals .....	235
Centronics Parallel Interface.....	236
Centronics Parallel Interface Signals .....	237
IEEE 1284 Parallel Interface.....	238
Compatibility Mode.....	238
Nibble Mode .....	238

Byte Mode .....	238
Signals .....	239
Terminating Resistor Configurations .....	241
RS-232 And RS-422 Serial Interfaces .....	244
RS-232 .....	244
RS-422 .....	245
<b>6 Reprogramming the Security Key .....</b>	<b>247</b>
Reprogramming The Security Key .....	247
How To Program The Security Key .....	247
<b>7 Troubleshooting .....</b>	<b>249</b>
Cleaning Requirements .....	249
Exterior Cleaning .....	249
Interior Cleaning .....	250
Diagnosing Problems .....	252
Bar Code Verification .....	252
Printing A Hex Dump .....	253
Fault Messages .....	254
<b>A Printer Specifications .....</b>	<b>285</b>
Ribbon Specifications .....	285
Paper Specifications .....	286
Printer Weight And Dimensions .....	287
Environmental Characteristics .....	287
Electrical Characteristics .....	289
Interfaces .....	289
Printing Rates .....	290
<b>B ASCII Character Set .....</b>	<b>291</b>
<b>C Zero Tear Printer .....</b>	<b>293</b>
Overview .....	293
Operation .....	294
Position The Paper Input And Adjust The Paper Guides .....	294
Load Paper .....	296
Position The Paper Out Sensor .....	298
Set The Tear Bar Distance .....	299
Set The Top Of Form .....	300
Control Panel Menus .....	301
Performance Limitations .....	302



- D Customer Support ..... 305
  - Printronic Customer Support Center..... 305
  - Printronic Supplies Department ..... 305
  - Corporate Offices..... 306
  
- E Communication Notices ..... 307
  - Notices..... 307
  - Energy Star..... 309
  - Product Recycling and Disposal ..... 309
  - Communication Statements..... 310
  - Lithium Battery Warning ..... 313
  - Software License Agreement..... 314



---

# 1

# *Introduction*

---

## **Printer Overview**

---

This chapter provides a general overview of your printer and the conventions used within this manual.

### **Printronix P7000 Series Printers**

---

The Printronix® P7000 Series Printers are the latest line matrix printers to feature PSA3™ (Printronix System Architecture, third generation). All printer models (see Table 1 on page 12) are packaged in various configurations that offer software versatility and the latest refinements in printing technology. The print mechanisms are housed in sound-insulated cabinets which make the printer among the quietest line matrix printers in the world. Additionally, your printer has a flexible architecture that allows you to add new features and emulations as they become available.

LinePrinter Plus® is the standard emulation. LinePrinter Plus includes the Epson® FX-1050, Printronix P-Series, P-Series XQ, Serial Matrix and Proprinter® III XL emulations. Coax/Twinax, IPDS™, ANSI®, LG, PCL2, IGP®/PGL®, and IGP/VGL graphics enhancement emulations are available as optional upgrades. No matter what emulation is installed, your printer is easy to use. The message display and lights on the control panel communicate with you directly and clearly. You can select every function on your printer at the control panel, or you can send commands from the host computer.

The printer model numbers indicate physical configuration and printing speed. Model numbers beginning with P70 indicate pedestal models. Model numbers beginning with P72 indicate cabinet models. The final two digits in the model number (except for P7080 and P7280) refer to the printer's maximum speed in lines per minute (lpm): 02 for 200 lpm, 03 for 300 lpm, 05 for 500 lpm, 06 for 600 lpm, 10 for 1000 lpm, 15 for 1500 lpm, and 20 for 2000 lpm.

Refer to the following table for a complete listing of model numbers and options.

**NOTE:** H = H-Series  
 HD = High Density  
 HZT = H-Series Zero Tear  
 ZT = Zero Tear

**Table 1. The Printronix P7000 Series Printers**

Model Number	Print Speed	Model Type	Power Stacker
P7002H	200 lpm	Pedestal	
P7202HZT	200 lpm	Zero Tear Pedestal	
P7003HZT	300 lpm	Zero Tear Pedestal	
P7005	500 lpm	Pedestal	
P7005ZT	500 lpm	Zero Tear Pedestal	
P7205	500 lpm	Cabinet	N/A
P7006HZT	600 lpm	Zero Tear Pedestal	
P7010	1000 lpm	Pedestal	
P7010ZT	1000 lpm	Zero Tear Pedestal	
P7015	1500 lpm	Pedestal	
P7015ZT	1500 lpm	Zero Tear Pedestal	
P7080HD	133 lpm	Pedestal	
P7080HDZT	133 lpm	Zero Tear Pedestal	
P7210	1000 lpm	Cabinet	Option
P7215	1500 lpm	Cabinet	Option
P7220	2000 lpm	Cabinet	Option
P7280HD	133 lpm	Cabinet	Option

## Integrated Print Management System

The P7000 has a new feature that automatically monitors and communicates ribbon life. Using a specially barcoded spool, the printer can automatically detect when a new or used ribbon is loaded, and all ribbon properties. With a sophisticated algorithm, the system monitors all jobs printed and automatically updates the remaining ribbon life on the front panel display. This allows the system administrator to have precise control over print quality and consumable costs. The accurate presentation of available ribbon life allows for efficient planning of print jobs. For example, you can install a new ribbon before printing large print jobs.

When the ribbon life gets near the end point, the printer displays a ribbon low message and flashes the indicator light. Printing will continue without interruption. Once the ribbon reaches 0% remaining, the alarm sounds, the indicator light flashes, the display updates, and printing pauses. If a new ribbon is loaded, the system automatically detects the change, clears the condition, and restarts the life at 100%. If it is not convenient to change the ribbon immediately, press the Online key and it will resume printing for a few minutes. This should be enough to complete the job. If not, repeat the same procedure indefinitely to extend printing on the same ribbon.

## Output Darkness

By default the system is configured to meet most user requirements. However, some applications require that the output remains darker than the nominal set point while some applications are less critical and could tolerate a lighter final image. The system can easily adjust to this variability. A setting under the Printer Control menu is available that allows the user to adjust the final output. The range is as follows:

Normal (Default)  
Darker +1 through +6  
Lighter -1 through -10

The ribbon life indicator always cycles between 100% and 0%, but if a darker setting is selected, zero will be reached more quickly.

If a lighter setting is selected, the system will extend the amount of printing it takes to reach zero.

## Ribbon Flipping

In some cases, the application's print pattern is narrow enough where only half of the ribbon is used when printing. In these cases, you can flip the ribbon and use the other half. The Integrated Print Management System detects the flip and resets the ribbon life to 100%.

**NOTE:** It is the user's responsibility to ensure the print pattern is sufficiently narrow to support flipping. If not, the ribbon life may falsely indicate 100% for the flipped ribbon.

## Loading a Used Ribbon

You can take ribbons off the printer and reload it at a later time. The ribbon life gauge automatically updates to reflect the correct remaining capacity.

**NOTE:** The ribbon must be reloaded back onto the same printer, and in the same orientation as it was removed. If the used ribbon is loaded onto a different printer, or if it is flipped over, it will incorrectly indicate the ribbon as new.

## Ribbon Log

The Integrated Printer Management System tracks all used ribbons. This data allows you to monitor how many ribbons and ribbon types have been used on the printer. This data is contained in the ribbon log. To print the ribbon log, see page 227.

## **Consumable Monitoring With PrintNet Enterprise**

The Integrated Print Management System works with PrintNet Enterprise (PNE). PNE allows a system administrator to remotely view the current consumable status of all printers. PNE can be configured to deliver alerts on all consumable warnings. When a ribbon reaches the low state, PNE notifies the system administrator remotely via an automated e-mail alert of the low condition. This allows corrective action to be taken before the ribbon reaches its end of life. If the ribbon is not changed, an alert will again be initiated once the ribbon reaches the 0% end point. Refer to your PrintNet Enterprise Remote Management Software manual for details.

## **Graphics Enhancements**

---

The IGP/PGL and IGP/VGL emulations allow you to create and store forms, generate logos, bar codes, expanded characters, and create other graphics. Alphanumeric and bar code data are added as the form is printed.

These emulations are available as factory-installed or field-installed options. For more information, contact your authorized service representative.

## **Taking Care Of Your Printer**

---

Your printer will produce high print quality jobs if it is well taken care of. Periodic cleaning, handling the printer properly, and using the correct printer supplies such as ribbon and paper ensures optimum performance. Chapter 7 explains how to clean the printer, and printer supplies are listed in Appendix A.

---

## Conventions In This Manual

---

All uppercase print indicates control panel keys.

**Example:** Press the CLEAR key, then press the ON LINE key.

Quotation marks (“ ”) indicate messages on the Liquid Crystal Display (LCD).

**Example:** Press the ON LINE key. “OFFLINE” appears on the LCD.

The + (plus) symbol represents key combinations.

**Example:** “Press ▲ + ▼” means press the ▲ (UP) key and the ▼ (DOWN) key at the same time.

---

## Warnings And Special Information

---

Read and comply with all information highlighted under special headings:

**WARNING** A warning notice calls attention to a condition that could harm you.

**CAUTION** A caution notice calls attention to a condition that could damage the printer.

**IMPORTANT** Information vital to proper operation of the printer.

**NOTE:** A note gives you helpful tips about printer operation and maintenance.

---

## Related Documents

---

- *Maintenance Manual* — Explains how to maintain and repair the line matrix printer at the field service level of maintenance.
- *Coax/Twinax Programmer's Reference Manual* — Covers the host control codes and character sets for the Coax and Twinax emulations.
- *Coax/Twinax Programmer's Reference Manual for the Simple Protocol Converter Option* — Covers the host control codes and character sets for the Coax and Twinax Simple Protocol Converter emulations.
- *LinePrinter Plus Programmer's Reference Manual* — Covers the host control codes for the LinePrinter Plus emulation.
- *IGP/PGL Programmer's Reference Manual* — Provides information used with the optional IGP Printronix emulation enhancement feature.
- *IGP/VGL Programmer's Reference Manual* — Provides information used with the optional Code V™ emulation enhancement feature.
- *ANSI Programmer's Reference Manual* — Provides host control codes and character sets for the ANSI emulation.
- *IPDS Twinax Emulation Programmer's Reference Manual* — Provides an overview of Intelligent Printer Data Stream™ (IPDS) features, commands, and diagnostics.
- *Character Sets Reference Manual* — Information about and examples of the character sets available in line matrix printers.

- *Integrated Network Interface Card User's Manual* — Information about network protocols, configuration, and operation.
- *External Network Interface Card User's Manual* — Information about network protocols, configuration, and operation.

## Contact Information

---

### Printronix Customer Support Center

---

**IMPORTANT** Please have the following information available prior to calling the Printronix Customer Support Center:

- Model number
- Serial number (located on the back of the printer)
- Installed options (i.e., interface and host type if applicable to the problem)
- Configuration printout (Press PRT CONFIG on the control panel, then press Enter)
- Is the problem with a new install or an existing printer?
- Description of the problem (be specific)
- Good and bad samples that clearly show the problem (faxing of these samples may be required)

Americas (714) 368-2686

Europe, Middle East, and Africa (31) 24 6489 410

Asia Pacific (65) 6548 4114

<http://www.printronix.com/public/servicessupport/default.aspx>

### Printronix Supplies Department

---

Contact the Printronix Supplies Department for genuine Printronix supplies.

Americas (800) 733-1900

Europe, Middle East, and Africa (33) 1 46 25 1900

Asia Pacific (65) 6548 4116  
or (65) 6548 4182

<http://www.printronix.com/public/supplies/default.aspx>



## Corporate Offices

---

Printronix, Inc.  
14600 Myford Road  
P.O. Box 19559  
Irvine, CA 92623-9559  
Phone: (714) 368-2300  
Fax: (714) 368-2600

Printronix, Inc.  
Nederland BV  
P.O. Box 163, Nieuweweg 283  
NL-6600 Ad Wijchen  
The Netherlands  
Phone: (31) 24 6489489  
Fax: (31) 24 6489499

Printronix Schweiz GmbH  
42 Changi South Street 1  
Changi South Industrial Estate  
Singapore 486763  
Phone: (65) 6542 0110  
Fax: (65) 6546 1588

Visit the Printronix web site at [www.primtronix.com](http://www.primtronix.com)



---

# 2

## *Setting Up The Printer*

---

### **Before You Begin**

Read this chapter carefully before installing and operating the printer. The printer is easy to install. However, for your safety and to protect valuable equipment, perform all the procedures in this chapter in the order presented.

---

### **Power Requirements**

The printer must be connected to a power outlet that supplies AC 100V to 240V +/- 10% at 50 to 60 Hz. The printer automatically senses and adjusts itself to conform to the correct voltage range.

Primary circuit protection is provided by the power switch, which is also a circuit breaker. Consult an electrician if printer operation affects local electrical lines.

**IMPORTANT** Printer power should be supplied from a separate AC circuit protected at 10 amperes for 100 - 120 volts or 5 amperes for 200 - 240 volts at 50 or 60 Hertz.

---

### **Select A Site**


Select a printer site that meets all of the following requirements:

- Permits complete opening of the printer cover and doors.
- For cabinet models, allows at least three feet of clearance behind the printer. (This permits air to circulate freely around the printer and provides access to the paper stacking area.)
- Has a standard power outlet that supplies 88-135 Volts AC or 178-270 Volts AC power, at 47 to 63 Hz.
- Is relatively dust-free.
- Has a temperature range of 10° C to 40° C (50° F to 104° F) and a relative humidity from 15% to 90% non-condensing.
- Is located within the maximum allowable cable length to the host computer. This distance depends on the type of interface you plan to use, as shown in Table 2.


**Table 2. Maximum Interface Connection Cable Length**

Interface Type	Maximum Cable Length
Centronics Parallel	5 meters (15 feet)
Dataproducts Parallel	12 meters (40 feet)
IEEE 1284 Parallel	10 meters (32 feet)
Serial RS-232	15 meters (50 feet)
Serial RS-422	1220 meters (4000 feet)
Coax	1500 meters (4920 feet)
Twinax	1500 meters (4920 feet)
Twinax (shielded cable)	1500 meters (4920 feet)
Twisted Pair / Type 3	300 meters (985 feet)
Ethernet 10/100Base-T	100 meters (328 feet)

## Printer Dimensions



**Figure 1. Printer Dimensions - Cabinet Model**



**Figure 2. Printer Dimensions - Cabinet Model with Paper Stacker**




Figure 3. Printer Dimensions - Pedestal Model

# Printer Component Locations




Figure 4. Printer Component Locations





---

# 3

## *Operating The Printer*

---

### **Powering On The Printer**

---

When you power on the printer, it executes a self-test. The default power-up state is online. When the self-test completes and the software has initialized successfully, the status indicator light turns on, indicating the printer is online. The default value of the type of emulation you have installed appears in the upper right corner of the display. The ribbon life remaining is shown on the second line.

If there is a fault during the self-test, the status indicator flashes and a specific fault message appears on the display (such as "LOAD PAPER"). The alarm also sounds if it is configured to do so. See "LCD Message Troubleshooting Table" on page 254 for information on fault messages and solutions.

---

### **Operating Modes**

---

**Online.** In online mode, the printer can receive and print data sent from the host. Pressing the ON LINE key toggles the printer from online to offline mode. The status indicator is lit in online mode.

**Offline.** In offline mode, you can perform operator functions, such as loading paper and setting top-of-form. You can also move within the printer configuration menus. Pressing the ON LINE key toggles the printer from offline to online mode. The status indicator is off in offline mode.

**Fault.** In fault mode, a condition exists which must be cleared before printing can continue. The status indicator flashes, the alarm beeps (if configured to sound), and a descriptive fault message displays.

The current operating mode can be selected via control panel keys or can result from routine operations such as powering on the printer.

## The Control Panel

Figure 5 shows the keys, displays, and indicators as they appear on the control panel. The following section provides the descriptions, and functions of the control panel keys.

Key combinations are indicated with the plus (+) sign. For example, “Press  $\triangle$  +  $\nabla$ ” means to press the  $\triangle$  key and the  $\nabla$  key at the same time.




Figure 5. Control Panel

## Control Panel Keys

### ON LINE / CLEAR

Toggles the printer between online and offline modes. If a fault condition exists, pressing this key will clear the fault message and return the printer from fault mode to offline mode.

**NOTE:** If the fault condition is not corrected *before* pressing this key, the fault message will reappear when attempting to place the printer online.

### PAPER ADVANCE

Performs advance to top-of-form, as defined by the current active form length. The key works both online and offline.

- If online with data in the printer buffer, the data will print and then the paper will move to the next top-of-form.
- In the fault state, PAPER ADVANCE will advance the paper. The first press moves to the top of the next available form. All subsequent presses advances one forms length as defined by the current active forms length.

## VIEW / EJECT

When the printer is online or offline, pressing this key executes the view or eject function, depending on whether the printer is a cabinet or a pedestal (or zero tear pedestal).

If online with data in the printer buffer, the data prints and the key functions as described below.

If in a fault state, this key will be ignored.

- **View Function** — for cabinet models, pressing the VIEW/EJECT key moves the last data printed to the tractor area for viewing. While in the view state, the message "Printer in View" displays, pressing the UP or DOWN arrow keys moves the paper up or down in 1/72 inch increments. This is done to align the image within a pre-printed form, for example. Refer to the UP and DOWN key functions for additional details on the microstep feature. Pressing VIEW/EJECT a second time moves the paper back to the adjusted print position.

**Eject Function** — for pedestal models, when the VIEW/EJECT key is pressed, the bottom of the last printed form will move to the tear bar position. The message "READY TO TEAR/EJECT To Return" displays. While in this position, pressing the UP or DOWN arrow keys moves the paper up or down in 1/72 inch increments. Refer to the Up and Down key functions for additional details on the microstep feature. When the VIEW/EJECT key is pressed a second time, the printer will move the paper to enable printing on the next available form.

## CANCEL

In offline mode, this key cancels all data in the print buffer, if enabled in the "ADVANCED USER" menu (see page 221). The print buffer is cleared without printing any of the data and the current paper position is set as the top-of-form. If this function is disabled, the CANCEL key will be ignored.

**NOTE:** Use of this key will cause loss of data.

## SET TOF

Sets the top-of-form on the printer. This key is active only when the printer is offline and will not operate if the printer is in a fault condition. The paper moves down to the print position and aligns to the top-of-form. Refer to the *Quick Setup Guide* for complete instructions on how to set the top-of-form.

**NOTE:** If there is any data in the buffer, the paper will move to the last print position.

## PRT CONFIG

In offline mode, PRT CONFIG prints the current short configuration. This key requires a confirmation with the ENTER key; pressing any other key will exit from this function. See "The Configuration Menus" on page 47 for an explanation of configuration menus.

## JOB SELECT

In offline mode, this key allows for fast selection of any of the previously stored configurations. Pressing this key causes the printer to cycle through the following messages: Load Config., Factory Config, Load Config 1, Load Config 2, Load Config 3,...,Load Config 8.

## ENTER

When navigating the configuration menus, ENTER selects the currently displayed option value as the active value. An asterisk (\*) appears next to the active value on the display. ENTER is also used for starting and stopping printer tests and generating a configuration printout.

**NOTE:** The ENTER key must be unlocked in order to function.

See UP + DOWN, below.

The ENTER key lock and unlock function can be configured to be a key combination other than ▲ + ▼ (see page 225).

## UP or DOWN (▲ or ▼)

Moves up or down between levels in the configuration menus and makes vertical forms adjustment. After pressing VIEW, press ▲ or ▼ to adjust the paper up or down in 1/72 inch increments for fine vertical forms alignment. When the printer is in offline mode, press ▲ or ▼ to move through levels in the configuration menus.

## UP + DOWN (▲ + ▼)

Locks and unlocks the ENTER key.

**NOTE:** The ENTER key lock and unlock function can be configured to be a key combination other than ▲ + ▼ (see page 225).

## PREV or NEXT (◀ or ▶)

Moves between the options on the current level of configuration menu. In the configuration menu, press ◀ to scroll backward or press ▶ to scroll forward through the menu selections on the same level.

## PREV + NEXT (◀ + ▶)

When both keys are pressed simultaneously, the printer will reset to the power-up configuration and reset its internal state (in offline mode).

## ▲ + ON LINE (IPDS Emulation only)

In offline mode, press ▲ + ON LINE. If there is data in the printer buffer, the printer will be placed in online mode, print one page, and return to the offline mode. This action can be repeated until the end of a print job. Only one page prints each time you press

▲ + ON LINE. If there is no data in the printer buffer, the printer is placed in online mode.

In the fault state, ▲ + ON LINE does not work.

### **▲ + PAPER ADVANCE (IPDS Emulation only)**

In offline mode, press ▲ + PAPER ADVANCE. The printer will perform a reverse linefeed. If you hold down the ▲ + PAPER ADVANCE keys for longer than 1/2 second, the printer moves to the previous top-of-form position. If there is data in the printer buffer, the data does not print.

In the fault state, ▲ + PAPER ADVANCE does not work.

### **▲ + VIEW (IPDS Emulation only)**

In offline mode, press ▲ + VIEW. If there is data in the IPDS printer buffer, the printer will be placed in online mode, print one line, and return to offline mode. This action can be repeated until the end of the job. This function prints only one line of text. If the data is not text, only 1/6 inch prints. If there is no data in the printer buffer, the printer is placed in online mode for one second and then returns to offline mode.

In the fault state, ▲ + VIEW does not work.

### **Ribbon Life Indicator**

The second line of the LCD displays the remaining life of the currently installed ribbon. The default settings for this feature should match the requirements for most applications; no special user setup is needed. If your particular application requires darker printing or can tolerate lighter printing, the ribbon end point can be adjusted as appropriate. Please refer "Ribbon End Point" on page 68.


## Operational Procedures

This section contains routine printer operating procedures on how to:

- reload paper
- unload paper
- cancel a print job.

### Reload Paper

Do this procedure when “LOAD PAPER” displays. (This message occurs when the last sheet of paper passes through the paper slot.) This procedure reloads paper without removing the last sheet of the old paper supply, while retaining the current top-of-form setting.




**Figure 6. Paper Slot Location**

1. Raise the printer cover. Raise the platen lever as far as it will go. (See Figure 4 on page 23 for the location of the lever.)
2. Press ON LINE/CLEAR to turn off the alarm. Do not open the tractor doors or remove the existing paper.
3. For cabinet models, open the front door. Align the paper supply with the label on the floor. Ensure the paper pulls freely from the box.
4. Feed the paper up through the paper slot (see Figure 6). It may be easier to feed one corner of the new paper up through the slot first. When this corner can be grasped from the top, rotate the paper back to the normal position.

**NOTE:** If you are using thick, multi-part forms and are unable to load the new paper over the existing paper, go to step 15.


5. Hold the paper to prevent it from slipping down and through the paper slot.



**Figure 7. Loading New Paper into the Printer**

6. Pull the new paper above and behind the ribbon mask, but in front of the existing paper. See Figure 4 on page 23 for the ribbon mask location. If necessary, gently press the existing paper back.
7. Align the top edge of the new paper with the top perforation of the existing paper.
8. Load the new paper over the existing paper. Open and load the tractors one at a time to prevent the paper from slipping.

**NOTE:** Make sure that the top edge of the new paper lines up with the top horizontal perforation of the last page.




**Figure 8. Setting the Platen Lever**

9. Turn the platen stop knob clockwise or counterclockwise to match the paper thickness. (The A-B-C scale corresponds approximately to 1-, 3-, and 6-part paper thickness).

**NOTE:** If you are using the same thickness of paper, there is no need to readjust.

10. Lower the platen lever until it stops.
11. Press ON LINE/CLEAR to remove the “LOAD PAPER” fault message from the display.
12. Press PAPER ADVANCE several times to make sure the paper feeds properly beyond the tractors and over the lower paper guide. Feed sufficient paper to ensure the paper stacks correctly.
13. Close the printer top cover. Close the cabinet front door.
14. Press ON LINE/CLEAR to place the printer in online mode and resume printing.






**Figure 9. Paper Slots on the Printers**


**NOTE:** Perform steps 15 to 32 only if you are unable to load the new paper over the existing paper.

15. Open both tractor doors.
16. Remove the old paper from the tractors. Allow the paper to fall into the paper supply area.
17. Feed the new paper up through the paper slot. Hold the paper to prevent it from slipping down through the paper slot.



**Figure 10. Loading Paper on the Left Tractor**


18. Pull the paper above and behind the ribbon mask. See Figure 4 on page 23 for the ribbon mask location.
19. Load the paper on the left tractor.
20. Close the tractor door.



**Figure 11. Positioning the Left Tractor to Avoid Damage**


**CAUTION** To avoid damage to the printer caused by printing on the platen, always position the left tractor unit directly to the left of the “1” mark on the paper scale.

21. Normally, you should not need to adjust the position of the left tractor. If adjustment is necessary, unlock the left tractor. Slide the tractor until it is directly to the left of the number “1” on the paper scale and lock it. (You can also use the paper scale to count columns.)



**Figure 12. Loading Paper onto the Sprockets**

- 22. Unlock the right tractor.
- 23. Load the paper onto the sprockets and close the tractor door.  
If necessary, slide the right tractor to remove paper slack or to adjust for various paper widths. Then, lock the tractor.



**Figure 13. Using the Paper Guide to Orient the Paper**


**24. Pedestal models:**

Using the vertical position knob to move the paper up, guide the paper over the upper paper guide and through the slot to the rear of the top cover. For pedestal models with the Quick Access Cover, refer to the *Quick Setup Guide* for paper exiting options.

25. Press PAPER ADVANCE several times to make sure the paper feeds properly beyond the tractors and over the lower paper guide. Feed sufficient paper to ensure the paper stacks correctly.

**26. Cabinet models:**


Open the cabinet rear door. Make sure the paper is aligned with the label in the output area (inside the cabinet). Close the front and rear doors.



**Figure 14. Aligning the Perforation with the TOF Indicator**

27. Align the top of the first print line with the TOF indicator on the tractor by rotating the vertical position knob. For best print quality, it is recommended that the top-of-form be set at least one print line or more below the perforation.

**NOTE:** For exact positioning, press the VIEW/EJECT key to move the last data printed to the tractor area for viewing. While in View mode “Printer in View” displays. Press the Up or Down Arrow keys to move the paper vertically in small increments. Pressing the VIEW/EJECT key a second time moves the paper back to the adjusted print position. The key works both online and offline provided that the printer is in View mode. (This procedure is applicable for both the cabinet and pedestal models.)



**Figure 15. Adjusting the Platen Lever**

28. Turn the Auto Platen Stop Knob clockwise or counterclockwise to match the paper thickness. (The A-B-C scale corresponds approximately to 1-, 3-, and 6-part paper thickness. Adjust until you have the desired print quality).

**NOTE:** The platen stop allows you to set an optimum and consistent thickness that is not affected when opening and closing the platen lever.

29. Lower the platen lever until it stops.


30. Press ON LINE/CLEAR to clear any fault messages (such as “LOAD PAPER”) from the LCD.

31. Press SET TOF. The top-of-form you have set moves down to the print position. If there is data in the buffer, the paper moves forward to the last print position on the next page.

32. Press ON LINE/CLEAR and close the printer cover.


## Unload Paper

1. Press ON LINE/CLEAR to place the printer in offline mode and open the printer cover.
2. For cabinet models, open the cabinet rear door. For models with the power stacker installed, press the STACKER UP key on the rear control panel.



**Figure 16. Unloading the Paper from the Printer**


3. Tear off the paper at the perforation.
4. Allow the paper to fall to the back of the printer and into the paper stacking area.
5. For pedestal models, remove the stacked paper from the paper tray.



**Figure 17. Removing Stacked Paper from the Printer**

6. For cabinet models, remove the stacked paper from the rear cabinet floor. For cabinet models with the power stacker installed, remove the paper from the wire paper tent and press the STACKER DOWN key to lower the stacker mechanism.
7. Close the cabinet rear door.





**Figure 18. Completely Removing the Paper**

8. To completely remove the paper from the printer:
  - a. Raise the platen lever as far as it will go and open both tractor doors.

**CAUTION** Be careful when pulling any paper backward through the paper path, especially when using a label stock. If you are not careful, labels can detach and adhere to the printer within the paper path, where only an authorized service representative can remove them.

- b. Open the cabinet front door.
- c. Gently pull the paper down through the paper slot. Allow the paper to fall into the paper supply area.
- d. Remove the paper from the paper supply area.

## Integrated Print Management System

---

The Integrated Print Management System feature automatically monitors and communicates the status of the ribbon's life to help the operator know when to change ribbons. Using a special bar coded spool, the P7000 automatically detects when a new or used ribbon is installed and determines the ribbon's length, ink color, and expected yield. The ribbon life, starting from 100% when new and decreasing to 0% when depleted, is always displayed on the control panel. See Figure 5 on page 26.

When the ribbon life reaches 2%, a warning message "RIBBON UNDER 2%/ Change RBN soon" appears on the control panel display. The control panel status indicator lamp flashes. The printer will continue printing in this condition until the ribbon life reaches 0% at which time, printing will stop. The ribbon may be changed at any time while the printer is in the "RBN END POINT/ Change Ribbon" condition without losing data in the printer's buffer. Simply follow the procedures outlined below to change the ribbon.

You may also resume printing for approximately two more minutes without changing the ribbon by pressing the ON LINE/CLEAR key twice. This may be done as many times as needed to complete the job in progress.


### Lighter Or Darker Print

---

The ribbon life value as determined by the Integrated Print Management System is factory set so that the image quality at the end of the ribbon life is as good as it was when the ribbon was new. You may adjust the ribbon end point for a lighter or darker image as required for your printing needs. See "PRINTER CONTROL" on page 218..


## Changing Ribbons

Before changing the ribbon, determine whether at the end of ribbon life if you want to make the print lighter (extend the ribbon life) or darker (shorten the ribbon life). If you want to make the print lighter, go to “Ribbon End Point” on page 218 and follow the procedures for adjusting the image density. If you are satisfied with the print darkness, or if you want to increase the darkness at the end of ribbon life, continue with the following steps.



**Figure 19. Preparing to Load the Ribbon**

1. Open the printer cover.
2. Raise the platen lever as far as it will go.
3. Close the tractor doors.
4. Remove the old ribbon and discard properly.




**Figure 20. Loading the Barcoded Ribbon**

5. Place the full spool on the right hand side ribbon hub and press it into place.

**IMPORTANT**

The full spool has a barcode label on the bottom side and a date code label on the top. Once the sensor reads and logs the ribbon barcode, the Integrated Print Management System starts to track ribbon usage. A date code label is on the top side of the right hand spool.

If you remove the ribbon during the course of its life and want to re-install the same ribbon, be sure to place the same spools on the correct hubs.



**Figure 21. Threading the Ribbon Around the Ribbon Guide**

6. Thread the ribbon around the ribbon guide and along the ribbon path. Be sure to thread the ribbon between the hammer bank cover and the ribbon mask.
7. Place the empty spool on the left hub.
8. Press the spool down until it snaps into place.
9. Turn the left spool by hand to make sure the ribbon tracks correctly in the ribbon path and around the ribbon guides.

**NOTE:** If there are ink stained fingerprints on the ribbon barcode (located on the ribbon spool), wipe it clean with a soft cloth or towelette moistened with alcohol.

10. Close the platen lever.
11. Close the printer top cover.

If you want to increase the darkness level of the ribbon at the end of life, go to “Ribbon End Point” on page 218 and follow the procedures for adjusting the image density.

If you are satisfied with the print darkness, press the ON LINE/CLEAR key twice to return the printer to operation.

## Cancel A Print Job

---

The procedure to cancel a print job depends on the printer emulation and your application software. Contact your system administrator for additional information.

1. If the printer is online, press ON LINE/CLEAR to place the printer in offline mode.
2. From the host system, stop the print job.

**NOTE:** If the print job is not stopped from the host system before pressing CANCEL, the print job continues with data missing when the printer returns to online mode. Exercise caution to prevent unwanted data loss occurrences, as this function deletes unprinted data in the printer. This function is active only in offline mode; the purpose of this function is to eliminate the necessity of printing unwanted data when print jobs are canceled.

3. Press CANCEL.

**NOTE:** You may need to enable the Cancel option on the front panel. See “ADVANCED USER” on page 221. for details.

4. Set the top-of-form. Refer to the Quick Setup Guide.

---

# 4

## *The Configuration Menus*

---

### Configuration Overview

---

To print data, the printer must respond correctly to signals and commands received from the host computer. Configuration is the process of matching the printer's operating characteristics to those of the host computer and to specific tasks, such as printing labels or printing on different sizes of paper. The characteristics which define the printer's response to signals and commands received from the host computer are called configuration parameters.

You can configure the printer using the configuration menus and the control panel or by sending control codes in the data stream from a host computer attached to the printer. This chapter provides an introduction to configuring the printer and includes the configuration menus available (depending on which emulation you have installed in the printer).

#### **IMPORTANT**

**Configuration directly affects printer operation. Do not change the configuration of your printer until you are thoroughly familiar with the procedures in this chapter.**

---

### Changing Parameter Settings

---

You may change a printer parameter setting, such as line spacing or forms length, either by pressing keys on the control panel or by sending emulation control codes in the data stream from a host attached to the printer. The control panel allows you to configure the printer's resident set of configuration menus. An example procedure for using the control panel to change parameter settings begins on page 49.

When control codes are sent from a host attached to the printer, they override control panel settings. For example, if you set the line spacing to 6 lpi with the control panel, and application software later changes this to 8 lpi with a control code, the control code overrides the control panel setting.

---

### Saving Parameter Settings

---

The parameter settings that you have changed can be permanently stored in the printer's memory as a configuration. See "Auto Save Configuration" on page 52. and "Saving Your New Configuration" on page 52.

You may also save your new configurations using the PTX\_SETUP command host control code. See your *LinePrinter Plus Programmer's Reference Manual* for details.

## Default And Custom Configurations

A configuration consists of a group of parameter settings, such as line spacing, forms length, etc. Your printer provides a fixed default configuration and allows you to define several custom configurations for use with particular print jobs. The factory default configuration can be loaded, but it cannot be altered.

Eight configurations can be modified for unique print job requirements. The “Save Config.” option allows you to save eight groups of parameter settings in memory as custom configurations numbered from 1 through 8. An explanation on how to save a set of parameter values as a custom configuration using the “Save Config.” menu option begins on page 52.

## Navigating The Menus

To manipulate configurations review the following instructions about navigating through the menus.

You must be offline to move within the menus.

ON LINE/CLEAR




Press to toggle between ONLINE and OFFLINE. Menus are accessed with the printer offline.



OR



Press to move up or down through the menu levels.



Press to scroll through the available choices on a chosen level.

ENTER



Press to confirm selection.



+




Press to lock and unlock the ENTER key. The ENTER key is locked by default to prevent you from accidentally changing the printer configuration. The lock and unlock function can be configured to be other than ▲ + ▼ (See “Set Lock Key” on page 225.)

To experiment with navigating the menus, use the example on the next page as a tutorial.














# Changing Parameters Example













A configuration consists of several parameters. The default factory configuration has a starting set of parameters. In the configuration menu above, and in all the configuration menus in this chapter, the factory default values are indicated by an asterisk (\*).

Your print jobs may require parameter values which vary from the default settings. This section provides an example procedure for changing individual parameter values.

The following procedure shows how to change and save the settings for the Barcode Quality and Language options. Use these guidelines to navigate the configuration menus and change other parameters.

Step	Press	LCD	Notes	
1.	Make sure the printer is on.			
2.	ON LINE/CLEAR 	OFFLINE QUICK SETUP	Allows you to make configuration changes.	
3.	 + 	ENTER SWITCH UNLOCKED		
		OFFLINE QUICK SETUP		
4.	 UNTIL	OFFLINE PRINTER CONTROL		
5.		PRINTER CONTROL Ribbon End Point		
6.	 UNTIL	PRINTER CONTROL Barcode Quality		
7.		Barcode Quality Dark*		
8.	 OR 	Barcode Quality Draft		Cycle through the choices.
9.	ENTER 	Barcode Quality Draft*		The * indicates this choice is active.
10.		PRINTER CONTROL Barcode Quality		

Step	Press	LCD	Notes
11.	 UNTIL	PRINTER CONTROL Display Language	Press until the desired parameter displays.  The * indicates this choice is active.  Locks the ENTER key.  Press ENTER to automatically save configuration changes. Press ONLINE to continue without saving.  Configuration changes have been saved as Configuration 1, and will be set as the Power-Up config. The printer will then be brought online.  Places the printer online without permanently saving the configuration changes.
12.		Display Language English*	
13.	 OR 	Display Language Spanish	
14.	ENTER 	Display Language Spanish*	
15.	 + 	ENTER SWITCH LOCKED	
16.	ON LINE/CLEAR 	ENTER = Save ONLINE = No Save	
17A.	ENTER 	Cfg = 1* = Power-Up Cfg	
17B.	ON LINE/CLEAR 	ONLINE Ribbon Life = 100%	
18.	The printer is ready for operation		

## Auto Save Configuration

---

After any changes are made to the Factory Default configuration menu items, you will be prompted to save the changes to “Config #” when you place the printer online. “#” represents the next available unassigned configuration number. When prompted, press one of the following:

- **Enter.** Saves to Config 1 or the next available Config, and becomes the power-up config.
- **Online.** Changes will be implemented but saved only temporarily until deliberately saved as a new configuration or until you power off the printer. All changes will be lost when you power off the printer.

## Saving Your New Configuration

---











The Save Config. option allows you to save up to eight custom configurations to meet different print job requirements. Once you have changed all of the necessary parameters, you may save them as a numbered configuration (Example 1 on page 53) or a named configuration (Example 2 on page 55) that can be stored and loaded later for future use. If you do not save your configuration using the Auto Save, or this option, all of your parameter changes will be erased when you power off the printer.










Once you have saved a custom configuration using this option, it will not be lost if you power off the printer. You can load a configuration for a specific print job (see “Load Config.” on page 70). You can also modify and resave it. You may want to print your configurations (see “Print Config.” on page 70) and store them in a safe place, such as inside the printer cabinet. If the Protect Configs. parameter is enabled and you try to resave an existing configuration, the new configuration will not be saved until the existing configuration has been deleted (see “Delete Config.” on page 70).

**NOTE:** Once you change active emulations, any changes to the previously selected emulation will be gone unless they have been saved.

### Example 1











This example shows how to save a configuration as a numbered configuration, then later print it.












Step	Press	LCD	Notes
1.	Make sure the printer is on.		
2.	ON LINE/CLEAR 	OFFLINE QUICK SETUP	
3.	 + 	ENTER SWITCH UNLOCKED	Allows you to make configuration changes.
		OFFLINE QUICK SETUP	
4.	 UNTIL	OFFLINE CONFIG. CONTROL	
5.		CONFIG. CONTROL Load Config.	
6.	 UNTIL	CONFIG. CONTROL Save Config.	
7.		Save Config. 1*	
8.	 OR 	Save Config. 2	Cycle through the choices.
9.	ENTER 	Save Config. 2*	The * indicates this choice is active.

Step	Press	LCD	Notes
<p><b>NOTE:</b> We recommend that you print the configuration. To print the configuration go to Step 9. To skip this procedure and resume printer operation, go to Step 14.</p>			
10.		CONFIG. CONTROL Save Config.	
11.	 UNTIL	CONFIG. CONTROL Print Config.	
12.		Print Config. Current	
13.	 OR 	Print Config. 2	Press until the desired parameter displays.
14.	ENTER 	OFFLINE CONFIG. CONTROL	The selected configuration is printed.
15.	 + 	ENTER SWITCH LOCKED	Locks the ENTER key.
16.	ON LINE/CLEAR 	ONLINE Ribbon Life = 100%	
17.	If you printed out the configuration, store it in a safe place. The printer is ready for operation.		






### Example 2

This example shows how to save a configuration as a named configuration.

Step	Press	LCD	Notes
1.	Make sure the printer is on.		
2.	ON LINE/CLEAR 	OFFLINE QUICK SETUP	
3.	 + 	ENTER SWITCH UNLOCKED	Allows you to make configuration changes.
		OFFLINE QUICK SETUP	
4.	 UNTIL	OFFLINE CONFIG. CONTROL	
5.		CONFIG. CONTROL Load Config.	
6.	 UNTIL	CONFIG. CONTROL Name Configs.	
7.		Name Configs. 1	The LCD flashes.
8.	 UNTIL	Name Configs 2	You will rename config 2.
9.		2 2*	
10.	 UNTIL	2 T	Cycle through the choices until "T" displays.

Step	Press	LCD	Notes
11.		2 T_	Saves the first character.
12.	 UNTIL	2 TE	Cycle through the choices until "E" displays.
13.		2 TE_	Saves the second character.
14.	 UNTIL	2 TES	Cycle through the choices until "S" displays.
15.		2 TES_	Saves the third character.
16.	 UNTIL	2 TEST	Cycle through the choices until "T" displays.
17.		2 TEST_	Saves the fourth character.
18.	ENTER 	Name Configs TEST	The configuration is renamed TEST.
19.		CONFIG. CONTROL Name Configs	
20.	 UNTIL	CONFIG. CONTROL Save Config.	
21.		Save Config. 1*	



Step	Press	LCD	Notes
22.		Save Config. TEST	TEST now appears as one of configuration choices.
23.	ENTER 	Saving Configuration	
		Save Config. TEST*	Your configuration is saved as TEST.
24.	 + 	ENTER SWITCH LOCKED	Locks the ENTER key.
25.	ON LINE/CLEAR 	ONLINE Ribbon Life = 100%	

Now you have the saved configuration for later use if needed.

## Optimizing Print Quality

### LP+, IGP/PGL, and IGP/VGL Emulations

You can optimize print quality for darker and sharper barcodes and characters. Doing so, however, will decrease the printer speed.

To optimize print quality, you can change the values of the following configuration parameters:

- **Bar Code Quality (Printer Control menu):** Select “Dark” or “Recommended.” Recommended prints the darkest images, but at the slowest speed. Dark prints at a faster speed than Recommended, but the characters are not as dark. (See page 219 for a written description of Bar Code Quality.)
- **Print Quality (IGP/PGL emulation):** Select “Best” or “High.” Best prints the darkest images, but at the slowest speed. High prints at a faster speed than Best, but the characters are not as dark. (See page 177 for the IGP/PGL Configuration Menu, and see page 186 for a written description of Print Quality.)
- **Print Quality (IGP/VGL emulation):** Select “High.” (See page 190 for the IGP/VGL Configuration Menu, and see page 197 for a written description of Print Quality.)

## Optimizing Print Speed

---

### LP+, IGP/PGL, and IGP/VGL Emulations

The printer has been configured at the factory for optimal print speed. To optimize print quality instead, you can change values for specific configuration parameters such as Barcode Quality and Print Quality. Doing so, however, will decrease the printer speed.


If you have optimized the printer for print quality, you can change it to optimal speed by selecting the values as follows:

- **Bar Code Quality (Printer Control menu):** Select Draft. (See page 59 for the Configuration Main Menu, and see page 219 for a written description of Bar Code Quality.)
- **Print Quality (IGP/PGL emulation):** Select Dataprocessing. (See page 177 for the IGP/PGL Configuration Menu, and see page 186 for a written description of Print Quality.)
- **Print Quality (IGP/VGL emulation):** Select Dataprocessing. (See page 190 for the IGP/VGL Configuration Menu, and see page 197 for a written description of Print Quality.)

### Coax/Twinax Emulation

You can increase print speed by selecting the Enable mode for the Early Print Complete configuration parameter in the Coax/Twinax Emulation. However, if an error occurs while in Enable mode, you may lose data. For more information, refer to “Early Print Complete” on page 109. (For the Coax/Twinax Emulation menu, see page 104.)

# Main Menu



<sup>1</sup>If installed

<sup>2</sup> If Twinax is selected

<sup>3</sup> If VGL is enabled

<sup>4</sup> If LP+ is selected

<sup>5</sup> If ANSI is installed

<sup>6</sup> If LG is installed

<sup>7</sup> If PCL-II is installed

<sup>8</sup> If Ethernet is installed

<sup>9</sup> Not available in LG or PCL-II


<sup>10</sup> Not available if PNE Port number is set to Serial.

<sup>11</sup> If Real Time Clock (RTC) option is installed.

<sup>12</sup> Available for Zero Tear Pedestal printer only.

<sup>13</sup> Only if a Cisco radio card is installed.

**Figure 22. Main Menu Configuration**




<sup>1</sup>If installed  
<sup>2</sup> If Twinax is selected  
<sup>3</sup> If VGL is enabled  
<sup>4</sup> If LP+ is selected  
<sup>5</sup> If ANSI is installed  
<sup>6</sup> If LG is installed  
<sup>7</sup> If PCL-II is installed  
<sup>8</sup> If Ethernet is installed  
<sup>9</sup> Not available in LG or PCL-II  
<sup>10</sup> Not available if PNE Port number is set at Serial  
<sup>11</sup> If Real Time Clock (RTC) option is installed.  
<sup>12</sup> Available for Pedestal printer only.

---

Brief descriptions follow for the first-level configuration menu options:

- **QUICK SETUP** — These options allow quick access to the most frequently changed or inputted parameters during the installation of the printer.
- **ZTP SETTINGS** These options allow you to set parameters for zero tear pedestal printers.
- **CONFIG. CONTROL** — These options allow you to save, print, load, delete, name, and reset entire sets of configuration parameters.
- **HOST INTERFACE** — These options allow you to select either the Serial RS-232, Serial RS-422, Centronics® parallel, Dataproducts® parallel and Long Lines, Ethernet™, IEEE® 1284 parallel, Auto Switching, Coax or Twinax interface for the printer. This menu also allows you to configure several parameters for each interface.
- **NETWORK SETUP** — This option allows you to select from Ethernet Address options and Ethernet Parameters options.
- **ACTIVE (IGP) EMUL** — This menu allows you to select the PGL or VGL emulation from the menu if IGP is installed.
- **ACTIVE EMULATION** — This menu allows you to activate the desired emulation to be used with your printer.
- **EMULATION** — This menu allows you to configure the options which are available for the current operating (active) emulation. For example, if LinePrinter+ is the active emulation, then the LinePrinter+ emulation options can be configured using this menu.
- **PRINTER CONTROL** — This menu allows you to select parameters common to a general user, such as display language and Barcode quality.
- **ADVANCED USER** — This menu allows you to select several advanced operating parameters for the printer, such as the speed at which paper will advance when slewing.
- **DIAGNOSTICS** — This menu includes the diagnostic tests, system memory, and statistics of the printer.
- **DATE** — This menu allows you to set the printer's real time clock. The parameters include hours, minutes, year, month, and day.
- **Printer MGMT** — These options allow you to select the PNE port type, port number, port timeout period, status port number, and management port number.

# QUICK SETUP



\* = Factory Default

<sup>1</sup> If installed

<sup>2</sup> If VGL is enabled

<sup>3</sup> If VGL is selected

<sup>4</sup> If LP+ is selected

<sup>5</sup> If ANSI is installed

<sup>6</sup> If LG is installed

<sup>7</sup> If PCL-II is installed

<sup>8</sup> If PGL is selected


<sup>9</sup> Available for Zero Tear Pedestal printer only

<sup>10</sup> If CTHI is installed and Autoswitching or Twinax is selected

<sup>11</sup> Available only if ANSI, LG, or PCL is installed

<sup>12</sup> Available only if ANSI, LG, and PGL are not installed

**QUICK SETUP**  
(from page 62)



Funct. of CPI  
136 Characters\*  
(1-272)

Bot. Frm 66/6\*  
(0-198)  
Top Mrg 0/6\*  
(0-198)

Left Mrg 0.00\*  
(0-198)  
Top Mrg 0/6\*  
(0-198)

Inches/Page\*  
Lines/Page

13.2 Inches\*  
13.6 Inches

Ribbon End  
Point

Darker +6  
Darker +5  
Darker +4  
Darker +3  
Darker +2  
Darker +1  
Normal\*  
Lighter -1  
Lighter -2  
Lighter -3  
Lighter -4  
Lighter -5  
Lighter -6  
Lighter -7  
Lighter -8  
Lighter -9  
Lighter -10

Save Config

1\*  
2 - 8

Power Up  
Config

Factory\*  
1 - 8

- \* = Factory Default
- 1 If installed
- 2 If VGL is enabled
- 3 If VGL is selected
- 4 If LP+ is selected
- 5 If ANSI is installed
- 6 If LG is installed
- 7 If PCL-II is installed
- 8 If PGL is selected
- 9 Available for Zero Tear Pedestal printer only
- 10 If CTHI is installed and Autoswitching or Twinax is selected
- 11 Available only if ANSI, LG, or PCL is installed
- 12 Available only if ANSI, LG, and PGL are not installed

## Host Interface

The Host Interface menu enables you to select and configure interfaces between the printer and your host computer.

## Device ID

This parameter defines the printer emulation as IPDS, 4234-2 or 5225. After the emulation has been changed, a POR status is sent to the host. IPDS is the default.

### Adapter Address

- **IP Address.** A numeric address such as 123.45.61.23 which identifies a printer or server in a LAN or WAN.
- **Subnet Mask.** A binary value used to divide IP networks into smaller subnetworks or subnets. This mask is used to help determine whether IP packets need to be forwarded to other subnets.
- **Gateway Address.** A gateway address is the IP address of a hardware device (gateway) that translates data between two incompatible networks, which can include protocol translation.
- **MAC Address.** This menu item is the Manufacturer's Assigned Number, and is unique for each printer. It is read-only.
- **DHCP.** You can enable/disable the DHCP protocol using this option, but consult your administrator for the appropriate setting.

### Ethernet Address

- **IP Address.** A numeric address such as 123.45.61.23 which identifies a printer or server in a LAN or WAN.
- **Subnet Mask.** A binary value used to divide IP networks into smaller subnetworks or subnets. This mask is used to help determine whether IP packets need to be forwarded to other subnets.
- **Gateway Address.** A gateway address is the IP address of a hardware device (gateway) that translates data between two incompatible networks, which can include protocol translation.
- **MAC Address.** This menu item is the Manufacturer's Assigned Number, and is unique for each printer. It is read-only.
- **DHCP.** You can enable/disable the DHCP protocol using this option, but consult your administrator for the appropriate setting.

### WLAN Address

- **IP Address.** A numeric address such as 123.45.61.23 which identifies a printer or server in a LAN or WAN.
- **Subnet Mask.** A binary value used to divide IP networks into smaller subnetworks or subnets. This mask is used to help determine whether IP packets need to be forwarded to other subnets.
- **Gateway Address.** A gateway address is the IP address of a hardware device (gateway) that translates data between two incompatible networks, which can include protocol translation.
- **MAC Address.** This menu item is the Manufacturer's Assigned Number, and is unique for each printer. It is read-only.
- **DHCP.** You can enable/disable the DHCP protocol using this option, but consult your administrator for the appropriate setting.



---

## ZTP Data Time

This option sets the pause time in the data stream that the ZTP requires before moving the form to the tear bar once a print job is completed. The values range from .5 to 5 seconds. The default is .5 seconds.

## ZTP Wait Time

This option sets the minimum amount of time that the form stays at the tear bar. This allows you time to remove the form before the form is retracted to print the next form. The adjustable values range from 500 to 5000 milliseconds in increments of 500 milliseconds. The default value is 2 seconds.

## ZTP TearDistance

This option sets the tear off distance from the current print position to the tear bar. Adjustable values in increments of 1/144th of an inch range from 200 to 2880. The up and down arrows adjust the display value. When you press the **Enter** key, the selected value is stored and a scale is printed to indicate the current tear off position. The default value is 1060.

**NOTE:** When a new value is selected, the printer will lose the current print position. You must reset the top of form to automatically save the new value.

## Active Emulation

The Active Emulation menu enables you to select either the ANSI, PCL, LG, PGL, or VGL emulation.

## Active IGP Emulation

The Active IGP Emulation menu enables you to activate either the PGL or VGL emulation.

## PGL SFCC

You can specify which hex code (1-FF) will be used as the Special Function Control Character (SFCC). The SFCC denotes that the following data is an IGP command.

- **7E** (the default)
- **1 – FF**

## VGL SFCC

You can specify which hex code (1-FF) will be used as the Special Function Control Character (SFCC). The SFCC denotes that the following data is an IGP command.

- **5E** (default)
- **1 – FF**

## Printer Protocol

Select the LinePrinter+ protocol you wish to use. Refer to the *LinePrinter Plus Programmer's Reference Manual* for more information.

## Form Length

Form length is the number of lines that can be printed on a page. You can set the form length in inches, millimeters (mm), or as a function of the current lpi (lines per inch).

## Form Width

The form width can be specified in inches, millimeters, or as a function of the current cpi (characters per inch). The forms width set should not exceed the actual paper width.

## Select CPI

This parameter lets you specify the characters per inch (cpi) values.

## Select LPI

This parameter lets you specify the lines per inch (lpi) values.

## P-Series SFCC

This parameter allows you to select which ASCII codes will function as the Special Function Control Code (SFCC) command delimiter. P-Series codes can use hex 00 through hex 7F. Options include the following:

- **SOH (hex 01)** (the default)
- **ESC (hex 1B)**
- **ETX (hex 03)**
- **CIRCUMFLEX (hex 5E)** – also called caret (^)
- **TILDE (hex 7E)** – (~)

**NOTE:** SOH, ETX, and ESC are non-printables. The characters (^) and (~) are printable; however, do not use them as printables in the host data stream if either is chosen as a delimiter because print errors will occur.

## Margins

- **Left Margin.** Set in columns. Column zero is defined as the far left edge of the page, and column numbering increments from left to right.
- **Right Margin.** Set in columns. Column zero is defined as the far right edge of the page, and column numbering increments from right to left.
- **Top Margin.** Defined in lines, starting from line zero at the top of the page and incrementing from the top down.
- **Bottom Margin.** Defined in lines, starting from line zero at the bottom of the page and incrementing from the bottom up.

---

## Form Length

Form length is the number of lines that can be printed on a page. You can set the form length in inches, millimeters (mm), or as a function of the current lpi (lines per inch).

## Form Width

The form width can be specified in inches, millimeters, or as a function of the current cpi (characters per inch). The forms width set should not exceed the actual paper width.

## Vert Forms

- **Bot Frm 66/6** (default). This option sets the bottom margin for the forms. You must specify the bottom margin in lines (at 6 lines per inch), ranging from 0 to 198 lines (33 inches). The default setting is 66. Press the right arrow to increase the value, left arrow to decrease the value, and ENTER to change units. Selecting a value for this option resets the top margin to 0, so the top margin must be redefined after this option is selected.
- **Top Mrg 6/0** This option sets the top margin for the forms. You must specify the top margin in lines (at 6 lines per inch), ranging from 0 to 198 lines (33 inches). The default setting is 0. Press the right arrow to increase the value, left arrow to decrease the value, and ENTER to change units. The margins will automatically adjust so that the top and bottom margins do not cross each other.

## Horiz Forms

- **Left Mgr 0.00** (default). This sets the left margin for the forms. You must specify the left margin in 1/10 inch increments, from 0 to 13.1 inches. The default value is 0. Press the right arrow to increase the value, left arrow to decrease the value, and ENTER to change units. The margins will automatically adjust so that the left and right margins do not cross each other.
- **Right Mrg 13.2**. This sets the right margin for the forms. You must specify the right margin in 1/10 inch increments, from 0.1 to 13.2 inches. The default value is 13.2. Press NEXT to increase the value, PREV to decrease the value, and ENTER to change units. The margins will automatically adjust so that the left and right margins do not cross each other.

## Page Length Rep

- **Inches/Page** (default). Allows the user to set the page length in inches.
- **Lines/Page**. Allows the user to set the page length in number of lines.

## Max Line Width

Set the maximum line width at either 13.2 inches or the maximum width of the printer.

## Ribbon End Point

This parameter adjusts the point at which the system will declare the ribbon as being expended. The life count will always be from 100% to 0%, but if a darker setting is selected 0% will be reached more quickly. If a lighter setting is selected, the system will extend the time it takes to reach 0%.

## Save Config

This option allows you to save up to eight configurations to meet different print job requirements. This eliminates the need to change the parameter settings for each new job. The configurations are stored in memory and will not be lost if you turn off the printer. If the Protect Configs. parameter is enabled, the new configuration will not be saved unless the existing configuration has been deleted first. The factory default configuration cannot be changed. See “Saving Your New Configuration” on page 52 for details.


## Power Up Config

This option allows you to specify which of the nine configurations (Factory or 1-8) will be the power-up configuration.

# ZTP SETTINGS

\* = Factory Default

<sup>1</sup> Available for Zero Tear Pedestal printers only.



## ZTP Function

This option enables or disables all unique ZTP functions. The default is Enable.

**NOTE:** When the ZTP Function is enabled, the View/Eject key is disabled and Slow Paper Slew is enabled.

## ZTP TearDistance

This option sets the tear off distance from the current print position to the tear bar. Adjustable values in increments of 1/144th of an inch range from 200 to 2880. The up and down arrows adjust the display value. When you press the **Enter** key, the selected value is stored and a scale is printed to indicate the current tear off position. The default value is 1060.

**NOTE:** When a new value is selected, the printer will lose the current print position. You must reset the top of form to automatically save the new value.

### ZTP Data Time

This option sets the pause time in the data stream that the ZTP requires before moving the form to the tear bar once a print job is completed. The values range from .5 to 5 seconds. The default is .5 seconds.

### ZTP Wait Time

This option sets the minimum amount of time that the form stays at the tear bar. This allows you time to remove the form before the form is retracted to print the next form. The adjustable values range from 500 to 5000 milliseconds in increments of 500 milliseconds. The default value is 2 seconds.


### ZTP Platen Open

This option allows the user to have the platen open whenever forms are reversed. Enabled is the default, used for most papers and labels. The feature can be disabled as required by some multi-part forms.

## CONFIG. CONTROL

The CONFIG. CONTROL menu allows you to control your printer's configurations according to the specifications necessary for your print jobs.

\* = Factory Default



### **Load Config.**

The printer can store numerous configurations in memory. This parameter allows you to select and load a specific configuration.

### **Save Config.**

This option allows you to save up to eight configurations to meet different print job requirements. This eliminates the need to change the parameter settings for each new job. The configurations are stored in memory and will not be lost if you turn off the printer. If the Protect Configs. parameter is enabled, the new configuration will not be saved unless the existing configuration has been deleted first. The factory default configuration cannot be changed. See “Saving Your New Configuration” on page 52 for details.

### **Print Config.**

This option is used to print a listing of various stored printer configurations. Store printouts of your configurations in a safe place for quick referral.

### **Delete Config.**

You can delete one or all of your eight customized configurations. The factory default configuration cannot be deleted.

### **Power-Up Config.**

You can specify which of the nine configurations (Factory or 1-8) will be the power-up configuration.

### **Protect Configs.**

You can specify whether or not a new configuration should overwrite an existing configuration when you activate the Save Configs. parameter. When disabled (default), the new configuration will overwrite the existing configuration. When enabled, the new configuration will *not* overwrite the existing configuration, and the message “CONFIG. EXISTS / Delete First” displays.

---

## Name Configs

You may specify a 15-character name which can be used to refer to a configuration. The name you enter for a configuration will be used in the Load Config., Save Config., Print Config., Delete Config., and Power-Up Config. menus. The name can only be cleared by using the Reset Cfg Names menu.

When you move into the Name Configs. menu, the top line of the display shows the current configuration name. The second line of the display is initially the same as the top line. You can modify the second line of the display without affecting the top line until the ENTER key is pressed, which sets the modified name.

Press the UP or DOWN ( ▲ or ▼ ) keys to cycle through the values available for that character at the cursor location. Press the NEXT ( ► ) key to move to the next character to be modified. Press the PREV key ( ◀ ) to go back to a character you have already modified. Continue until you have entered the name you want to give to this configuration, then press ENTER to save. The name you entered will now represent this configuration on the printer's front panel. To exit this menu without saving, press any key other than the ENTER key. The configuration name will revert to the last saved value.

## Reset Cfg Names

You can reset specific configuration names back to the default value of the configuration number.


## Auto Save

- **Enable** (default). When a change has been made to a Config. menu, this option automatically prompts the user to save or not save the change to a Config #.

If you are currently in the Factory Config. menus and make a change, pressing Enter saves to Config 1 or the next available Config. and becomes the Power-Up Config. If the Current Config is Config 1 and a menu change is made, pressing Enter will save the change to Config 1.

- **Disable**. The printer will not prompt you to save any changes made.

# HOST INTERFACE




The Host Interface Menu enables you to select and configure one of many types of interfaces between the printer and your host computer. The currently selected interface is indicated with an asterisk on the control panel message display. Each interface has its own submenu with a set of interface parameters which can be configured.

**IMPORTANT** When switching between Twinax, Coax, or Auto Switching, the printer will load the power-up configuration and the new interface parameters. Any settings made and not saved before selecting these interfaces will be lost.



## Auto Switching Submenu



Auto Switching gives the printer the ability to handle multiple data streams sequentially. With Auto Switching, the printer can service hosts attached to the serial, parallel, Ethernet, coax and twinax ports as if they were the only interface connected.

For example, if the host computer sends one print job to the RS-232 serial port and a separate print job to the IEEE 1284 parallel port, the printer's Auto Switching is able to handle both jobs, in the order they were received. The user does not have to reconfigure the selected interface between jobs.

## Port Type

Select the types of parallel, serial and/or C/T interfaces which are connected to the printer. For example, if your printer is attached to one host with a Centronics connection and a second host with an RS-422 serial connection, you would select Centronics under the Parallel Hotport menu, RS-422 under the Serial Hotport menu, and Disable under the C/T Hotport menu.

## Trickle Time

When the printer is printing data from a host and a second job is received by the printer from a different host, Trickle Time prevents the second host from timing out while it is waiting for its data to be printed. In order to support this feature, the port has to be able to accept data from the host and store it for future use.

For example, if the printer is printing a job from the serial port, and then receives a second print job from the parallel port, the data from the parallel port will “trickle” bit by bit into the printer buffer to prevent a timeout error from being sent back to the host connected to the parallel port.

The selected value is the time that the printer waits before getting the next byte of data from the host. The Trickle Time value should be less than the host time out value, but not too much shorter or else the printer fills up its buffer too fast. This function is not applicable for C/T hotport.

## Timeout

This is the value used by the printer to time out from the current port and check the other selected port types for data to print. When the printer has not received data from the host after a certain period of time, it needs to timeout in order to service the other ports.


## Report Status

- **Disable** (default). When a fault occurs on the printer, only the active port reports the fault to the host.
- **Enable**. The port will report any fault even when it is not the current active port.

## Switch Out On

- **Data Timeout** (default). Allows Autoswitching when no data has been received for the selected Time Out period.
- **Session Close**. Allows Autoswitching only when the Network Socket is closed. If the Ethernet option is not installed the Network Socket is always reported as closed and this menu option is ignored.

## IEEE 1284 Parallel (Bidirectional) Submenu



The IEEE 1284 interface is faster and more versatile than Centronics and supports bidirectional communication. Configuration of this interface is controlled from the host. Refer to “IEEE 1284 Parallel Interface” on page 238 more details about the available modes (Compatibility, Nibble, and Byte).

### Prime Signal

- **Enable** (default). The parallel port will perform a warm start (reboot) if the host asserts the prime signal.
- **Disable**. The parallel port will not perform a warm start (reboot) if the host asserts the prime signal.

### TOF Action

- **Reset** (default). A form feed is performed before a warm start when the prime signal is asserted from the host. This setting is used only if the prime signal parameter is enabled.
- **Do Nothing**. Nothing occurs before a warm start when the prime signal is asserted from the host.

### Buffer Size in K

This option configures the amount of memory allocated for the IEEE 1284 parallel port buffer. You can specify between 1 and 16 Kbytes, in 1-Kbyte increments.

### Auto Trickle

Auto Trickle is used to prevent a host computer from timing out because the parallel interface was busy for too long. When Auto Trickle is enabled and the printer's buffers are almost full, the printer will begin to trickle data in (at the rate set in the Trickle Time menu) until the buffers start to empty.

### Trickle Time

When the printer is printing data from a host and a second job is received by the printer from a different host, Trickle Time prevents the second host from timing out while it is waiting for its data to be printed. In order to support this feature, the port has to be able to accept data from the host and store it for future use.

For example, if the printer is printing a job from the serial port, and then receives a second print job from the parallel port, the data from the parallel port will “trickle” bit by bit into the printer buffer to prevent a timeout error from being sent back to the host connected to the parallel port.


The selected value is the time that the printer waits before getting the next byte of data from the host. The Trickle Time value should be less than the host time out value, but not too much shorter or else the printer fills up its buffer too fast. This function is not applicable for C/T hotport.

### Offline Process

- Disable (the default). When set to disable, the printer does not process parallel/network data while offline.
- Enable. When set to enable, the printer continues to process (but not print) the current network/parallel job while the printer is offline until the printer's buffer is full.

### Centronics (Parallel) Submenu

\* = Factory Default



### Data Bit 8

- **Enable** (default). Allows access to the extended ASCII character set.
- **Disable**. The printer interprets bit 8 of each incoming data character as a zero, regardless of its actual setting.

### PI Ignored

The PI (Paper Instruction) signal is used to control vertical paper motion.

- **Enable** (default). Ignores the PI signal and treats the data as characters or control codes.
- **Disable**. Causes the printer to interpret the eight data lines as VFU commands when the PI signal is true.

### Data Polarity

The Data Polarity parameter must be set to match the data polarity of your host computer.

- **Standard** (default). Does not expect the host computer to invert the data.
- **Inverted**. Expects the data received on the data lines from the host computer to be inverted. Ones become zeros, and vice versa.

### Resp. Polarity

The Resp. Polarity parameter must be set to match the response polarity of your host computer.

- **Standard** (default). Does not invert the response signal.
- **Inverted**. Inverts the response signal sent to the host computer.

### Busy On Strobe

- **Enable** (default). Asserts a busy signal after each character is received.
- **Disable**. Asserts a busy signal only when the print buffers are full.

### Latch Data On

Specifies whether the data is read on the leading or trailing edge of the data strobe signal. The default is leading.

### Prime Signal

- **Enable** (default). The parallel port will perform a warm start (reboot) if the host asserts the prime signal.
- **Disable**. The parallel port will not perform a warm start (reboot) if the host asserts the prime signal.

### TOF Action

- **Reset** (default). A form feed is performed before a warm start when the prime signal is asserted from the host. This setting is used only if the prime signal parameter is enabled.
- **Do Nothing**. Nothing occurs before a warm start when the prime signal is asserted from the host.

### Buffer Size in K

Configures the amount of memory allocated for the Centronics parallel port buffer. You can specify between 1 and 16 Kbytes, in 1-Kbyte increments.

### Auto Trickle

Auto Trickle is used to prevent a host computer from timing out because the parallel interface was busy for too long. When Auto Trickle is enabled and the printer's buffers are almost full, the printer will begin to trickle data in (at the rate set in the Trickle Time menu) until the buffers start to empty out.

### Trickle Time


When the printer is printing data from a host and a second job is received by the printer from a different host, Trickle Time prevents the second host from timing out while it is waiting for its data to be printed. In order to support this feature, the port has to be able to accept data from the host and store it for future use.

For example, if the printer is printing a job from the serial port, and then receives a second print job from the parallel port, the data from the parallel port will “trickle” bit by bit into the printer buffer to prevent a timeout error from being sent back to the host connected to the parallel port.

The selected value is the time that the printer waits before getting the next byte of data from the host. The Trickle Time value should be less than the host time out value, but not too much shorter or else the printer fills up its buffer too fast. This function is not applicable for C/T hotport.

## Dataproducts Submenu

\* = Factory Default



### Data Bit 8

- **Enable** (default). Allows access to the extended ASCII character set.
- **Disable**. The printer interprets bit 8 of each incoming data character as a zero, regardless of its actual setting.

### PI Ignored

The PI (Paper Instruction) signal is used to control vertical paper motion.

- **Enable** (default). Causes the printer to interpret the eight data lines as DVFU commands when the PI signal is true.
- **Disable**. Ignores the PI signal and treats the data as characters or control codes.

### Data Polarity

The Data Polarity parameter must be set to match the data polarity of your host computer.

- **Standard** (default). Does not expect the host computer to invert the data.
- **Inverted**. Expects the data received on the data lines from the host computer to be inverted. Ones become zeros, and zeros become ones.

### Resp. Polarity

The Response Polarity parameter must be set to match the response polarity of your host computer.

- **Standard** (default). Does not invert the response signal.
- **Inverted**. Inverts the response signal sent to the host computer.

### Latch Data On

Specifies whether the data is read on the leading, middle, or trailing edge of the data strobe signal. The default is Middle.

### Prime Signal

- **Disable** (default). The parallel port will not perform a warm start (reboot) if the host asserts the prime signal.
- **Enable**. The parallel port will perform a warm start (reboot) if the host asserts the prime signal.

### TOF Action

- **Reset** (default). A form feed is performed before a warm start when the prime signal is asserted from the host. This setting is used only if the prime signal parameter is enabled.
- **Do Nothing**. Nothing occurs before a warm start when the prime signal is asserted from the host.

### Buffer Size in K

Configures the amount of memory allocated for the Dataproducts parallel port buffer. You can specify between 1 and 16 Kbytes, in 1-Kbyte increments.

### Auto Trickle

Auto Trickle is used to prevent a host computer from timing out because the parallel interface was busy for too long. When Auto Trickle is enabled and the printer's buffers are almost full, the printer will begin to trickle data in (at the rate set in the Trickle Time menu) until the buffers start to empty out.



### Trickle Time


When the printer is printing data from a host and a second job is received by the printer from a different host, Trickle Time prevents the second host from timing out while it is waiting for its data to be printed. In order to support this feature, the port has to be able to accept data from the host and store it for future use.

For example, if the printer is printing a job from the serial port, and then receives a second print job from the parallel port, the data from the parallel port will “trickle” bit by bit into the printer buffer to prevent a timeout error from being sent back to the host connected to the parallel port.

The selected value is the time that the printer waits before getting the next byte of data from the host. The Trickle Time value should be less than the host time out value, but not too much shorter or else the printer fills up its buffer too fast. This function is not applicable for C/T hotport.

### Serial Submenu

\* = Factory Default



## Interface Type

This parameter allows you to select either the RS-232 or RS-422 serial port interface. The default is RS-232.

## Data Protocol

You can select one of the following serial interface protocols to meet the host interface requirements.

- **XON / XOFF** (default). The printer controls the flow of communication from the host by turning the transmission on and off. In some situations, such as when the buffer is full or the timing of signals is too slow or too fast, the printer will tell the host to stop transmission by sending an XOFF character. An XOFF character is sent when the number of empty bytes in the buffer is less than or equal to 25 percent of the buffer size. If the host keeps sending data after an XOFF is sent, the printer firmware will continue to send an XOFF for every 16 characters received. When cleared, the printer will resume receiving data (XON). The data does not have any End of Text codes; XON / XOFF is a non-block protocol.
- **ETX / ACK**. End of Text / Acknowledge. The host controls the flow of communication to the printer by sending a block of data and ending the block with an End of Text (ETX) signal. When the printer receives the ETX signal, it will acknowledge the ETX, thereby acknowledging it has received the entire block of data.
- **ACK / NAK**. ACK means acknowledge; the device acknowledges it has accepted a transmission. NAK means negative acknowledge; the device did not receive the transmission.
- **SERIES1 1 CHAR**. The printer controls the flow of communication from the host by turning the transmission on and off using response characters sent to the host. If the number of valid bytes in the buffer reaches 75 percent of the buffer size, the online or offline and buffer full response character is sent. If the buffer is completely full, an online or offline buffer full response is sent every time a character is sent from the host. Whenever the printer state changes to online or offline, the appropriate response character is sent. If the idle response option is enabled, the printer will send a response character every two seconds while the number of valid bytes in the buffer is less than 75 percent of the buffer size. If a poll character is received (configurable from the Poll Character xx Hex option on the front panel from hex 0 through FF), the printer will send a response character *n* milliseconds later (configurable from the Poll Character xx MS on the front panel from 0 through 30). This *n* milliseconds is called the poll delay. The poll character will be removed from the input data stream and will not be processed. This may cause problems with the transmission of binary data (e.g., control codes, bit image, etc.). If a poll delay is started due to the receipt of a poll character and another poll character is received, the second poll character has no effect and is removed from the input data stream. If a transition (from buffer full to empty or online to offline) occurs during a poll delay, the new printer state will be sent at the end of the poll delay.

The response characters are described in Table 3.

**Table 3. Series1 1 Char Response Characters**

Printer State	Response
Online and Buffer Empty	CR
Online and Buffer Full	3
Offline and Buffer Empty	0
Offline and Buffer Full	2

- **SERIES1 2 CHAR.** This protocol behaves exactly the same as the Series1 Char except there is a two-character response to the host. The response characters are described in Table 4.

**Table 4. Series1 2 Char Response Characters**

Printer State	Response
Online and Buffer Empty	1 CR
Online and Buffer Full	3 CR
Offline and Buffer Empty	0 CR
Offline and Buffer Full	2 CR

- **DTR.** The printer controls the data flow by sending this hardware signal to the host. If there is enough room in the printer buffer, the printer will send a high signal; if the buffer is full, the printer will send a low signal. DTR tells the host if it is safe to send more data. (If the host sends data during an unsafe condition, data will be lost.) DTR is not available when RS-422 is selected.

## Baud Rate

Sets the baud rate of the serial interface in the printer. Baud rate is the speed at which serial data is transferred between the host computer and the printer. The choices for the RS-232 and RS-422 interfaces are 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, and 115200 Baud. The default is 9600 Baud.

**NOTE:** If you select a baud rate that is greater than 19200, you may need to use RS-422 or select a lower baud rate to prevent data loss. You also may need to increase the Buffer Size in K parameter to improve performance.

## Word Length

Sets the length of the serial data word. The length of the data word can be set to 7 or 8 bits, and must match the corresponding data bits setting in the host computer.

## Stop Bits 1

Sets the number of stop bits in the serial data word. Either one or two stop bits can be selected. The setting must match the corresponding stop bit setting in the host computer.

## Parity

Set for odd parity, even parity, mark, sense, or no parity. The setting must match the corresponding parity setting in the host computer.

## Data Term Ready

This configuration is part of hardware flow control and determines when the Data Terminal Ready (DTR) signal is generated. This signal indicates if the printer is ready to receive data.

- **True** (default). Continuously asserts the DTR signal.
- **On Line and BNF (buffer not full)**. Asserts the DTR signal when the printer is online and the internal serial buffer is not full.
- **Off Line or BF (buffer full)**. Asserts the DTR signal when the printer is offline or the internal serial buffer is full.
- **On Line**. Asserts the DTR signal when the printer is online.
- **False**. Never asserts the DTR signal.

## Request To Send

This configuration is part of hardware flow control and determines when the Request to Send (RTS) signal is generated. This signal indicates whether or not the printer is ready to receive data.

- **On Line and BNF** (default). Asserts the RTS signal when the printer is online and the internal serial buffer is not full.
- **Off Line or BF**. Asserts the RTS signal when the printer is offline or the internal serial buffer is full.
- **On Line**. Asserts the RTS signal when the printer is online.
- **False**. Never asserts the RTS signal.
- **True**. Continuously asserts the RTS signal.

## Buffer Size in K

This option configures the amount of memory allocated for the serial port buffer. You may specify between 1 and 16 Kbytes, in 1-Kbyte increments.

**NOTE:** If you select a baud rate that is 19200 or greater, you may need to increase the Buffer Size in K parameter to improve performance.

## Poll Character

This option is for the Series1 protocol. Whenever the printer receives this character, it sends a response to the host indicating the current state of the printer (see Series1 protocol). It may be configured from 0 through FF hexadecimal.

## Poll Response

This option is for the Series1 protocol. After receiving a poll character, the printer will wait the poll response time in milliseconds before sending the response. It may be configured from 0 through 30.

## Idle Response

This option is for the Series1 protocol.

- **Disable** (default)
- **Enable**. The printer will send a response character every two seconds while the number of valid bytes in the buffer is less than 75 percent of the buffer size.

## One Char Enquiry

The One Char Enquiry mode uses the Poll Character to detect a request from the host and sends a response back to the host. This option also allows you to turn on and off this feature.

**Table 5. One Char Enquiry Response Characters**

Printer State	Response (hex)
Online and Buffer Not Full	22
Online and Buffer Full	23
Offline and Buffer Not Full	20
Offline and Buffer Full	21

The Poll Character is removed from the data stream. If the Data Protocol is set to ETX/ACK, ACK/NAK, or Series 1, One Char Enquiry is automatically disabled.

## Framing Errors

Possible errors that can occur when the printer's serial interface settings do not match those of the host computer.

- **Enable** (default). If a framing error occurs, a fault message will display on the control panel.
- **Disable**. If a framing error occurs, a fault message will not display on the control panel.

## E-Net Adapter Submenu

---

**E-Net Adapter**  
(from page 72)

Buffer Size  
in K

16\*  
1-16

\* = Factory Default

The E-Net Adapter interface allows you to locate the printer on a LAN rather than attach the host directly into the printer. The detailed configuration of this option is given in the *PrintNet User's Manual*.

### Buffer Size in K

This option configures the amount of memory allocated for the Ethernet buffer. You can specify between 1-16 Kbytes. The default is 16 Kbytes.

## Ethernet Submenu

---

**Ethernet**  
(from page 72)

Buffer Size  
in K

16\*  
1-16


\* = Factory Default

The Ethernet interface allows you to locate the printer on a LAN rather than attach the host directly into the printer. The detailed configuration of this option is given in the *Network Interface Card User's Manual*.

### Buffer Size in K


This option configures the amount of memory allocated for the Ethernet buffer. You can specify between 1 and 16 Kbytes, in 1-Kbyte increments. The default is 16 Kbytes.

# NETWORK SETUP MENU



- <sup>1</sup> Only if the Ethernet Adapter feature is installed.
- <sup>2</sup> Only if the Integrated Ethernet feature is installed.
- <sup>3</sup> Only if the Wireless Adapter feature is installed.
- <sup>4</sup> Only if a Symbol radio card is installed.
- <sup>5</sup> Only if a Cisco radio card is installed.

# ADAPTER ADDRESS



## IP Address

A numeric address such as 123.45.61.23 which identifies a printer or server in a LAN or WAN.

## Subnet Mask

A binary value used to divide IP networks into smaller subnetworks or subnets. This mask is used to help determine whether IP packets need to be forwarded to other subnets.

### Gateway Address

A gateway address is the IP address of a hardware device (gateway) that translates data between two incompatible networks, which can include protocol translation.

### MAC Address

This menu item is the Manufacturer's Assigned Number, and is unique for each printer. It is read-only.


### DHCP

You can enable/disable the DHCP protocol using this option, but consult your administrator for the appropriate setting.

The options include:

- **Disable** (default)
- **Enable.**

## ADAPTER PARAMS



You may enable or disable the Novell or NetBIOS Protocols within this menu, as well as selecting which Novell Frame scheme to use in processing Novell signals. See the Novell chapter in the *Network Interface Card User's Manual* for more details.



## Novell Protocol

This option determines whether the Novell protocol will be available. The selections are as indicated below:

- **Enable** (default). Makes the Novell protocol available with the ethernet installed.
- **Disable**. Makes the Novell protocol unavailable during printer operation.

## Nest Serv Type

You can change the Nest Server using this option, but consult your administrator for the appropriate setting.

The options are Auto (default), Bindery, and NDS.

## NetBIOS Protocol

This option determines whether the NetBIOS protocol will be available. The selections are as indicated below:

- **Enable** (default). Makes the NetBIOS protocol available with the ethernet installed.
- **Disable**. Makes the NetBIOS protocol unavailable during printer operation.

## Novell Frame

This selection determines which framing scheme will be used in processing Novell signals.

- **Ethernet 802.2** (default)
- **802.2 Snap**
- **Auto Sensing**
- **Ethernet II**
- **Ethernet 802.3**

## ASCII Data Port

This option sets the port number for ASCII print jobs. The data port number needs to match your host system setting.

- **9100** (default)
- **1023 - 65535**

## IPDS Data Port

This option allows you to set the port number for IPDS print jobs only if the IPDS option is installed.

The range is 0 - 5000, and the default is 5001.

## Keep Alive Timer

This is the time that the Keep Alive Timer will run. With the Keep Alive Timer on, the tcp connection will stay connected even after the print job has terminated.

- **3 Minutes** (default)
- **2 - 10 Minutes**

## Ethernet Speed

This menu option only appears if a 10/100Base-T network interface card (NIC) is installed. The Ethernet Speed menu allows compatibility with different systems and networks. The factory default is Auto Select.


- **Auto Select.** (default) This setting tells the 10/100Base-T NIC to perform an auto detection scheme and configure itself to be 10 Half Duplex, 10 Full Duplex, 100 Half Duplex, or 100 Full Duplex.
- **10 Half Duplex.** Tells the 10/100Base-T NIC to communicate at 10 Megabits per second using half duplex.
- **10 Full Duplex.** Tells the 10/100Base-T NIC to communicate at 10 Megabits per second using full duplex.
- **100 Half Duplex.** Tells the 10/100Base-T NIC to communicate at 100 Megabits per second using half duplex.
- **100 Full Duplex.** Tells the 10/100Base-T NIC to communicate at 100 Megabits per second using full duplex.

## Job Control

The job control mode has three options:

- **Standard** (default). The NIC waits for the printer to finish receiving the current job before sending another job. The status line shows “done” when the job is completely received by the NIC. This is the default.
- **Enhanced.** The NIC waits for the printer to finish receiving the current job before sending another job. The status line shows “done” when the job is fully printed.
- **Off.** No job synchronization between the NIC and the printer.

## ETHERNET ADDRESS



### IP Address

A numeric address such as 123.45.61.23 which identifies a printer or server in a LAN or WAN.

### Subnet Mask

A binary value used to divide IP networks into smaller subnetworks or subnets. This mask is used to help determine whether IP packets need to be forwarded to other subnets.

### Gateway Address

A gateway address is the IP address of a hardware device (gateway) that translates data between two incompatible networks, which can include protocol translation.

### MAC Address

This menu item is the Manufacturer's Assigned Number, and is unique for each printer. It is read-only.


### DHCP

You can enable/disable the DHCP protocol using this option, but consult your administrator for the appropriate setting.

The options include:

- **Disable** (default)
- **Enable**.

## ETHERNET PARAMS



The ETHERNET PARAMS menu helps your printer communicate on a network.

For information on assigning the IP Address, Gateway Address, Subnet Mask, and MAC Address, refer to the *Network Interface Card User's Manual*.

### NetBIOS Protocol

This option determines whether the NetBIOS protocol will be available. The selections are as indicated below:

- **Enable** (default). Makes the NetBIOS protocol available with the ethernet installed.
- **Disable**. Makes the NetBIOS protocol unavailable during printer operation.

### ASCII Data Port

This option sets the port number for ASCII print jobs. The data port number needs to match your host system setting.

- **9100** (default)
- **1023 - 65535**

### IPDS Data Port

This option allows you to set the port number for IPDS print jobs only if the IPDS option is installed.

The range is 1023 - 65535, and the default is 5001.

### Keep Alive Timer

This is the time that the Keep Alive Timer will run. With the Keep Alive Timer on, the tcp connection will stay connected even after the print job has terminated.

- **3 Minutes** (default)
- **2 - 10 Minutes**

## Ethernet Speed

This menu option only appears if a 10/100Base-T network interface card (NIC) is installed. The Ethernet Speed menu allows compatibility with different systems and networks. The factory default is Auto Select.


- **Auto Select.** (default) This setting tells the 10/100Base-T NIC to perform an auto detection scheme and configure itself to be 10 Half Duplex, 10 Full Duplex, 100 Half Duplex, or 100 Full Duplex.
- **10 Half Duplex.** Tells the 10/100Base-T NIC to communicate at 10 Megabits per second using half duplex.
- **10 Full Duplex.** Tells the 10/100Base-T NIC to communicate at 10 Megabits per second using full duplex.
- **100 Half Duplex.** Tells the 10/100Base-T NIC to communicate at 100 Megabits per second using half duplex.
- **100 Full Duplex.** Tells the 10/100Base-T NIC to communicate at 100 Megabits per second using full duplex.

## Job Control

The job control mode has three options:

- **Standard** (default). The NIC waits for the printer to finish receiving the current job before sending another job. The status line shows “done” when the job is completely received by the NIC. This is the default.
- **Enhanced.** The NIC waits for the printer to finish receiving the current job before sending another job. The status line shows “done” when the job is fully printed.
- **Off.** No job synchronization between the NIC and the printer.

## WLAN ADDRESS



### IP Address

A numeric address such as 123.45.61.23 which identifies a printer or server in a LAN or WAN.

### Subnet Mask

A binary value used to divide IP networks into smaller subnetworks or subnets. This mask is used to help determine whether IP packets need to be forwarded to other subnets.

### Gateway Address

A gateway address is the IP address of a hardware device (gateway) that translates data between two incompatible networks, which can include protocol translation.

### MAC Address

This menu item is the Manufacturer's Assigned Number, and is unique for each printer. It is read-only.


### DHCP

You can enable/disable the DHCP protocol using this option, but consult your administrator for the appropriate setting.

The options include:

- **Disable** (default)
- **Enable**.

# WLAN PARAMS



## Signal Strength

This menu displays the strength of the wireless signal.

**NOTE:** This is a display value only and cannot be changed.

## Operation Mode

Allows you to select the way the Wireless option communicates:

- **Infrastructure** (default). The Wireless option must go through a server.
- **Pseudo IBSS**. Proprietary, peer-to-peer communication (without a server). The two peers must be specific to one manufacturer.
- **Ad Hoc**. Standard, peer-to-peer communication (without a server). The two peers can be from different manufacturers.

## SSID Name

A 1 - 32 character, case sensitive string that identifies the group the printer talks to.

**NOTE:** The SSID name may be edited in three parts (1-15), (16-30), and (31-32).

For each part of the SSID name, press the MICRO UP or MICRO DOWN keys to cycle through the values available for that character at the cursor location. Press the SCROLL UP key to move to the next character to be modified. Press the SCROLL DOWN key to go back to the name you want to give to this SSID name, then press ENTER to save. The name you entered will now represent this SSID name on the printer's front panel. To exit this menu without saving, press any key other than the ENTER key. The SSID name will revert to the last saved value.

## Reset SSID Name

Allows you to reset the SSID name.

## Min Xfer Rate

Allows you to set the minimum speed at which the Wireless Option will accept a connection (in million bits per second). The options are:

- **Auto-negotiate** (default)
- **1Mb/Sec.**
- **2Mb/Sec.**
- **5.5Mb/Sec**
- **11Mb/Sec**

## Channel

Allows you to select the RF channel. The options are Default (the factory default) and 1-15.



## Ant. Diversity

The type of antenna used:

- **Diverse** (default). Select when you want to use the antenna with the best reception.
- **Primary**. Select when you want to use the Primary antenna on the server.
- **Auxiliary**. Select when you want to use the Auxiliary antenna on the server.

## Preamble

The length of the preamble in transmit packets.

- **Default** (default). The Wireless option automatically determines the length.
- **Short**. For newer printers which can handle higher transfer rate speeds.
- **Long**. For older printers which cannot handle higher transfer rate speeds.

## Antenna

- **Primary** (default). Select when you want to use the Primary antenna on the RF card.
- **Auxiliary**. Select when you want to use the Auxiliary antenna on the RF card.

## Power Mgmt

This allows you to set power-save mode and sleep time. A value specifying the sleep time in milliseconds will be provided. If set to zero, power-save mode will be disabled. The range includes:

- **0 ms.** (default)
- **100 ms. - 1000 ms.**

## Transmit Power

The power level as a percentage of full power (0 - 100%).

## Internat. Mode

When enabled, the Wireless option adapts to international frequency requirements in Europe. The options include:

- **Disable** (default)
- **Enable**

## Auth Method

This feature allows the user to select the authentication method used for the wireless network interface.

- **Open** (default). Selects open authentication.
- **Shared**. Selects shared key authentication.
- **Kerberos**. Selects Kerberos authentication (for use when a Symbol RF card is installed).
- **LEAP**. Selects LEAP authentication (for use with a Cisco RF card installed).

## WEP Key 1 Through WEP Key 4

- **WEP Key Format**. Allows you to format the WEP keys in ASCII or hexadecimal code. The default is hexadecimal.
- **WEP Key Width**. This is the encryption strength. The options are 40 Bits and 128 Bits; 40 Bits are weaker and 128 Bits are stronger.

**NOTE:** If you select 40 Bits, the WEP key BYTE6 through WEP Key BYTE13 menus will not display.

The default is 128 Bits.

- **WEP Key BYTE1 through BYTE13**. These are the individual characters of the encryption key.

## Default WEP Key

This feature enables you to encrypt (scramble) information for security purposes. With this feature, you can set up to four encryption keys, in either ASCII or hexadecimal format, and in either 40 or 128 bits. (The more bits you choose, the more difficult it will be to decode the information.)

**NOTE:** None of the WEP Key Configuration menus display on the configuration printout.

## Reset WEP Keys

Allows you to reset all four WEP keys (WEP Key 1 through WEP Key 4) at one time.

## WPA Mode

Selects the WPA wireless security mode.

- **Disable** (default). WPA security is disabled.
- **Personal**. Selects personal or pre-shared key mode for WPA security.

### WPA Cipher

Selects the WPA wireless security cipher setting. Options include:

- **TKIP** (default)
- **AES**
- **TKIP+AES**


### WPA P-Phs

Allows you to set the individual bytes of the WPA passphrase.

### Reset WPA P-Phs

Allows you to reset all 32 bytes of the WPA passphrase at once.

## WLAN KERBEROS



### Kerberos Enable

- **Disable** (default). Disables Kerberos authentication in the wireless network interface.
- **Enable**. Enables Kerberos authentication in the wireless network interface.

### **Kerb. Passwd**

- **Kerb. Pwd (01-15)**. The first 15 characters of the Kerberos password (maximum number of characters is 40).
- **Kerb. Pwd (16-30)**. Characters 16 to 30 of the Kerberos password (maximum number of characters is 40).
- **Kerb. Pwd (31-40)**. Characters 31 to 40 of the Kerberos password (maximum number of characters is 40).

### **Reset Kerb. Pwd**

Resets the Kerberos password to an empty string.

### **KDC Port Number**

KDC (Key Distribution Center) port number is the 2-byte UDP/TCP port used for Kerberos Communication.

The range is 0-65535, and the default is 88.

### **Clock Skew**

Sets the maximum allowable amount of time in seconds or minutes that Kerberos authentication will tolerate before assuming that a Kerberos message is valid. The range for Seconds is 60-900, and the default is 300. The range for Minutes is 1-15, and the default is 5.

### **Ticket Lifetime**

Sets the maximum allowable amount of time in Seconds, Minutes, Hours, or Days that a ticket obtained from the Kerberos server is valid before getting a new one.


- **Seconds**. The range is 300-259200, and the default is 43200.
- **Minutes**. The range is 5-4320, and the default is 720.
- **Hours**. The range is 1-72, and the default is 12.
- **Days**. The range is 1-3, and the default is 1.
- **Tckt Lifetime (SEC)**. The ticket lifetime unit in seconds. The default is 43200.

### **Renew Lifetime**

Sets the maximum allowable amount of time in Seconds, Minutes, Hours, or Days before warning that a new Kerberos password is needed.

- **Seconds**. The range is 0-604800, and the default is 0.
- **Minutes**. The range is 0-10080, and the default is 0.
- **Hours**. The range is 1-168, and the default is 0.
- **Days**. The range is 0-7, and the default is 0.
- **Renew Life (SEC)**. Renew lifetime unit in seconds. The default is 0.

## WLAN LEAP



### Auth Method

This feature allows the user to select the authentication method used for the wireless network interface.

- **Open** (default). Selects open authentication.
- **Shared**. Selects shared key authentication.
- **Kerberos**. Selects Kerberos authentication (for use when a Symbol RF card is installed).
- **LEAP**. Selects LEAP authentication (for use with a Cisco RF card installed).

### LEAP Username

- **LEAP Username (01-15)**. The first 15 characters of the LEAP user name (maximum number of characters is 32).
- **LEAP Username (16-30)**. Characters 16 to 30 of the LEAP user name (maximum number of characters is 32).
- **LEAP User (31-32)**. Characters 31 to 32 of the LEAP user name (maximum number of characters is 32).

### Reset LEAP User

Resets the LEAP user name to an empty string.

### LEAP Password

- **LEAP Password (01-15)**. The first 15 characters of the LEAP password (maximum number of characters is 32).
- **LEAP Password (16-30)**. Characters 16 to 30 of the LEAP password (maximum number of characters is 32).
- **LEAP Password (31-32)**. Characters 31 to 32 of the LEAP password (maximum number of characters is 32).

### Reset LEAP Password

Resets the LEAP password to an empty string.

## ACTIVE IGP EMUL

---

\* = Factory Default

**ACTIVE IGP  
EMUL**  
(from page 60)

IGP/PGL\*  
IGP/VGL  
(not shown if any  
below are installed)

ANSI (if installed)  
PCL-II (if installed)  
LG (if installed)  
LP+ (with any above)

This ACTIVE IGP EMUL function allows you to activate the desired emulation. There are two methods for selecting the desired emulation. The first is by selecting the emulation directly from the printer menu. The second is by sending a host command which will switch the emulation automatically (see the appropriate Programmer's Reference Manual for details).

When changing from one emulation to the other, the printer will load the power-up configuration and the new emulation parameters. Any configuration settings performed before selecting these emulations that are not saved in NVRAM will be lost.

**IMPORTANT** To configure an IGP emulation, the IGP emulation must be selected in the ACTIVE IGP EMUL menu. The IGP emulation that is not selected will not appear in the EMULATION menu (see "Main Menu" on page 59).

# ACTIVE EMULATION

The ACTIVE EMULATION menu allows you to activate the desired emulation to be used with your printer.

- <sup>1</sup> If installed
- <sup>2</sup> If ANSi is installed
- <sup>3</sup> If LG is installed
- <sup>4</sup> If PCL-II is installed


**ACTIVE EMULATION** <sup>2, 3, 4</sup>  
(from page 60)

44/48XX-ANSI <sup>1</sup>  
PCL-II <sup>1</sup>  
LG <sup>1</sup>  
IGP/PGL + LP+  
IGP/VGL + LP+


# EMULATION

The EMULATION menu allows you to select the emulation to be used with your printer. The Proprinter XL, Epson FX, P-Series, P-Series XQ, and Serial Matrix emulations are all part of LinePrinter +. You can configure options for the active emulation via the EMULATION menu. Emulation options are further described in their corresponding Programmer's Reference Manual.

- \* = Factory Default
- <sup>1</sup> Optional Emulation



# Coax/Twinax (CTHI) Emulation



## Standard

With a standard coax interface, the printer emulates the following IBM coax printer models:

- 3287 Models 1 and 2
- 4234 Model 1

With a standard twinax interface, the printer emulates the following IBM twinax printer models:

- 4234 Models 2 and 12
- 5225 Models 1, 2, 3, and 4

**NOTE:** The standard Coax/Twinax emulation selection will only be available if Coax or Twinax is selected from the HOST INTERFACE menu. See page 72.

For more information, refer to the *Coax/Twinax Programmer's Reference Manual*.

The 3270 Params and 5250 Params selection is available only if the TN option is installed.



## Simple Prot Conv

---

The Simple Protocol Converter (SPC) option allows those who use third party add-on Coax or Twinax protocol converters to produce the same output on a Line Matrix printer with the Coax/Twinax (CTHI) capability as done using a non-CT printer with the third party converter interfaces.

The SPC replaces the third party add-on protocol converters attached to older line matrix printers.

The SPC gives the printer the operational ability to connect to any PC, or network system supporting parallel or serial interfaces, and to three different IBM host systems: System 3x, AS/400<sup>®</sup>, and 3270 Mainframes.


The SPC will support the following third party models for Twinax: MODE 219, MODE IBM, and MODE PROLINE.

The printer emulations supported by the SPC are Twinax 5225 and Coax 3287. The SPC also provides a range of interfaces available in your line matrix printer: Centronics, Dataproducts, Serial, Coax, and Twinax. Also supported are Epson, Proprinter, P-Series, Serial Matrix, IGP/VGL, and IGP/PGL emulations.

The SPC has the ability to handle multiple print jobs concurrently through Coax/Twinax and Parallel and Serial interfaces. This is accomplished through the Auto Switching feature (see page 73). Because of hardware restrictions, Coax and Twinax cannot be selected together.

For more information, consult the *Coax/Twinax Programmer's Reference Manual* for the Simple Protocol Converter Option.

## Coax Emulation



**Char Set Select**  
(from page 106)


\* = Factory Default

Primary  
Sets

Secondary  
Sets

0037 English US*	English US*
0037 Eng Nether	English UK
0285 English UK	Austrian/German
0273 Austr/Germ	German (Alt)
0274 Belg. Old	Belgian
0275 Brazilian	Brazilian
0260 Canad Fren	Canadian French
0277 Danish	Danish/Norweg.
0287 Danish Alt	Danish (Alt)
0278 Finnish	Finnish/Swedish
0288 Finn. Alt	Finnish (Alt)
0297 French	French
0500 Internat 5	International
0280 Italian	Italian
0281 Japan. Eng	Japanese Eng.
0282 Portuguese	Japanese Katak.
0284 Span Speak	Portuguese
0289 Span. Alt	Portug. (Alt)
0500 Swiss Bil	Spanish
0500 Belg. New	Spanish (Alt)
0803 Hebrew Old	Spanish Speak.
0424 Hebrew	Swiss Fren/Ger
0892 OCR A	Old Hebrew
0893 OCR B	Hebrew
0420 Arabic	Farsi/Latin
0880 Cyril. Old	Greek Old
0423 Greek Old	Greek New
0875 Gr New Euro	Arabic
0871 Icelandic	Turkish
0290 Japan Kata	Turkish Old
0870 Latin 2	Latin 2/ROECE
0838 Thai	Yugoslavian
1026 Turkish	
0890 Yugos. Old	
1097 Farsi	
1025 Cyrillic	
0905 Turk. Old	
0256 Intern. 1	
0924 Euro Lat-9	
1140 Euro Eng.	
1141 Euro Aust.	
1142 Euro Dan.	
1143 Euro Finn.	
1144 Euro Ital.	
1145 Euro Span.	
1146 Euro UK	
1147 Euro Fren.	
1148 Euro Swiss	
1149 Euro Ice.	

\* = Factory Default



## Char Set Select

Specifies the print language used by the printer. Character sets are shown in detail in the *Character Sets Reference Manual*.

## Translation Tbl

Prints out SCS and DSC/DSE tables of the Coax interface's current character set. This operation is valid only when the Coax interface is selected as the current interface (see "HOST INTERFACE" on page 72).

## Active Char Set

Selects which group of character sets (Primary or Secondary) will be active. Secondary Set is the default.

## Prt Partial Line

- **Enable** (default). Forces the printer to print if a partial line is in the printer (i.e., line not ending with a LF).
- **Disable**. The last partial line of data will not be printed.

## PA1

PA1 is only valid when the printer is in the offline state and the coax Systems Network Architecture Character String (SCS) data stream is active. This function displays the "PA1 ENABLED" message when the ENTER key is pressed and sends a special operator request to the host when the printer is put back in Online mode. Refer to the *Coax/Twinax Programmer's Reference Manual* for more information about SCS.

**NOTE:** Selecting the PA1 menu item again ("PA1 DISABLED" appears on the operator panel) or selecting the PA2 menu item will reset the pending PA1 function.

## PA2

PA2 is only valid when the printer is in the Offline state and the coax SCS data stream is active. This function displays the “PA2 ENABLED” message when the ENTER key is pressed and sends a special operator request to the host when the printer is put back in online mode.

**NOTE:** Selecting the PA2 menu item again (“PA2 DISABLED” appears on the operator panel) or selecting the PA1 menu item will reset the pending PA2 function.

## Buffer Reprint

This option is valid only when the printer is printing in SCS mode. When the ENTER key is pressed, “Buffer Reprint Enabled” is displayed and an Intervention Required status is sent to the host. Pressing ENTER again cancels the Buffer Reprint function and displays “Buffer Reprint Disabled.”

## Early Print Cmpl

Allows the printer to send print (order) complete status to the host before the printer is actually done printing all data. This option is valid only when the printer is in DSC/DSE mode.

- **Disable** (default). The printer will suppress the Early Print Complete response until all printing is complete.
- **Enable**. The printer will send an acknowledgment to the host when it is able to accept more data.

**NOTE:** When Early Print Complete is enabled and an error occurs, you may lose data.

## SCS Buffer Cntrl

This option is used in Coax LU1/SCS mode only.

- **Don't Wait** (default). The printer does not wait for the job to be printed before sending the print completion to the host.
- **Wait Until Done**. The printer waits for the job to print before sending the print completion to the host.

This option speeds up the LU1 job printing for short jobs. If you select “Don't Wait,” there is a risk that you may not be able to recover the print job when the printer has fault.

## Cancel IGP/DCU

- **Enable** (default). Cancels all buffers when a job is put on hold from the host or when the CANCEL key is pressed.
- **Disable**. Does not cancel any internal buffer in the printer when a job is put on hold from the host or when the CANCEL key is pressed.

## PTX Transparent

### Lead-in Chars

You can enable additional printer features which are not accessible through standard Coax emulations. To access these features, send text commands in the data stream. The commands must have a start and end code. Four sets are available:

- **Set 1.** start code: <%  
stop code: >
- **Set 2.** start code: ␣␣  
stop code: \$
- **Set 3.** start code: \_%  
stop code: \_
- **User Defined.**

### Usr Defined HTRN

This option is used in Twinax SPC emulation. The range is ASCII character. This option allows users to define their own lead-in characters for the Printronix Specific commands. Select a hex value for the following codes for the User Defined option:

- **Start Code 1 5F**
- **Start Code 2 5F**
- **Stop Code 5B**

### Alt. Set 80-9F

- **Printable.** Prints data in the range of hex 80 through hex 9F.
- **Control Code.** Interprets data in the range of hex 80 through hex 9F as a control code.

## Change Case

Specifies the font as Mono or Dual case. This option is available only in non-SCS mode. The host will be notified of the change when the printer is placed online. Mono Case prints the same as Dual Case if the character set is one of the following “right to left” sets: Katak., Hebrew, Old Hebrew, and Farsi. The default is Dual Case.

SCS (System Network Architecture Character String) mode is controlled by the host computer.

## Set Text Orientn

Specifies the direction in which characters are printed on the page. This allows the printer to print languages which are printed right to left instead of left to right.

- **Control By Host** (default). Allows printers configured as a 4234 to use the “Set Text Orientation” command from the host.
- **Left to Right**.
- **Right to Left**. When a right to left language is selected, the host will be notified of print direction changes when the printer is placed online.

## Image Buf Size

Allows you to select 2K or 4K as the image buffer size. This option is valid only when the printer emulates the 3287. For the 4234 emulation, the buffer size is fixed at 4K. A POR status is sent to the host when the printer is placed online.

## Intervention Req

- **Send to Host** (default). The printer sends a signal to the host computer when a printer fault or hold mode time-out occurs.
- **Do Not Send**. No signal will be sent to the host computer.

## Compatibility Op

The Compatibility Options allow you to select special printer functions in the non-SCS mode based on the capabilities of the printer emulated.

### CR At MPP+1

MPP is Maximum Print Position, which is also known as line length. This option controls a carriage return at the end of a print line and at MPP+1.

- **On** (default). Produces a carriage return to the first print position of the next line.
- **Off**. Produces a carriage return to the first print position of the current line.

### NL At MPP+1

Controls how many lines are skipped when the carriage returns to a new line.

- **On** (default). Moves to the first print position two lines down from the current position.
- **Off**. Moves to the first print position of the next print line.

### Position Aft FF (4234 only)

Allows you to select the location of the print position after a form feed command is sent.

- **On** (default). Sets the printer to print at print position 1 of the first print line on the next form.
- **Off**. Sets the printer to print at print position 2 of the first print line on the next form.

### Last Char = FF

Determines the print line position when a form feed command is the last code encountered in the print buffer.

- **On** (default). Moves to the first print position on the second line of the next form.
- **Off**. Moves to the first print position on the first line of the next form.

**NOTE:** This option is ignored if Auto Skip At End is on.

If configured as a 3287, and a form feed occurs in the middle of a print buffer, the printer defaults to the first print position on the second line of the next form regardless of the setting of this option.

### Null Suppression

- **Off** (default). Ignores nulls. The print position does not move.
- **On**. Treats nulls as blank spaces.

### FF Validity

Determines if the position of a form feed command affects its execution.

- **Off** (default). Performs a form feed only if it occurs at the first print position in a line or at Maximum Print Position +1. A form feed command at any other position is recognized as a space.
- **On**. Allows the printer to perform a form feed command anywhere in the data stream.

### Auto Skip At End

Specifies whether or not to perform an automatic form feed at the end of a print buffer. If form feed is the last character in the print order, the form feed function is supplied by the Auto Skip At End option.

- **Off** (default). Sets the printer to print at print position 1 of the next line.
- **On**. Sets the printer to print at print position 1 of the first line of the next form.



## FF After Job

Determines the print position after an operator-initiated local copy (print screen function).

- **Off** (default). Performs an automatic new line command after completing a print buffer (unless a new line, form feed, or carriage return command was the last one executed). The printer is set to print at print position 1 of the next line.
- **On**. Performs an automatic form feed command unless a form feed was the last one executed. The printer is set to print at print position 1 of the first line on the next form.

## CR, EM, & NL (3287 only)

CR (Carriage Return), EM (Error Message), and NL (New Line) specify that the printer treat the CR, EM, and NL control codes either as spaces or as control codes.

- **On** (default). Treats the CR, EM, and NL commands as control codes.
- **Off**. Treats the CR, EM, and NL commands as spaces.

## Translate Table

Defines which translate table to use for printing.

- **Default** (default). Translates data by using the default table of the current character set.
- **Downloaded**. Translates data from EBCDIC to internal code by using the downloaded translate table.

## Host Override

Determines whether the printer accepts certain commands sent by the host or continues to use the current operator panel settings.

- **Disable** (default). Allows the following host commands to override operator panel settings: line length, forms length, lines per inch (LPI), characters per inch (CPI), print quality, and text orientation. Note the information appearing on the message display may not match the data stream setting. No values will change upon initial selection of the disable option.
- **Enable**. The operator panel settings override the host commands.

## Format Control

Enables the printer to reflect the same spacing as CTPC model printers after absolute and relative move commands are executed.

- **Disable** (default). Reflects distance, generated by the IGP/VGL feature, IGP/PGL feature, and Hex Transparent control code sequence, in the new position (after horizontal and vertical tabs are executed).
- **Enable**. Does not reflect distance, generated by the IGP/VGL feature, IGP/PGL feature, and Hex Transparent control code sequence, in the new position (after horizontal and vertical tabs are executed).

### Max. Print Width

Set the maximum print width at either 13.2 inches or the maximum width of the printer. The default is 13.2 inches.


### Buffer Print

- **Disable** (default). The printer will print normally.
- **Enable**. The printer prints the EBCDIC data and control codes received from the host as hex values. Refer to page 253 for information on how to obtain a hex code printout.

**NOTE:** Use of this parameter may alter print attributes set by the host computer. A power cycle may be required after changing Buffer Print from enable to disable.

# Twinax Params

\* = Factory Default



\* = Factory Default



## Char Set Select

Specifies the print language used by the printer. Character sets are shown in detail in the *Character Sets Reference Manual*.

## Active Char Set

This option selects which group of character sets (Primary or Secondary) will be active. Secondary Set is the default.

## Prt Partial Line

- **Enable** (default). Forces the printer to print a partial line (i.e., line not ending with a LF) before moving to the top of form on the next page.
- **Disable**. The last partial line of data will not be printed.

## Device ID

This parameter defines the printer emulation as IPDS, 5225, or 4234-2. After the emulation has been changed, a POR status is sent to the host. IPDS is the default.

## Device Address

Allows you to set the device address from 0 through 6. The host directs data and commands on the twinax line to a specific device based on its unique device address. After the address has been changed, a POR status is sent to the host.

## 5225 World Trade

The 5225 emulation has a standard multinational character set that serves as a base and 14 extended world trade character set assortments.

## Cancel IGP/DCU

- **Enable** (default). Cancels all buffers when a job is put on hold from the host or the CANCEL key is pressed.
- **Disable**. Does not cancel any internal buffer in the printer when a job is put on hold from the host or the CANCEL key is pressed.

## PTX Transparent

### Lead-in Chars

You can enable additional features that are not available in standard Twinax emulations. To access these features, send text commands in the data stream. The commands must have a start and end code. Three sets (each containing a start and end code) are available:

- **Set 1.** start code: <%  
stop code: >
- **Set 2.** start code: ␣␣  
stop code: \$
- **Set 3.** start code: \_%  
stop code: \_
- **User Defined**

### Usr Defined HTRN

This option is used in Twinax SPC emulation. The range is ASCII character. This option allows users to define their own lead-in characters for the Printronix Specific commands. Select a hex value for the following codes for the User Defined option:

- **Start Code 1 5F**
- **Start Code 2 5F**
- **Stop Code 5B**

### Alt. Set 80-9F

- **Printable** (default). Prints data in the range of hex 80 through hex 9F.
- **Control Code.** Interprets data in the range of hex 80 through hex 9F as a control code.

## Graphic Chek Err

Allows overriding of the host setting for the SGEA (Set Graphic Error Action) command. For more information about the SGEA command, refer to the *Coax/Twinax Programmer's Reference Manual*.

- **Enable** (default). The host setting for the SGEA used by the printer. If the SGEA command is requested to stop on graphic errors, the printer will stop when a graphic error is detected.
- **Disable.** Ignores the SGEA command from the host. The printer does not stop when an error is detected; instead, it substitutes the character selected in the Graphic Chek Code parameter.

## Graphic Chek Cod

Specifies the replacement character to print in place of any unprintable character that is received from the host. Choose a hex character from 40 through FE. The character becomes the printer default when:

- the printer is powered off and then powered on;
- an SGEA command specifies to use the operator panel default;
- the Graphic Chek Err parameter is disabled.

## LAC Option

Allows the host system to load alternate character images into the printer. This may be used for designing graphics, barcodes, and charts, or for printing in foreign languages.

- **Enable** (default). Prints the LAC character as defined.
- **Disable**. Ignores the LAC definition from the host and prints from the currently selected character set.

## LAC Approx.

A process that reorganizes columns of dots so that clean, readable printing is possible.

- **On** (default). Converts the emulated character cells to standard cells for the P7224 model.
- **Off**. Converts character cells byte by byte and not by LAC approximation.

## Set Text Orientn

Specifies the direction in which characters are printed on the page. This allows the printer to print languages that are printed right to left instead of left to right. The options include:

- **Control By Host** (default)
- **Left to Right**
- **Right to Left**

## Host Override

Determines whether the printer accepts certain commands sent by the host or continues to use the current operator panel settings.

- **Disable** (default). Allows the following host commands to override operator panel settings: line length, forms length, lines per inch (LPI), characters per inch (CPI), print quality, and text orientation. Note the information appearing on the message display may not match the data stream setting. No values will change upon initial selection of the disable option.
- **Enable**. The operator panel settings override the host commands.

**NOTE:** Host margin and tab settings will take precedence whether or not Host Override is enabled.

### Format Control

Enables the printer to reflect the same spacing as CTPC model printers after absolute and relative move commands are executed.

- **Disable** (default). Reflects distance, generated by the IGP/VGL feature, IGP/PGL feature, and Hex Transparent control code sequence, in the new position (after absolute and relative move commands are executed).
- **Enable**. Does not reflect distance, generated by the IGP/VGL feature, IGP/PGL feature, and Hex Transparent control code sequence, in the new position (after absolute and relative move commands are executed).

### Max. Print Width

Set the maximum print width at either 13.2 inches or the maximum width of the printer. The default is 13.2 inches.

### Buffer Print

- **Disable** (default). The printer will print normally.
- **Enable**. The printer prints the EBCDIC data and control codes received from the host as hex values. Refer to page 253 for information on how to obtain a hex code printout.

**NOTE:** Use of this parameter may alter print attributes set by the host computer. A power cycle may be required after changing Buffer Print from enable to disable.




# 3270 Params

\* = Factory Default

<sup>1</sup> This menu appears only if the TN3270 option is installed.

**3270  
Params <sup>1</sup>**  
(from page 104)



Max. Print  
Width

13.2 inches\*  
Printer Width



\* = Factory Default

## Translation Tbl

Prints out a table of the Coax interface's current character set. This operation is valid only when the TN3270 interface is the current interface.

## Active Char Set

Specifies which character language set will be the active set.

- **Secondary Sets** (default)
- **Primary Sets**

## Prt Partial Line

- **Enable** (default). When this option is enabled, it forces the printer to print if a partial line is in the printer (i.e. line not ending with a LF).
- **Disable**. When disabled, the last partial line of data will not be printed.

## Early Print Cmpl

Early Print Complete allows the printer to send Print Complete status to the host before the printer is actually done printing all data. Early Print Complete is only available if the IPDS feature is installed.

- **Disable** (default). Means the printer will suppress the Early Print Complete response until all printing is complete.
- **Enable**. Means the printer will send an acknowledgement to the host when it is able to accept more data.

**NOTE:** When an Early Print Complete is enabled and an error occurs, the data in the printer will remain in the buffer (regardless of the setting of the Cancel Buffer option). It is recommended that local procedures be followed to recover from the error.

Do not select Early Print Complete while a print job is in progress. If this is done you will need to restart the printer.

## PTX Transparent

### Lead-in Chars

You can enable additional printer features which are not accessible through standard TN3270 emulations. To access these features, send text commands in the data stream. The commands must have a start and end code. Four sets are available:

- **Set 1.** start code: <% (default)  
stop code: >
- **Set 2.** start code: ␣␣  
stop code: \$
- **Set 3.** start code: \_%  
stop code: \_
- **User Defined.**

### Usr Defined HTRN

This option is used to set user defined lead-in characters. The range is ASCII character. This option allows users to define their own lead-in characters for the Printronix Specific commands. Select a hex value for the following codes for the User Defined option:

- **Start Code 1 5F** (default)
- **Start Code 2 5F**
- **Stop Code 5B**

### Alt. Set 80-9F

- **Printable** (default). Prints data in the range of hex 80 through hex 9F.
- **Control Code**. Interprets data in the range of hex 80 through hex 9F as a control code.

### Change Case

Specifies the font as Mono or Dual case. This option is available only in non-SCS mode. The host will be notified of the change when the printer is placed online. Mono Case prints the same as Dual Case if the character set is one of the following “right to left” sets: Katak., Hebrew, Old Hebrew, and Farsi.

SCS (System Network Architecture Character String) mode is controlled by the host computer.

- **Dual Case** (default)
- **Mono Case**

### Set Text Orientn

Specifies the direction in which characters are printed on the page. This allows the printer to print languages which are printed right to left instead of left to right.

- **Left to Right** (default).
- **Right to Left**. When a right to left language is selected, the host will be notified of print direction changes when the printer is put online.

### Intervention Req

Select from the following:

- **Send To Host** (default). The printer sends a signal to the host computer when any of the following occur:
  - Printer faults occur.
  - Hold mode time-out occurs.
- **Not Send To Host**

If not selected, the printer will only send the signal on printer faults that cause data loss (paper jam, ribbon stall, online platen open, etc.).

## Compatibility Op

The Compatibility Options allow you to select special printer functions in the non-SCS mode based on the capabilities of the printer emulated.

### CR At MPP+1

MPP is Maximum Print Position, which is also known as line length. This option controls a carriage return at the end of a print line and at MPP+1.

- **On** (default). Produces a carriage return to the first print position of the next line.
- **Off**. Produces a carriage return to the first print position of the current line.

### NL At MPP+1

Controls how many lines are skipped when the carriage returns to a new line.

- **On** (default). Moves to the first print position two lines down from the current position.
- **Off**. Moves to the first print position of the next print line.

### Position Aft FF (4234 only)

Allows you to select the location of the print position after a form feed command is sent.

- **On** (default). Sets the printer to print at print position 1 of the first print line on the next form.
- **Off**. Sets the printer to print at print position 2 of the first print line on the next form.

### Last Char = FF

Determines the print line position when a form feed command is the last code encountered in the print buffer.

- **On** (default). Moves to the first print position on the second line of the next form.
- **Off**. Moves to the first print position on the first line of the next form.

**NOTE:** This option is ignored if Auto Skip At End is on.

If configured as a 3287, and a form feed occurs in the middle of a print buffer, the printer defaults to the first print position on the second line of the next form regardless of the setting of this option.

### Null Suppression

- **Off** (default). Ignores nulls. The print position does not move.
- **On**. Treats nulls as blank spaces.

### FF Validity

Determines if the position of a form feed command affects its execution.

- **Off** (default). Performs a form feed only if it occurs at the first print position in a line or at Maximum Print Position +1. A form feed command at any other position is recognized as a space.
- **On**. Allows the printer to perform a form feed command anywhere in the data stream.

### Auto Skip At End

Specifies whether or not to perform an automatic form feed at the end of a print buffer. If form feed is the last character in the print order, the form feed function is supplied by the Auto Skip At End option.

- **Off** (default). Sets the printer to print at print position 1 of the next line.
- **On**. Sets the printer to print at print position 1 of the first line of the next form.

### FF After Job

Determines the print position after an operator-initiated local copy (print screen function).

- **Off** (default). Performs an automatic new line command after completing a print buffer (unless a new line, form feed, or carriage return command was the last one executed). The printer is set to print at print position 1 of the next line.
- **On**. Performs an automatic form feed command unless a form feed was the last one executed. The printer is set to print at print position 1 of the first line on the next form.

### CR, EM, and NL (3287 only)

CR (Carriage Return), EM (Error Message), and NL (New Line) specify that the printer treat the CR, EM, and NL control codes either as spaces or as control codes.

- **On** (default). Treats the CR, EM, and NL commands as control codes.
- **Off**. Treats the CR, EM, and NL commands as spaces.

### Host Override

Determines whether the printer accepts certain commands sent by the host, or continues to use the current operator panel settings.

- **Disable** (default). Allows these host commands to override operator panel settings: line length, forms length, lines per inch (LPI), characters per inch (CPI), print quality, and text orientation. Note the information appearing on the message display may not match the data stream setting. No values will change upon initial selection of the disable option.
- **Enable**. The operator panel settings override the host commands.

## Format Control

Enables the printer to reflect the same spacing as CTPC model printers after absolute and relative move commands are executed.


- **Disable** (default). Reflects distance, generated by the VGL feature, PGL feature, and Hex Transparent control code sequence, in the new position (after horizontal and vertical tabs are executed).
- **Enable**.

## Max. Print Width


Set the maximum print width the printer will print when using a C/T host interface. Set for 13.2 inches when printing files larger than the width of the printer. All data exceeding the width of the maximum Printer Width will be truncated.

- **13.2 inches** (default)
- **Printer Width** (the maximum width of the printer)

## 5250 Params







\* = Factory Default

### Translation Tbl

Prints out a table of the TN5250 interface's current character set. This operation is valid only when the TN5250 interface is the current interface.

### Active Char Set

Selects which group of character sets (Primary or Secondary) will be active.

- **Secondary Set** (default)
- **Primary Set**

### Prt Partial Line

- **Enable** (default). When this option is enabled, it forces the printer to print if a partial line is in the printer (i.e. line not ending with a LF).
- **Disable**. When disabled, the last partial line of data will not be printed.

### PTX Transparent

#### Lead-in Chars

You can enable additional printer features which are not accessible through standard TN5250 emulations. To access these features, send text commands in the data stream. The commands must have a start and end code. Four sets are available:

- **Set 1.** start code: <% (default)  
stop code: >
- **Set 2.** start code: ␣␣  
stop code: \$
- **Set 3.** start code: \_%  
stop code: \_
- **User Defined.**

#### Usr Defined HTRN

This option is used to set user defined lead-in characters. The range is ASCII character. This option allows users to define their own lead-in characters for the Printronix Specific commands. Select a hex value for the following codes for the User Defined option:

- **Start Code 1 5F** (default)
- **Start Code 2 5F**
- **Stop Code 5B**

#### Alt. Set 80-9F

- **Printable** (default). Prints data in the range of hex 80 through hex 9F.
- **Control Code**. Interprets data in the range of hex 80 through hex 9F as a control code.

## Graphic Chek Err

Allows overriding of the host setting for the SGEA (Set Graphic Error Action) command. For more information about the SGEA command, refer to the *Coax/Twinax Programmer's Reference Manual*.

- **Enable** (default). The host setting for the SGEA used by the printer. If the SGEA command is requested to stop on graphic errors, the printer will stop when a graphic error is detected.
- **Disable**. Ignores the SGEA command from the host. The printer does not stop when an error is detected; instead, it substitutes the character selected in the Graphic Chek Code parameter.

## Graphic Chek Cod

Specifies the replacement character to print in place of any unprintable character that is received from the host. Choose a hex character from 40 through FE. The character becomes the printer default when:

- The printer is powered off and then powered on.
- An SGEA command specifies to use the operator panel default.
- The Graphic Chek Err parameter is disabled.

The value can be the following:

- **60** (default)
- **40 – F4**

## Set Text Orientn

Specifies the direction in which characters are printed on the page. This allows the printer to print languages which are printed right to left instead of left to right.

- **Left to Right** (default)
- **Right to Left**. When a right to left language is selected, the host will be notified of print direction changes when the printer is put online.

## Host Override

Determines whether the printer accepts certain commands sent by the host, or continues to use the current operator panel settings.

- **Disable** (default). Allows these host commands to override operator panel settings: line length, forms length, lines per inch (LPI), characters per inch (CPI), print quality, and text orientation. Note the information appearing on the message display may not match the data stream setting. No values will change upon initial selection of the disable option.
- **Enable**. The operator panel settings override the host commands.

### Format Control

Enables the printer to reflect the same spacing as CTPC model printers after absolute and relative move commands are executed.


- **Disable** (default). Reflects distance, generated by the VGL feature, PGL feature, and Hex Transparent control code sequence, in the new position (after horizontal and vertical tabs are executed).
- **Enable**.

### Max. Print Width

Set the maximum print width the printer will print when using a C/T host interface. Set for 13.2 inches when printing files larger than the width of the printer. All data exceeding the width of the maximum Printer Width will be truncated.

- **13.2 Inches** (default)
- **Printer Width** (the maximum width of the printer)

### SPC Coax Params



## Logical Buf Size

Refers to the size of the printer buffer, which should be set the same as the host screen (buffer) size. If the host screen size is unknown, use 1920. Do not change this parameter in the middle of a print job.

## Intervention Req

- **Send to Host** (default). The printer sends a signal to the host computer when the CANCEL key is pressed or a printer fault or hold mode time-out occurs.
- **Do Not Send**. No signal will be sent to the host computer.

## Buffer Print

- **Disable** (default). The printer will print normally.
- **Enable**. The printer prints the EBCDIC data and control codes received from the host as hex values. Refer to page 253 for information on how to obtain a hex code printout.

## Translation Tbl

Prints a table of the Coax interface's current character set. This operation is valid only when the Coax interface is selected (see "HOST INTERFACE" on page 72).

## Column 132 Wrap

When enabled, this option causes the printer to line wrap at 132 characters despite the current print density, allowing more characters per line. The options include:

- **Disable** (default)
- **Enable**

## Usr Defined HTRN

This option is used in Twinax SPC emulation. The range is ASCII character. This option allows users to define their own lead-in characters for the Printronix Specific commands. Select a hex value for the following codes for the User Defined option:

- **Start Code 1 5F**
- **Start Code 2 5F**
- **Stop Code 5B**

## PA1

PA1 is only valid when the printer is in the offline state and the Coax Systems Network Architecture Character String (SCS) data stream is active. This function displays the "PA1 ENABLED" message when the ENTER key is pressed and sends a special operator request to the host when the printer is placed online. Refer to the *Coax/Twinax Programmer's Reference Manual* for more information about SCS.

## PA2

PA2 is only valid when the printer is in the OFFLINE state and the Coax SCS data stream is active. This function displays the “PA2 ENABLED” message when the ENTER key is pressed and sends a special operator request to the host when the printer is placed ONLINE.

## Buffer Reprint

This option is valid only when the printer is printing in SCS mode. When the ENTER key is pressed, “Buffer Reprint Enabled” is displayed and an Intervention Required status is sent to the host. Pressing ENTER again cancels the Buffer Reprint function and “Buffer Reprint Disabled” is displayed.

## SPC Null Supp

- **Enable** (default). Treats nulls as blank spaces.
- **Disable**. Ignores nulls. The print position does not move.

## SPC Space Supp

This option is only available in Coax SPC emulation and is used in LU3/DSC/DSE mode only.

- **Disable** (default). Treats nulls and spaces normally.
- **Enable**. If the entire line consists of spaces and nulls, the line will be discarded.


## NL At MPP+1

Controls how many lines are skipped when the carriage returns to a new line.

- **On** (default). Moves to the first print position two lines down from the current position.
- **Off**. Moves to the first print position of the next print line.

## SPC Twx Params

\* = Factory Default



**NOTE:** To access the SPC Twinax Params menu, be sure to select the Twinax option in the Host Interface menu.

### Device Address

Allows you to set the device address from 0 through 6. The host directs data and commands on the twinax line to a specific device based on its unique device address. After the address has been changed, a POR status is sent to the host.

## SPC Type

Allows you to select a specific type of Simple Protocol Converter (SPC) Twinax emulation: MODE 219 for Model 219 protocol convertor, MODE P5000 for Printronix protocol convertor, and MODE IBM for the IBM protocol convertor.

## Printer Type

Determines the SPC Twinax emulation "Mode." When set to Std Centronics, IGP/VGL, or IGP/PGL, the Set Line Density and Set Print Density commands are translated into a Carriage Return (CR), and vertical format commands are ignored unless the EVFU is enabled.

## SFCC Char

Determines what character is printed when an EBCDIC Logical Not character ¬ (Hex 5F) is received from the host.

## User Defined HTRN

This option is used in Twinax SPC emulation. The range is ASCII character. This option allows users to define their own lead-in characters for the Printronix Specific commands. Select a hex value for the following codes for the User Defined option:

- **Start Code 1**
- **Start Code 2**
- **Stop Code**

## EVFU

- **Enable.** The EVFU parameter allows vertical format control by the host in all four printer type modes.
- **Disable.** Vertical format control is only allowed in IMPACT/P-SERIES mode.

## SPC Char Set

Allows you to select the print language character set.

## Translation Tbl

Prints out a table of the Twinax interface's current character set. This operation is valid only when the Twinax interface is selected.

## Buffer Print


- **Disable** (default). The printer will print normally.
- **Enable.** The printer prints the EBCDIC data and control codes received from the host as hex values. Refer to page 253 for information on how to obtain a hex code printout.



# LinePrinter Plus Emulation

**NOTE:** When the printer is set to SPC Twx Params or SPC Coax Params, no LP+ menu items will take effect on the same offline. The LP+ Emulation resets when the printer is taken offline.




\* = Factory Default



\* = Factory Default


<sup>1</sup>These menus do not appear if the Coax or Twinax host interface is selected. See page 72.

<sup>2</sup> This value is 132 if the Coax or Twinax host interface is selected.



# LinePrinter Plus Emulation (With PCL-II)

**NOTE:** When the printer is set to SPC Twx Params or SPC Coax Params, no LP+ menu items will take effect on the same offline. The LP+ Emulation resets when the printer is taken offline.



## Printer Protocol

Select the LinePrinter+ protocol you wish to use. Refer to the *LinePrinter Plus Programmer's Reference Manual* for more information.

## CPI/LPI Select

This parameter lets you specify the characters per inch (cpi) and lines per inch (lpi) values.

## Host Command

This parameter allows you to block certain host commands from being acknowledged by the printer.

- **Enable** (default). All host commands are acknowledged by the printer.
- **Ignore All**. All host commands are ignored by the printer.
- **Ignore CPI**. All CPI commands sent by the host are ignored by the printer.
- **Ignore LPI**. All LPI commands sent by the host are ignored by the printer.
- **Ignore Unidir**. All Unidirectional commands sent by the host are ignored by the printer.

## Font Attributes

### Typeface

- **Data Processing** (default). A general purpose font printing out at 120 dpi horizontally and 72 dpi vertically. The width of the font will vary with each cpi.
- **NLQ**. A high quality font printing at 180 dpi horizontally and 96 dpi vertically. This font has serifs and the width of the font varies with the cpi.
- **OCR-A / OCR-B**. Optical character recognition fonts printing at 120 dpi horizontally and 144 dpi vertically. Both fonts print only at 10 cpi.
- **High Speed**. A draft quality font printing at 120 dpi horizontally and 48 dpi vertically. The width of the font varies with the cpi.
- **NLQ Sans Serif**. A high quality font printing at 180 dpi horizontally and 96 dpi vertically. This font prints without serifs. The width of the font varies with the cpi.
- **High Speed 100**. A draft quality font printing at 100 dpi horizontally and 48 dpi vertically. When chosen from the front panel, it defaults to 10 cpi. The cpi can then be varied, but the width will not change.
- **NLQ 200**. This NLQ font prints at 200 dpi horizontally and 96 vertically. When chosen from the front panel, it defaults to 12 cpi. The cpi can then be varied, but the width will not change.
- **DP 200**. This Data Processing font prints at 200 dpi horizontally and 72 vertically. When chosen from the front panel, it defaults to 12 cpi. The cpi can then be varied, but the width will not change.
- **High Speed 64**. This font prints at 120 dpi horizontally and 64 vertically. When chosen from the front panel, it defaults to 10 cpi. The cpi can then be varied, but the width will not change.
- **BARCODE 145**. This Data Processing font prints at 145 dpi horizontally and 72 vertically. When chosen from the front panel, it defaults to 12 cpi. The cpi can then be varied, but the width will not change.
- **BARCODE 160**. This Data Processing font prints at 160 dpi horizontally and 72 vertically. When chosen from the front panel, it defaults to 13 cpi. The cpi can then be varied, but the width will not change.

---

## Prop. Spacing (Proportional Spacing)

Each printed character is contained inside a character cell. The width of the character cell includes the character and the space around the character.

- **Disable** (default). Each character cell is printed with the same width. Each column in the printed text will line up.

```
This example is printed with
proportional spacing disabled.
```

- **Enable**. The width of each character cell varies with the width of the character. For example, [i] takes less space to print than [m]. Using proportional fonts generally increases the readability of printed documents, which gives text a typeset appearance.

```
This example is printed with
proportional spacing enabled.
```

## Bold Print

- **Disable** (default). Text is printed normally.
- **Enable**. Text is printed with a heavy line thickness.

## Italic Print

- **Disable** (default). Text is printed normally.
- **Forward Slant**. Text is printed with a forward slant.
- **Backward Slant**. Text is printed with a backward slant.


## Slashed Zero

This parameter allows you to print the numeral “0” with or without the slash. This option applies to all character sets except OCR-A and OCR-B.

- **Disable** (default). Zero is printed without a slash.
- **Enable**. Zero is printed with a slash.

## Text Position

Specifies where the text will be positioned in the line space. When set to Top-of-Line, text will be positioned at the top of the line space. When set to Bottom-of-Line, the text will be positioned as if it were at the bottom of a 6 lpi line space. The following example shows both Top-of-Line and Bottom-of-Line text positions:



## Page Format

### Form Length

Form length is the number of lines that can be printed on a page. You can set the form length in inches, millimeters (mm), or as a function of the current lpi (lines per inch).

### Form Width

The form width can be specified in inches, millimeters, or as a function of the current cpi (characters per inch). The form width set should not exceed the actual paper width.

### Margins

- **Left Margin.** Set in columns. Column zero is defined as the far left edge of the page, and column numbering increments from left to right.
- **Right Margin.** Set in columns. Column zero is defined as the far right edge of the page, and column numbering increments from right to left.
- **Bottom Margin.** Defined in lines, starting from line zero at the bottom of the page and incrementing from the bottom up.

### Perforation Skip

- **Disable** (default). Allows printing on page perforation.
- **1/2 inch, 2/3 inch, 5/6 inch, 1 inch.** You may set up a skip-over margin of 1/2 inch, 2/3 inch, 5/6 inch, or 1 inch. For example, a skip-over margin of 1 inch allows a 1 inch margin at the bottom of the page.

---

## Print Char. Set

When this selection is displayed and the ENTER key is pressed, the current character set is printed.

## Reset Cmd CFG Ld

When the printer receives a host data stream reset command (ESC @ or ESC[K) in addition to resetting printer variables, the selected configuration is loaded.

- **Disable** (default). The active emulation parameters are loaded when the reset command is executed.
- **Power-Up Config**. The power-up configuration is loaded when the reset command is executed.
- **Current Config**. The currently selected configuration is loaded when the reset command is executed.
- **Factory Config**. The factory installed configuration is loaded when the reset command is executed.


## Set Substitution

When this option is activated, the character set overlay in RAM is activated. This can also be accomplished through a host command of **SFCC RX**. In either case, a flag is set indicating that the substitution table is active. If the power-up configuration has Ld Set at Pwrup and Set Substitution both enabled, the character set overlay is automatically activated at power-up or during a soft reset. See the *LinePrinter Plus Programmer's Reference Manual* for more information.


## Barcode x-Offset

- **Disable** (default)
- **Enable**. Allows text to print next to a barcode when xxxx and yyyy are not set to the origin.

## P-Series Emulation




## P-Series Emulation (with PCL-II)





# P-Series Emulation (With LG)



## Control Code 06

Control Code 06 defines the function of ASCII code hex 06 (ACK). You can select an alternate line spacing of 6, 8, or 10.3 LPI.

## Control Code 08

Control Code 08 defines the function of ASCII code hex 08 (BS). You can define the code to output the following character:

- **Elongated** (default).
- **Backspace**.

## Define CR Code

This option controls the action of the printer when it receives a Carriage Return code (hex 0D) from the host computer. If this feature is enabled, each time the printer receives a carriage return, it inserts an additional Line Feed code (hex 0A) into the data stream. Do not use this feature if the host computer sends Line feeds to the printer.

- **CR = CR** (default). Does not insert an extra line feed after each carriage return.
- **CR = CR + LF**. Inserts an extra line feed after each carriage return. The next print position will be print position 1 of the next line.

## Auto LF

This option defines the printer action when print data is received past the forms width setting.

- **Disable** (default). Discards any data past the forms width.
- **Enable**. Performs an automatic carriage return and line feed when data is received past the forms width, causing the excess text to print on the next line.

## Overstrike

This option enables you to print bold characters.

- **Enable** (disable). Turns on bold print. When enabled, overstrike printing slows down the printer.
- **Disable**. Turns off bold print.

## Define LF Code

- **LF = CR + LF** (default). Forces an automatic carriage return with each line feed command. The next print position is print position 1 of the next line.
- **LF = LF**. Does not perform an automatic carriage return. The next print position will be the current print position of the next line.

## P-Series SFCC

This parameter allows you to select which ASCII codes will function as the Special Function Control Code (SFCC) command delimiter.

P-Series codes can use hex 00 through hex 7F. Options include the following:

- ESC (hex 1B)
- SOH (hex 01)
- ETX (hex 03)
- CIRCUMFLEX (hex 5E)—also called caret (^)
- TILDE (hex 7E)—(~)

**NOTE:** SOH, ETX, and ESC are non-printables. The characters (^) and (~) are printable; however, do not use them as printables in the host data stream if either is chosen as a delimiter because print errors will occur.

## VFU Select

Controls how the printer handles vertical formatting.

- **EVFU** (default). Enables the VFU and selects P-Series compatible Electronic Vertical Format Unit (EVFU).
- **DVFU**. Enables the VFU and selects the Dataproducts compatible Direct Access Vertical Format Unit (DVFU).
- **CVFU**. Enables the VFU and selects the Centronics compatible Direct Access Vertical Format Unit (CVFU).
- **Disable**. Disables all VFU processing.

## Alt. Set 80-9F

Determines whether the printer processes ASCII codes hex 80 through hex 9F as control codes or as printable characters. The options include:

- **Control Code** (default)
- **Printable**.

## Character Set

Specifies a character set as shown in the “P-Series Character Set Menu” on page 148. To use one of these sets, choose the desired group heading (such as European Sets) and press ENTER. Then choose the desired set within that group (such as Roman 8) and press ENTER. Both the group and the desired set will be starred to indicate your selection. The UTF-8 selection allows printing of UTF-8 encoded Unicode™. Character sets are shown in detail in the *Character Sets Reference Manual*.

## SFCC d Command

- **Even dot plot** (default). This option interprets SFCC d Command as even dot plot.
- **Double High**. This option interprets SFCC d Command as double high. Select this option for backward compatibility.

## PSeries Dbl High


Allows printing compatibility between current and older model printers.


- **Normal** (default). This is normal, double-high printing for current model printers.
- **P3/4/6/9 Compat**. Where older printers print two dot rows higher, this option allows for compatibility by raising the print two dot rows to match the current models dot row value (two dot rows lower).

## FF Valid at TOF

- **Enable** (default). Performs a form feed when the host sends a Form Feed command and the printer is at the top of form.
- **Disable**. Will not perform a form feed when the host sends a Form Feed command and the printer is at the top of form.

### P-Series Character Set Menu





## P-Series Character Set Menu (with PCL-II)

\* = Factory Default

**Character Set**  
(from page 144)

IBM PC\*  
  Primary Subset  
    ASCII (USA)\*  
    French  
    German  
    English  
    Danish  
    Swedish  
    Italian  
    Spanish  
    Japanese  
    French Canadian  
    Latin American  
    Danish II  
    Spanish II  
    Latin Am II  
  Extended Subset  
    Code Page 437\*  
    Code Page 850  
  Extended Subset  
Multinational  
  ASCII (USA)\*  
  EBCDIC  
ECMA Latin 1  
DEC Mult.  
OCR-A  
OCR-B  
Latin 2 8859-2  
Latin 2 852  
Bulgarian  
Latin 9 8859-15  
Polish POL1  
DEC 256 Greek  
ELOT 928 Greek  
Greek 3  
ABY Greek  
ABG Greek  
ELOT 927 Greek  
Greek 437  
Greek 8859-7  
PC851 LiGk [12G]  
Greek-7 [12N]  
Greek-8 [8G]  
Hebrew Old  
Hebrew New  
Hebrew DEC


## P-Series Character Set Menu (with LG)

<b>Character Set</b> (from page 144)
---

\* = Factory Default

IBM PC*	DEC Mult.
Primary Subset	ASCII (USA)*
ASCII (USA)*	French
French	German
German	English
English	Norw./Danish
Danish	Swedish
Swedish	Italian
Italian	Spanish
Spanish	Japanese
Japanese	French Canadian
French Canadian	Dutch
Latin American	Finnish
Danish II	Swiss
Spanish II	OCR-A
Latin Am II	OCR-B
Extended Subset	Latin 9 8859-15
Code Page 437	CP 858 Euro
Code Page 850	
Multinational	
ASCII (USA)*	
EBCDIC	
ECMA Latin 1	
Primary Subset	
ASCII (USA)*	
German	
Swedish	
Danish	
Norwegian	
Finnish	
English	
Dutch	
French	
Spanish	
Italian	
Turkish	
Japanese	
Extended Subset	
Multinational*	
Barcode 10 CPI	
Mult. DP 10 CPI	
Mult. DP 12 CPI	
Mult. LQ 10 CPI	
Greek DP 10 CPI	
Greek DP 12 CPI	
Greek LQ 10 CPI	
Grap. DP 10 CPI	
Grap. LQ 10 CPI	
Sci. DP 10 CPI	
Sci. DP 12 CPI	
Sci. LQ 10 CPI	

## P-Series XQ Emulation



### Control Code 06

Control Code 06 defines the function of ASCII code hex 06 (ACK). You can select an alternate line spacing of 6, 8, or 10.3 LPI.

### Define CR Code

This option controls the action of the printer when it receives a Carriage Return code (hex 0D) from the host computer. If this feature is enabled, each time the printer receives a Carriage Return, it inserts an additional Line Feed code (hex 0A) into the data stream. Do not use this feature if the host computer sends line feeds to the printer.

- **CR = CR** (default). Does not insert an extra line feed after each carriage return.
- **CR = CR + LF**. Inserts an extra line feed after each carriage return. The next print position will be print position 1 of the next line.

### Auto LF

This option defines the printer action when print data is received past the forms width setting.

- **Disable** (default). Discards any data past the forms width.
- **Enable**. Performs an automatic carriage return and line feed when data is received past the forms width.



## Define LF Code

- **LF = CR + LF** (default). Forces an automatic carriage return with each line feed command received. The next print position is print position 1 of the next line.
- **LF = LF**. Does not perform an automatic carriage return when a line feed command is received. The next print position will be the current print position of the next line.

## Compressed Print

Controls which host command sets compressed printing.

- **Char 01 SOH** (default)
- **Char 03 ETX**
- **Char 09 HT**

## Elong/Alt. Font

Controls which host command sets elongated (double high) fonts and extended character set.

- **EIng=BS Font=SO** (default)
- **EIng=SO Font=BS**

## HS Print (High Speed Print)

Controls which host command sets high speed printing.

- **Char 02 STX** (default)
- **Char 03 ETX**
- **Char 09 HT**

## VFU Select

Controls how the printer handles vertical formatting. The choices are:

- **EVFU** (default). Enables the VFU and selects P-Series compatible Electronic Vertical Format Unit (EVFU).
- **DVFU**. Enables the VFU and selects the Dataproducts compatible Direct Access Vertical Format Unit (DVFU).
- **CVFU**. Enables the VFU and selects the Centronics compatible Direct Access Vertical Format Unit (CVFU).
- **Disable**. Disables all VFU processing.

### Upr. Case Select

Controls how the printer handles lowercase characters it receives from the host computer. When enabled, all characters will be printed in uppercase.

- **Disable** (default). Prints lowercase characters received from the host computer as lowercase, and prints uppercase characters received from the computer as uppercase.
- **Enable**. Prints lowercase characters received from the host computer as their corresponding uppercase equivalents; uppercase characters received from the computer print as uppercase.


### Slew Relative

“Slewing” is rapid vertical paper movement. This parameter determines the number of lines slewed (either 1-15 lines or 1-16 lines) when an EVFU Slew Relative command is received. The options include:

- **1-15 Lines** (default)
- **1-16 Lines**

### Serial Matrix Emulation

\* = Factory Default



## Control Code 06

Control Code 06 defines the function of ASCII code hex 06 (ACK). You can select an alternate line spacing of 6, 8, or 10.3 LPI.

## Define CR Code

This option controls the action of the printer when it receives a Carriage Return code (hex 0D) from the host computer. If this feature is enabled, each time the printer receives a Carriage Return, it inserts an additional Line Feed code (hex 0A) into the data stream. Do not use this feature if the host computer sends line feeds to the printer.

- **CR = CR** (default). Does not insert an extra line feed after each carriage return.
- **CR = CR + LF**. Inserts an extra line feed after each carriage return. The next print position will be print position 1 of the next line.

## Auto LF

The Auto LF option defines the printer action when print data is received past the forms width setting.

- **Enable** (default). Performs an automatic carriage return and line feed when data is received past the forms width.
- **Disable**. Discards any data past the forms width.

## Overstrike

This option enables you to print bold characters.

- **Enable** (default). Turns on bold print. When enabled, overstrike printing slows down the printer.
- **Disable**. Turns off bold print.

## Define LF Code

- **LF = LF** (default). Does not perform an automatic carriage return when a line feed command is received. The next print position will be the current print position of the next line.
- **LF = CR + LF**. Forces an automatic carriage return with each line feed command received. The next print position is print position 1 of the next line.

### Printer Select

- **Disable** (default). Ignores the ASCII DC1 and DC3 control codes.
- **Enable**. Disables the printer when a DC1 control code is received, and enables the printer when a DC3 control code is received.

### Alt. Set 80-9F

- **Control Code** (default). Interprets data in the range of hex 80 through hex 9F as a control code.
- **Printable**. Prints data in the range of hex 80 through hex 9F.

### Character Set

Specifies a character set as shown in the “Serial Matrix Character Set Menu” on page 157. To use one of these sets, choose the desired group heading (such as European Sets) and press ENTER. Then choose the desired set within that group (such as Roman 8) and press ENTER. Both the group and the desired set will be starred to indicate your selection. Character sets are shown in detail in the *Character Sets Reference Manual*.


### ESC d command


- **Even dot plot** (default). Interprets the ESC d command as even dot plot.
- **Double high**. Interprets the ESC d Command as double high. Select this option for backward compatibility.

## Serial Matrix Character Set Menu


**Character Set**  
(from page 154)

\* = Factory Default





## Proprinter XL Emulation



### Define CR Code

This option controls the action of the printer when it receives a Carriage Return code (hex 0D) from the host computer. If this feature is enabled, each time the printer receives a Carriage Return, it inserts an additional Line Feed code (hex 0A) into the data stream. Do not use this feature if the host computer sends line feeds to the printer.

- **CR = CR** (default). Does not insert an extra line feed after each carriage return.
- **CR = CR + LF**. Inserts an extra line feed after each carriage return.

### Auto LF

This option defines the printer action when print data is received past the forms width setting.

- **Enable** (default). Performs an automatic carriage return and line feed when data is received past the forms width.
- **Disable**. Discards any data past the forms width.

### Define LF Code

- **LF = LF** (default). Does not perform an automatic carriage return when a Line Feed command is received. The next print position will be the current print position of the next line.
- **LF = CR + LF**. Forces an automatic carriage return with each Line Feed command received. The next print position is print position 1 of the next line.

### FF Valid at TOF

- **Enable** (default). Performs a form feed when the host sends a Form Feed command and the printer is at the top of form.
- **Disable**. Will not perform a form feed when the host sends a Form Feed command and the printer is at the top of form.

## Character Set

Specifies a character set as shown in the “Proprinter XL Character Sets Menu” on page 161. To use one of these sets, choose the desired group heading (such as European Sets) and press ENTER. Then choose the desired set within that group (such as Roman 8) and press ENTER. Both the group and the desired set will be starred to indicate your selection. The UTF-8 selection allows printing of UTF-8 encoded Unicode™. Character sets are shown in detail in the *Character Sets Reference Manual*.

## Alt. Char Set

This option determines if data in the range of hex 80 through hex 9F should be interpreted as a control code or as a printable character.

- **Set 1** (default). Interprets data in the range of hex 80 through hex 9F as a control code.
- **Set 2**. Prints data for the characters at hex locations 03, 04, 05, 06, 15, and 80 through 9F.

## 20 CPI Condensed


Compressed print characters are narrower than the normal character set. This is helpful for applications where you need to print the maximum amount of information on a page.

- **Enable** (default). Prints characters about 60 percent the width of normal characters when compressed print is chosen by the host computer.
- **Disable**. Does not compress print widths, even if condensed print is chosen by the host.



## Proprinter XL Character Sets Menu

\* = Factory Default



### Proprinter XL Character Sets Menu (with PCL-II)

**Character Set**  
(from page 159)

\* = Factory Default

Code Page 437\*  
Code Page 850  
OCR-A  
OCR-B  
Latin 2 8859-2  
Latin 2 852  
Bulgarian  
Latin 9 8859-15  
Polish POL1  
Multinational  
DEC 256 Greek  
ELOT 928 Greek  
Greek 3  
ABY Greek  
ABG Greek  
ELOT 927 Greek  
Greek 437  
Greek 8859-7  
PC851 LtGk [12G]  
Greek-7 [12N]  
Greek-8 [8G]  
Hebrew Old  
Hebrew New  
Hebrew DEC

### Proprinter XL Character Sets Menu (with LG)


**Character Set**  
(from page 159)

\* = Factory Default

Code Page 437\*  
Code Page 850  
OCR-A  
OCR-B  
Code Page 210  
Code Page 220  
Code Page 852  
Code Page 855  
Code Page 857  
Code Page 862  
Code Page 866  
Lithuanian 1  
Lithuanian 2  
Hebrew New  
Hebrew Dec  
Hebrew Old  
Latin 9 8859-15  
CP 858 Euro

## Epson FX Emulation

\* = Factory Default



### Define CR Code

The Define CR Code option controls the action of the printer when it receives a Carriage Return code (hex 0D) from the host computer. If this feature is enabled, each time the printer receives a carriage return, it inserts an additional Line Feed code (hex 0A) into the data stream. Do not use this feature if the host computer sends line feeds to the printer.

- **CR = CR** (default). Does not insert an extra line feed after each carriage return.
- **CR = CR + LF**. Inserts an extra line feed after each carriage return.

### Auto LF

This option defines the printer actions when print data is received past the forms width setting.

- **Enable** (default). Performs an automatic carriage return and line feed when data is received past the forms width.
- **Disable**. Discards any data past the forms width.

### Define LF Code

The Define LF Code option controls the action of the printer when it receives a Line Feed code (hex 0A) from the host computer. If this feature is enabled, each time the printer receives a Line Feed, it inserts an additional Carriage Return code (hex 0D) into the data stream. This feature is required if the host computer does not send carriage returns to the printer.

- **LF = LF** (default). Does not add a carriage return with a line feed.
- **LF = CR + LF**. Adds an extra carriage return with each line feed.

## Printer Select

- **Disable** (default). Ignores the ASCII DC1 and DC3 control codes.
- **Enable**. Disables the printer when a DC1 control code is received, and enables the printer when a DC3 control code is received.

## Character Set

This parameter selects a character set for the Epson emulation, as shown in the “Epson FX Character Set Menu” on page 165. Note that when OCR-A or OCR-B is selected as the print language, the Font Attribute Typeface option under the LinePrinter Plus menu (page 140) is changed to OCR-A or OCR-B, respectively.

To use one of these sets, choose the desired group heading (such as European Sets) and press ENTER. Then choose the desired set within that group (such as Roman 8) and press ENTER. Both the group and the desired set will be starred to indicate your selection. The UTF-8 selection allows printing of UTF-8 encoded Unicode™. Character sets are shown in detail in the *Character Sets Reference Manual*.

## 20 CPI Condensed

Compressed print characters are narrower than the normal character set. This is helpful for applications where you need to print the maximum amount of information on a page.


- **Enable** (default). Prints about 60 percent of the width of normal characters when compressed print is chosen by the host computer. For example, a 12 CPI Draft font will compress to 20 CPI.
- **Disable**. Does not compress print widths, even if condensed print is chosen by the host.

## Alt. Set 80-9F

- **Control Code** (default). Interprets data in the range of hex 80 through hex 9F as a control code.
- **Printable**. Prints data in the range of hex 80 through hex 9F.

## Epson FX Character Set Menu

\* Factory Default



## Epson FX Character Set Menu (with PCL-II)

\* Factory Default

**Character Set**  
(from page 163)

Epson Set\*  
ASCII (USA)\*  
French  
German  
English  
Danish I  
Swedish  
Italian  
Spanish I  
Japanese  
Norwegian  
Danish II  
Spanish II  
Latin Am I  
French Canadian  
Latin Am II  
OCR-A  
OCR-B  
Latin 8859-2  
Latin 2 852  
Cyrillic 866  
Bulgarian  
Latin 9 8859-15  
Polish POL1  
Multinational  
ASCII (USA)\*  
EBCDIC  
DEC 256 Greek  
ELOT 928 Greek  
Greek 3  
ABY Greek  
ABG Greek  
ELOT 927 Greek  
Greek 437  
Greek 8859-7  
PC851 LtGk [12G]  
Greek-7 [12N]  
Greek-8 [8G]  
Hebrew Old  
Hebrew New  
Hebrew DEC  
IBM PC

## Epson FX Character Set Menu (with LG)


**Character Set**  
(from page 163)

\* Factory Default

Epson Set\*  
ASCII (USA)\*  
French  
German  
English  
Danish I  
Swedish  
Italian  
Spanish I  
Japanese  
Norwegian  
Danish II  
Spanish II  
Latin Am I  
French Canadian  
Latin Am II  
OCR-A  
OCR-B  
Code Page 210  
Code Page 220  
Code Page 852  
Code Page 855  
Code Page 857  
Code Page 862  
Code Page 866  
Lithuanian 1  
Lithuanian 2  
Hebrew Old  
Hebrew New  
Hebrew Dec  
Latin 9 8859-15  
CP 858 Euro  
IBM PC



# ANSI Emulation

\* Factory Default





\* = Factory Default



## CPI/LPI Select

Defines the default values for the horizontal and vertical character spacing. The number of characters per inch can range from 10.0 through 17.1. The number of lines per inch can range from 3.0 through 8.0.

## Font Attributes

### Typeface

Choose a typeface from the available options.

### Prop. Spacing (Proportional Spacing)

Each printed character is contained inside a character cell. The width of the character cell includes the character and the space around the character.

- **Disable** (default). Each character cell is printed with the same width. Each column in the printed text will line up.

```
This example is printed with  
proportional spacing disabled.
```

- **Enable**. The width of each character cell varies with the width of the character. For example, [i] takes less space to print than [m]. Using proportional fonts generally increases the readability of printed documents, giving text a typeset appearance.

```
This example is printed with  
proportional spacing enabled.
```

### Bold Print

- **Disable** (default). Text is printed normally.
- **Enable**. Text is printed with a heavy line thickness.

### Slashed Zero

This parameter allows you to print the numeral “0” with or without the slash. This option applies to all character sets except OCR-A and OCR-B.

- **Disable** (default). Zero is printed without a slash.
- **Enable**. Zero is printed with a slash.

---

## Page Format

### Margins

- **Left Margin.** Defines where the first print column is located. The left margin is specified as the number of characters from the left edge of the form.
- **Right Margin.** Defines where the last print column is located. The right margin is specified as the number of characters from the right edge of the form.
- **Top Margin.** Defines the location of the first print line on the page. The top margin is specified as the number of lines from the top of the form's position.
- **Bottom Margin.** Defines the location of the last print line on the page. The bottom margin is specified as the number of lines from the bottom of the form's position.

### Form Length

Specifies the form length in lines. The maximum form length in lines depends on the current LPI setting; it is equal to the maximum form length in inches multiplied by the current LPI setting. For example, at 6 LPI the maximum form length is 6 LPI x 24 inches = 144 lines.

Only valid form length values will be accepted. If you select a length that is larger than the maximum length for the current LPI, the maximum length will be used. If you need a longer page length, you must first change the LPI.

### IMPORTANT

**If the form length is set in lines and you change the LPI, the effective page length changes to the form length in characters divided by the new LPI.**

**NOTE:** Receipt of a data stream control code which changes the form length overrides the form length previously specified via the operator panel.

### Form Width

Allows you to input the form width in characters from 1 through 272. The maximum form width in characters depends on the current CPI setting; it is equal to the maximum form width in inches multiplied by the current CPI setting.

Only valid form width values will be accepted. If a width is selected that is larger than the maximum width for the current CPI, then the maximum width will be used. If a larger width value is desired, then the CPI value must be changed first.

Table 6 lists the maximum number of characters that can be printed for a given Characters Per Inch (CPI) setting.

**IMPORTANT** If the form width is set in characters and the CPI is changed, the effective page width is changed to be equal to the form width in characters divided by the new CPI.

Table 6. Form Width

CPI Setting	Maximum Form Width (in characters)
10.0	136
12.0	163
13.3	181
15.0	204
16.7	227
17.1	272

### Define CR Code

The Define CR Code option controls the action of the printer when it receives a Carriage Return code (hex 0D) from the host computer. If this feature is enabled, each time the printer receives a carriage return, it inserts an additional Line Feed code (hex 0A) into the data stream. Do not use this feature if the host computer sends line feeds to the printer.

- **CR = CR** (default). No extra line feeds are inserted.
- **CR = CR + LF**. Inserts an extra line feed after each carriage return.

### Auto LF

Defines the printer actions when print data is received past the form width setting.

- **Disable** (default). Discards any data past the form width.
- **Enable**. Performs an automatic carriage return and line feed when data is received past the form width.

### Define LF Code

Controls the action of the printer when it receives a Line Feed code (hex 0A) from the host computer. If this feature is enabled, each time the printer receives a line feed, it inserts an additional carriage return code (hex 0D) into the data stream. This feature can be used in most installations, but it is required if the host computer does not send carriage returns to the printer.

- **LF = CR + LF** (default). Adds an extra carriage return with each line feed.
- **LF = LF**. Does not add a carriage return with a line feed.

---

## Character Set

This parameter selects a character set for the ANSI emulation. Note that when 0876 OCR-A or 0877 OCR-B is selected as the print language, the Font Attributes Typeface parameter is changed to OCR-A or OCR-B, respectively. Character sets are shown in detail in the *Character Sets Reference Manual*.

## Printer Select

- **ON = DC1/OFF = DC3** (default). Disables the printer when a DC1 control code is received, and enables the printer when a DC3 control code is received.
- **Disable**. Ignores the DC1 and DC3 control codes.

## ESC c Sequence

- **Enable** (default). An ESC c code received from the host resets the printer parameters to the factory defaults.
- **Disable**. An ESC c code received from the host is ignored.

## Reset Cmd CFG Ld

When the printer receives a host data stream reset command (ESC @ or ESC[K) in addition to resetting printer variables, the selected configuration will be loaded.

- **Disable** (default). The active emulation parameters are loaded when the reset command is executed.
- **Power-Up Config**. The power-up configuration is loaded when the reset command is executed.
- **Current Config**. The currently selected configuration is loaded when the reset command is executed.
- **Factory Config**. The factory installed configuration is loaded when the reset command is executed.

## Received CR

- **Observe** (default). A CR code received from the host is handled as a carriage return.
- **Ignore**. A CR code received from the host is ignored.

## Received DEL

- **Observe** (default). A DEL code received from the host is handled as a Delete command.
- **Ignore**. A DEL code received from the host is ignored.

## Private Mode

Determines the default type of character set (Set 1 or Set 2). This can also be set by ESC sequences ESC [>5h and ESC [>5l. Refer to these descriptions in the *ANSI Programmer's Reference Manual* for further details.

### Pos. on BC/OvrSz

- **Set to top** (default). The paper is fed back to the top of barcodes or oversized characters after they are printed. This allows printing on the same line.
- **Set to bottom**. The printer will continue printing without backing up.

### BC Check Digit

- **By host** (default). The host calculates the barcode check digit and sends it along with the barcode. The check digit is not verified by the printer but printed as it was received.
- **By printer**. The barcode is sent without the check digit, and the printer calculates and adds it in.

### Barcode Darkmode

- **Enable** (default). The barcodes are printed at a higher resolution.
- **Disable**. The barcodes are printed at lower resolution but at a higher speed.

### PUM Default

This is the Unit of Measure (UOM) as it is used within the ANSI emulation. Coordinates received in ESC sequences can be sent in two UOMs:

- **Decipoints** (default). A unit of 1/720 inch
- **Lines or columns**. Uses the current LPI and CPI values.

The UOM used is determined by this configuration setting.

### Truncate PI Slew

- **Truncate at TOF** (default). The slew is terminated when the next Top-of-Form is reached. (This function applies to the ANSI EVFU only.)
- **Disable**. PI slews will be completed independent of their length.

### ETX/ACK

End of Text/Acknowledge. The host controls the flow of communication to the printer by sending a block of data and ending the block with an End of Text (ETX) signal. When the printer receives the ETX signal, it acknowledges the ETX, thereby acknowledging it has received the entire block of data.

- **Disable** (default)
- **Immediate**
- **Afterprint**

---

## IGP/PGL Emulation

---

The PGL emulation is the software based Intelligent Graphics Processor (IGP) for the line matrix family of printers. It is based upon, and is compatible with, the IGP-100/200/400 board using the PGL. The IGP graphics processing features are detailed below.

### Features

---

**On-Line Form and Label Generation** makes it easy to create forms or labels with a “preprinted” look for each application. IGP programs control all graphic functions, dramatically reducing host computer programming and processing time.

Graphic capabilities include boxes, vertical and horizontal lines with user-selectable thickness, logos, and special alphanumeric print features. Forms and graphic designs can be duplicated horizontally and vertically.

Alphanumeric data can appear as prepositioned “fixed” information (entered when the form is created), be overlayed onto the form (positioned in a specific location after the form is created), or can be dynamically merged with the form.

**Selectable Barcodes** provide you with the appropriate barcode for your application using standard wide-to-narrow ratios. A wide selection of barcodes is available: Code 39, Interleaved 2 of 5, UPC-A, UPC-E, MSI A through D, Code 128 Subset A, B, and C, EAN/UCC-128, EAN 8, EAN 13, POSTNET, PostBar, Royal Mail, and PDF417. UPC and EAN barcodes can specify add-on data.

**Expanded and Compressed Character Print** attract attention where needed. Alphanumeric height and width are controlled independently for a wide range of character sizes up to 113 times the standard character size (up to 11.3 inches wide and tall). Compressed print sizes of 10, 12, 13, 15, 17, and 20 characters per inch (cpi) are available.

**Logos** are created using alphanumeric commands and add many print and shading features for a “customized” appearance to forms, reports, and labels.

**Rotated Alphanumerics** permit new concepts in form design. Normal, expanded, and compressed character strings can be rotated 90 degrees clockwise or counterclockwise, or they can be printed upside down.

**Reversed Print** permits highlighting and contrasting by printing white characters on a dark background.

**Automatic Increment/Decrement Capability** allows batch form processing. Individual alphabetic, numeric, and barcode data fields can be identified and automatically incremented or decremented by any amount, beginning from a specified reference point.

**Scaling Capability** permits graphic elements, such as corners or boxes, to retain their physical shapes and sizes when printed in a horizontal and vertical density other than the base density of 60 x 72 dpi.

**Multinational Character Sets** provide many international character sets, each 96 characters in length. This feature also allows you to create your own character sets using characters defined and stored in memory.

**Extended Character Sets** provide 33 extended character sets, also containing 96 characters in length. These are also stored in memory.

## Configuring The Emulation With The Control Panel

---

You can select PGL default parameters directly from the control panel or by control codes as explained in the *IGP/PGL Programmer's Reference Manual*. The PGL parameters are described on the following pages. Parameters marked with an asterisk (\*) indicate the default value. The printer must be offline to enter the configuration structure.


Pressing an invalid key to enter a parameter value may move you to another level in the configuration or exit the configuration menu completely. Configure the IGP/PGL according to your specific requirements.

**IMPORTANT** **BEFORE** you reconfigure the IGP/PGL, print a configuration sheet to see all of the current settings.




# IGP/PGL Submenu

\* = Factory Default




## IGP/PGL Submenu (With PCL-II)

\* = Factory Default



## IGP/PGL Submenu (With LG)



### Define CR (Carriage Return) Code

This parameter forces the printer to insert an automatic Line Feed code into the data stream whenever a Carriage Return code occurs. This is to be used only if the host computer does not send line feeds to the printer.

- **CR = CR** (default). Does not perform a line feed. The next print position will be print position 1 of the current line.
- **CR = CR + LF**. Performs an automatic line feed. The next print position will be print position 1 of the next line.

## Define LF (Line Feed) Code

This parameter forces the printer to insert an automatic Carriage Return code into the data stream whenever a Line Feed code occurs. This can be used in most installations, but it is required if the host computer does not send carriage returns to the printer.

- **LF = LF** (default). Does not perform an automatic carriage return. The next print position will be the current print position of the next line.
- **LF = CR + LF**. Performs an automatic carriage return. The next print position will be print position 1 of the next line.

## Autowrap

This parameter determines if text will wrap to the next line when the line of text exceeds the right margin.

- **Disable** (default). Truncates the text beyond the right margin until a CR or CR + LF is received.
- **Enable**. Automatically inserts a CR + LF after a full print line.

## PGL SFCC

You can specify which hex code (1-255) will be used as the Special Function Control Code (SFCC). The factory default setting is 126. The SFCC denotes that the following data is a PGL command.

## PI Slew Range

You can specify how many lines the paper will feed.

- **16** (default). A paper slew of 0-15 will move 1-16 lines.
- **15**. A paper slew of 1-15 will move 1-15 lines. A paper slew of 0 will move 1 line.

## CR Edit

This parameter determines if a carriage return will be followed by a line feed.

- **Disable** (default). The printer ignores all carriage returns that are not followed by line feeds.
- **Enable**. The printer processes all carriage returns, even for those that are not followed by line feeds.

## Select Font

Select Font specifies which language is currently selected for use with the PGL. Refer to "IGP/PGL Font Set Menu" on page 188 for available selections.

---

## Slash 0

This parameter allows you to print the numeral “0” with or without the slash. This option applies to all character sets except OCR A and OCR B.

- **Disable** (default). Zero is printed without a slash.
- **Enable**. Zero is printed with a slash.

## Select LPI

This is the number of lines to be printed per inch. For example, at 6 lpi there is 1/6 inch from the top of one print line to the top of the next print line. The options are:

- **6.0** (default)
- **8.0**
- **9.0**
- **10.0**

## Auto Uppercase

This parameter enables the printer to print text in all uppercase when using the ALPHA command.

- **Disable** (default). The printer will print text in upper and lowercase.
- **Enable**. The printer will print text in uppercase only.

## Skip Cmd Prefix

This parameter determines if the printer will print any data before a PGL command is received.

- **Enable** (default). The printer ignores all data on the current line before an IGP command.
- **Disable**. The printer will print all data on the current line before an IGP command.

## Forms Handling

This submenu allows the user to handle the form in the following ways:

- **Disable** (the default). No effect.
- **Auto Eject**. Automatically ejects a page at the end of the job to spill out the last page.
- **Auto TOF**. Automatically does a form feed (FF) at the end of each form to the next top of form.


## Power On IGP/PGL

You can set the IGP feature so that it is enabled or disabled when the printer is powered on.

- **Enable** (default). The PGL is enabled when the printer is powered on. (The PGL feature is initialized in the Normal mode.)
- **Disable**. The PGL is disabled when the printer is powered on. (The PGL feature is initialized to the Quiet mode.)

## Ext Execute Copy

- **Disable** (default). Dynamic data and overlay data are not allowed if the optional Form Count parameter (number of forms to print) is specified as part of the Execute command. (This setting is IGP-100 compatible.)
- **Enable**. Only dynamic data is allowed within a form in which the Form Count parameter is specified in the Execute command. In this case, the exact same form (with identical dynamic data, etc.) is printed for the Form Count. However, incremental data is not incremented since the page that is printing is exactly the same. Also, each form is printed on a separate page.



## Barcode Options

The following sub-options help define specific options regarding barcode printing.

### UPC Descenders

This parameter allows you to print barcode descenders when human readable data is not present in the UPC/EAN barcodes.

- **Always** (default). UPC/EAN barcodes are printed with descenders, even if there is no human readable data.
- **Never**. UPC/EAN barcodes are printed without descenders if there is no human readable data.
- **Only with PDF**. UPC/EAN barcodes are printed with descenders only when the PDF command is present.

---

## Optimized Ratio

This option selects different barcode ratios for certain barcodes including Code 39 and I-2/5. It is included for compatibility with the IGP-X00 printers.

- **Disable** (default). Use standard barcode ratios.
- **Enable**. Select the alternate barcode ratios.

## I-2/5 Selection

This option is added to be compatible with a special IGP-X00 customization. Usually, if I-2/5 barcodes have an odd number of digits, a leading zero is inserted in front of the data. However, this special IGP-X00 customization gives you the option of adding a space character at the end of the barcode instead.

- **Leading Zero** (default). A leading zero is inserted in front of the printable data field.
- **Trailing Space**. A space is inserted at the end of the printable data field and a zero is encoded with the corresponding space in the end of the barcode.
- **X2 DPD**. When selected, an I-2/5 barcode with an X2 magnification will use the specially configured ratios 3:3:6:5 rather than 3:6:9:12 for compatibility issues.
- **Modulo 7 CD**. The I-2/5 barcode uses a modulo 7 check digit instead of the default modulo 10 check digit.

## AI 00 Spaces

This option is designated for EAN/UCC-128 barcodes whose application identifier (AI) is 00.

- **Disable** (default). The printable data field is printed with the AI enclosed in parentheses. This is the standard EAN/UCC-128 format.
- **Enable**. The printable data field is printed with the UCC fields separated by spaces. This option is IGP-X00 compatible.

## Select SO Char

Allows you to specify a decimal code from 0 through 255 to be used in place of SO (Shift Out) as the control code. This allows access for the alternate set of control function characters. See the description of the Code 128 barcodes in the *IGP/PGL Programmer's Reference Manual* for details.

## User-Def Ratio

- **Enable** (default). User-defined ratios are accepted for barcodes. This is the default.
- **Disable**. User-defined ratios are ignored and the magnification X1 is used in its place.

### C39 Compatbl.

This menu makes the old method of decoding C39 alternative character set compatible with the new.

- **Disable** (default) Uses the current way of decoding.
- **Enable.** Matches the old method of decoding.

### Host Form Length

Determines whether the form length specified in the CREATE command changes the form length designated in the LP+ menu (see “LinePrinter Plus Emulation” on page 137) when the form is printed by the EXECUTE command.

- **Disable** (default). The LP+ form length is unaffected by the form being printed.
- **Enable.** The LP+ form length changes to match the length of the PGL form being printed.

### Var Form Adjust

**(Ranges from 0 - 30).** Default is 0. This menu value is tenths of inches. The value of this menu specifies the amount of distance to add to PGL forms that have variable form lengths. Variable length forms are forms that are defined by using a “;0” in the CREATE statement: ~CREATE;FORM;0. Variable form lengths are defined by the contents within the form - the form is only as long as necessary to print the form. Changing this menu value adds additional lengths to the form (in tenths of inches). Again, this only applies to forms that use the “;0” variable length forms.

### Var Form Type

This menu option applies only to the host command, CREATE;NAME or CREATE;NAME;DISK. The host command CREATE;NAME followed by ;0, ;X or a form length number will always override the menu option.

- **Add Nothing** (default). No action.
- **Add; 0.** When selected, the form length ends at the longest printed element. Same as CREATE;NAME;0.
- **Add; X.** When selected, the form length is the same as the physical page length.

### Compressed CPI

This parameter allows you to choose a compressed character (60% shorter) for 17 or 20 cpi instead of the normal height character.

- **Disable** (default). The PGL does not use compressed 17 or 20 cpi font.
- **Light Font.** Uses the standard compressed 17 or 20 cpi font.
- **Dark Font.** Uses a darker compressed 17 or 20 cpi font compatible with the IGP-X00 printers.



---

## Ignore Char

- **Ignore Mode**

This parameter instructs the PGL to ignore the character selected under the Select Character menu.

- **Disable** (default). The PGL does not ignore any characters.
- **Enable**. The PGL ignores the characters specified in the Select Character menu.

- **Select Char**

Instructs the PGL which decimal character (0-255) to ignore from the host.

## Compatbl. Mode

This option instructs the PGL to behave similarly to older versions of the IGP with respect to certain commands.

All new users with new applications should select the “None” option. Selecting this mode insures the printer will behave as described in this manual.

When replacing an older product operating with an existing application, especially those using the PMODE and SMODE commands, you may need to select a compatibility mode. In this case, select the printer model number option that most closely matches the printer being replaced. The Compatibility Mode options include:

- **None** (default)
- **MVP**
- **L150**
- **P3000**
- **P6000**
- **P9000**

## Expanded Font

This option defines the type of expanded characters the PGL will select:

- **Scalable** (default). These expanded characters have rounded edges.
- **Block**. These are block characters compatible with the IGP-X00 printers.
- **Alt Block 1 / Alt Block 2**. Reserved block sets used only for compatibility purposes.

## Scalable Size

- **Normal** (default). Controls the size of scalable characters to be either normal size (as set by the user) or adjusted to match the size of block fonts. This is the default.
- **Block**. Adjusts the size of scalable characters to exactly match its block font alternative.

### True Form Slew

This option is related to slewing within forms when using the PMODE command. Customers with new applications are advised to keep this option enabled.

- **Enable** (default). Form length is accurate according to the form length parameter in the CREATE command.
- **Disable**. Form length is IGP-X00 compatible when using PMODE.

### Printer PI Line

This option enables the IGP to send PI instructions to the printer to slew the form.

- **Enable** (default). Send the PI instructions to the printer (LinePrinter Plus) during form slew. This is IGP-X00 compatible.
- **Disable**. Do not send PI instructions to the printer. LFs are sent instead.

### Print Quality

- **Data Processing** (default). The emulation prints at 60 x 72 dpi and lets you choose between normal alphanumerics and barcodes and dark mode alphanumerics and barcodes. This mode should be set if you want the highest speed.
- **High**. The emulation prints at 120 x 72 dpi, but all alphanumerics and barcodes are automatically printed in dark mode.
- **Best**. The emulation prints at 120 x 144 dpi and dark mode, which produces a higher resolution, better-looking print image.

### Power-on S-Mode

This option instructs the PGL to behave similarly to older versions of the IGP with respect to certain commands.

All new users with new applications should select “0,” the default option. Selecting this mode insures the printer will behave as described in this manual.

Power on S-Mode sets the printer in an SMODE compatibility state at power-up. The default is 0 (disabled, no power-on mode). To use this feature, select a mode from 1 through 5, which puts IGP/PGL in an SMODE state according to the compatibility mode set. If the compatibility mode set is None, then MVP is assumed by default.

For more information, see the *IGP/PGL Programmer's Reference Manual*.

---

## Trunc Dyn Data

This submenu allows the user to truncate the dynamic data up to the maximum data length specified in Create Mode.

- **Disable** (default). If the dynamic data exceeds the maximum data length, an error will report.
- **Enable**. If the dynamic data exceeds the maximum data length, the data truncates.

## Error Report


Sets the error reporting capability for IGP/PGL forms.

- **On** (default). Form boundary error checking reported. Any element which falls off the current page is reported as an error.
- **Debug Mode**. The printer is put in debug mode whenever a form is defined in Create Form mode. Each line of the Create Form is printed along with an error if one occurred. This is the same functionality as if there were a slash (/) entered before the Create Form Name.
- **Fault**. When an error occurs, the error is printed and the message "IGP/PGL ERROR" appears on the printer front panel. The printer then stops printing and goes offline. The error must be cleared before the printer can resume normal operation.
- **Off**. No form boundary checking. Graphic elements appear clipped if they are beyond the page boundaries.

## Select Font

Allows you to choose from various character sets, including IGP/PGL Standard sets, 256 character multinational sets, and UTF-8 encoded Unicode™.

### IGP/PGL Font Set Menu



---

## IGP/VGL Emulation

---

Code V Graphics language (VGL) is an Intelligent Graphics Printing (IGP) software emulation designed for your Line Matrix printer. The IGP Code V emulation of the QMS<sup>®</sup> Code V Version II programming language produces online forms, barcodes, and alphanumeric text-generation. The graphics processing features are detailed below.

---

### Features

---

**OnLine Form and Label Generation** makes it easy to create forms or labels with the “preprinted” look for each application. VGL programs control all graphics functions, dramatically reducing host computer programming and processing time. Graphics capabilities include boxes, vertical and horizontal, solid and dashed lines with a variety of thickness, logos, and special alphanumeric print features.

**Variable Barcodes** allow the barcode for your application to print with standard or user-defined ratios in vertical or horizontal orientations. Available barcodes are Codabar, Code 39, Code 93, Code 128 with Subsets A, B, and C, and Code EAN/UCC 128, EAN 8, EAN 13, Interleaved 2 of 5, MSI, UPC-A, UPC-E, POSTNET, PostBar, Royal Mail, and UPC Shipping. POSTNET is available only in the horizontal direction. A dark print mode is included for darker, high-contrast barcodes. The IBARC barcode command prints barcodes in four orientations: horizontal, rotated 90, rotated 180, or rotated 270 degrees.

**Expanded and Compressed Print** draws attention where needed. Alphanumeric height and width are controlled independently for a tremendous range of character sizes up to 9.9 inches wide and tall. Several compressed print sizes are available: 12, 13.33, 15, 17.65, and 20 (dpi), permitting up to 170 columns in an 8.5 inch printed area (20 dpi).

**Rotated Alphanumerics** permit new concepts in form design. Normal, expanded, and compressed character strings can be rotated 90 degrees clockwise, counterclockwise, or printed upside down.

**Logos** are easily created using alphanumeric commands and a variety of print and shading features, which provides a “customized” appearance for forms, reports, and labels. The registered trademark, copyright, TUV<sup>®</sup>, GS-Mark, UL<sup>®</sup>, and CSA<sup>®</sup> symbols are provided as standard designs on the VGL, and you can also define custom symbols.

**Reverse and Shaded Print** permit highlighting and contrasting by printing white characters on a dark background or white characters on a gray, shaded background. Various levels or patterns of gray shading and reverse printing may combine with the many other print features to create distinctive designs.

**Automatic Increment/Decrement Capability** allows batch form processing. Individual alphabetic, numeric, and barcode data fields can be identified and automatically incremented or decremented by any amount, beginning from a specified reference point.

**Standard Character Sets** provide you with many different character sets. Based on the Multinational Character Set, you can create your own character sets using characters defined and stored in flash memory.

## Configuring The Emulation With The Control Panel


You can select VGL default parameters directly from the control panel or by control codes as explained in the *IGP/VGL Programmer's Reference Manual*. The VGL parameters are described on the following pages. Parameters marked with an asterisk (\*) indicate the default value. The printer must be offline to enter the configuration structure.

**IMPORTANT** BEFORE you reconfigure the IGP/VGL, print a configuration sheet to see all of the current settings.

Pressing an invalid key to enter a parameter value may move you to another level in the configuration menu or exit the menu completely.


### IGP/VGL Submenu

\* = Factory Default




## IGP/VGL Graphics Options Submenu

\* = Factory Default



## IGP/VGL Submenu (with PCL-II)


\* = Factory Default






## IGP/VGL (with PCL-II) Graphics Options

\* = Factory Default




## IGP/VGL Submenu (with LG)

\* = Factory Default



## IGP/VGL (with LG) Graphics Options



### SFCC & Pwrup

This option has several sub-options which define the SFCC and power-up configuration used with VGL.

#### VGL SFCC

This option selects the Special Function Control Code. The default value 5E. Run a configuration printout to determine the currently selected VGL SFCC.

#### Power Up ^X

- **Disable** (default).
- **Enable**. Selects the ignore mode as the power-up default and selects the graphics mode ^PY as the power-up default. All characters are ignored until a ^A command is received.

#### Power Up ^F

- **Disable** (default).
- **Enable**. Selects free format mode as the power-up default and selects the graphics mode ^PY as the power-up default. Free format causes the VGL to ignore carriage returns, line feeds, and all characters below hex 20 sent from the host.

### Power Up ^PY

- **Disable** (default).
- **Enable**. Selects the graphics mode ^PY as the power-up default.

### LPI

The number of lines to be printed per inch. For example, at 6 lpi there is 1/6 inch from the top of one print line to the top of the next print line.

### Graphics Options

The following are several options which configure printing output.

#### Slash 0

This parameter allows you to print the numeral “0” with or without the slash. This option applies to all character sets except OCR-A and OCR-B.

- **Disable** (default). Zero is printed without a slash.
- **Enable**. Zero is printed with a slash.

#### Ignore Dots

- **Disable** (default).
- **Enable**. Causes the VGL to expect position values to be specified in only 1/10ths of an inch. If the dot position is also given, it is treated as text.

#### Append Rotated

- **Disable** (default). Logos and alphanumeric strings are treated as separate elements.
- **Enable**. Appends logos to an alphanumeric string rotated in a clockwise, counterclockwise, or inverted orientation.

#### Truncate Alpha

When enabled, this parameter prevents the printing of Error 48 (Element Off Page Error) if alphanumeric data, including spaces, extends beyond the right side of the form. The options include:

- **Enable** (default)
- **Disable**

#### True Vert 1/10

- **Disable** (default). A vertical 1/10 of an inch parameter is used as 7/72 of an inch. The absolute move is slightly smaller than expected. For example, a one-inch move would be 70/72 of an inch. Vertical moves that have the same value are identical in length.
- **Enable**. A vertical 1/10 inch parameter is used as 1/10 inch. Rounding occurs to the nearest 1/72 inch. This can cause vertical moves that have the same value to differ by  $\pm 1/72$  inch.

---

### Absorb After ^PY

- **Absorb Motion** (default). The first paper motion following a ^PY command is ignored.
- **Absorb All**. The system ignores all the data and terminator until a host generated motion terminator is detected.
- **Disable**. System terminators following a graphics command are sent to the printer and result in paper motion.

### UPC Descenders

- **Enable** (default). UPC/EAN barcodes are printed with descenders, even if there is no human readable data.
- **Disable**. UPC/EAN barcodes are printed without descenders if there is no human readable data.

### Rot. Char Size

- **Adjusted** (default). Rotated (clockwise/counterclockwise), expanded characters have a different size than an unrotated character with the same size parameters.
- **Not Adjusted**. Rotated, expanded characters are the same size as unrotated characters with the same size parameters.

### Ignore Spaces

- **Disable** (default). Trailing spaces are not deleted from the last alphanumeric element in a graphics pass.
- **Enable**. Trailing spaces are deleted from the last alphanumeric element in a graphics pass.

### Midline PY (includes ^PN)

- **Disable** (default). The Graphics mode Enable command, ^PY, must be the first three characters of a line.
- **Enable**. The ^PY or ^PN can occur anywhere in a line.

### Print Quality

- **Data Processing** (default). ALPHA text and barcodes are printed in normal mode at 60 x 72 dpi. This mode should be set if the highest speed is desired.
- **High**. ALPHA text and barcodes are printed in dark mode at 120 x 72 dpi.

### Expanded Font

- **Scalable** (default). These expanded characters have rounded edges.
- **Block**. These are block characters compatible with IGP-X10 printers.

### LP+ Font

- **Disable** (default). The IGP/VGL uses its default half-dot font, which is slightly different from the standard bitmap font used by LP+ at 12, 13, 15 and 17 cpi.
- **Enable**. The IGP/VGL uses the same font as used by LP+ at all cpi.

### MSI Check Digit

- **Print** (default). The check digit is appended at the end of the printable data field for MSI barcodes.
- **Don't Print**. The check digit for MSI barcodes does not print.

### I25 Selection

- **I25 Odd Data** (default). When an odd number of data is provided, the default setting, Leading Zero, will add a zero to the beginning of the bar code data. The setting, Check Digit, will add a check digit to the end of the bar code data so that the results add up to an even number of data.
- **Convert Alpha**. Disable is the default. When enabled, each non-digit I25 bar code character will convert to "0."

**NOTE:** If you use an Interleaved 2/5 barcode that automatically adds the check digit (type code k or l, IBARC type code INT2/5CD or INT2/5CDA), the check digit is added regardless of how this parameter is set.

### AI 00 Spaces

This option is designated for EAN/UCC-128 barcodes whose application identifier (AI) is 00.

- **Disable** (default). The printable data field is printed with the AI enclosed in parentheses. This is the standard EAN/UCC-128 format.
- **Enable**. The printable data field is printed with the UCC fields separated by spaces. This option is IGP-X00 compatible.

---

## Width Limit

- **Disable** (default).
- **Enable**. The system will limit the length and width for expanded characters to a limit shown in Table 7, which displays the maximum width allowed for a specific height in the range of 00 through 40 (0.0 through 4.0 inches).

Table 7. Width Limit Table

Height Param.	Max. Width Allowed	Height Param.	Max. Width Allowed
00	99	21	51
01	99	22	53
02	3	23	56
03	6	24	58
04	8	25	61
05	11	26	63
06	13	27	66
07	16	28	68
08	18	29	71
09	21	30	73
10	23	31	76
11	26	32	78
12	28	33	81
13	31	34	83
14	33	35	86
15	36	36	88
16	38	37	91
17	41	38	93
18	43	39	96
19	46	40	98
20	48		

## Absorb After ^PN

- **Disable** (default). All line terminators that follow the ^PN command are sent to the printer and processed.
- **Enable**. The first motion line terminator that follows the ^PN command is ignored.

## IGP110 Compatbl.

This option instructs the VGL to behave similarly to the IGP-10 with respect to certain commands. All new users with new applications should select the "Disable" option. Selecting this mode insures the printer will behave as described in this manual.

- **Disable** (default). The IGP does not emulate the IGP-10 mode.
- **Enable**. The IGP emulates the IGP-10 version.

### Auto FF at ^PN

- **Disable** (default). A form feed will not be generated automatically when the ^PN command is encountered.
- **Enable**. A form feed will be generated automatically to slew to the top of the next form when the ^PN command is encountered and when the current vertical position is not at top of form.

### PDF Size Comp.

This option is for compatibility of the font size of the barcode printable data field on the old build.

- **Disable** (default). Uses the normal font size.
- **Enable**. Matches the font size of the old build.

### C128 Mode Comp

The menu is for compatibility of the old build in auto mode switch.

- **Disable** (default). Uses auto mode switch.
- **Enable**. Matches the old build on the auto mode switch.

### C39 Compatbl.

This menu makes the old method of decoding C39 alternative character set compatible with the new.

- **Disable** (disable). Uses the current way of decoding.
- **Enable**. Matches the old method of decoding.

### Ignore ^Lxx Cmd.

- **Disable** (default).
- **Enable**. The ^Lxx command will always be ignored.

## Error Handling

Following are several options which define how errors are reported.

### Error Msgs

- **Enable** (default). Command syntax is checked and error messages printed when command parameters are incorrect.
- **Disable**. Error checking and error messages are suppressed.



---

## Error Markers

- **Enable** (default). Prints the following error markers for those elements that print beyond the page boundaries:
  - >> for elements that begin off the right side of the page;
  - << for elements that begin at the indicated position but end off the page; ♦ for elements where the starting position of the command contains an error other than an off-page error.

## Offpage Errors

- **Disable** (default). Does not report errors for elements that start or end beyond the right edge of the page.
- **Enable**. Reports errors for elements that start or end beyond the right edge of the page.

## Barcode Errors

- **Enable** (default). An error message will print when invalid barcode data is encountered.
- **Disable**. VGL will not print an error for illegal barcode data; the barcode will be skipped.

**NOTE:** When the Barcode Errors option is disabled, the VGL emulation will try to make the best use of invalid data by either truncating extra digits or adding zeros to the end of barcode data to meet minimum data length requirements for some barcodes. Not all errors will be corrected.

## Ignore / DB8 Setup

Following are several options which define character filtering and Data Bit 8.

### Ignore Chars

- **Disable** (default). Character filtering is not enabled.
- **Char 1**. Character 1 will be filtered. Select the option “Ignore CH#1” to specify character 1.
- **Char 2**. Character 2 will be filtered. Select the option “Ignore CH#2” to specify character 2.
- **Char 1 & 2**. Characters 1 & 2 will be filtered. Select the options “Ignore CH#1” and “Ignore CH#2” to specify values for these characters.

### Ignore CH#1

Specifies character 1 for the character filtering option. Valid decimal values are from 0 through 255.

### Ignore CH#2

Specifies character 2 for the character filtering option. Valid decimal values are from 0 through 255.

### Data Bit 8

- **Enable** (default). The PI line is not passed directly from host to printer; all 8 bits are used for data bits, and characters in the hex 80-FF range can be accessed.
- **Disable**. When the host PI line is enabled, Data Bit 8 internally indicates PI line status. To use the PI line, disable Data Bit 8, and enable the Host PI configuration option (under the PI Control option, below).

**NOTE:** Data Bit 8 is interpreted as either Data Bit 8 or PI signal, but never both. When enabled as Data Bit 8, Data Bit 8 has priority over the PI signal, and all data above hex 7F is used to access character data and not to interpret PI line data.

Conversely, when Data Bit 8 is disabled and the PI signal is used, Data Bit 8 of the data is reserved for use as the PI function, and you cannot access characters in the hex 80-FF range. Therefore, to access characters in the hex 80-FF range, Data Bit 8 must be enabled.

### Font Set

The Font Set specifies which language is currently selected for use with the VGL. Refer to “IGP/VGL Font Set Menu” on page 204 for available selections.

### PI Control

#### Printer PI

- **Disable** (default). The ASCII emulation is configured with the PI line disabled.
- **Enable**. The ASCII emulation is configured with the PI line enabled.

#### Host PI

- **Disable** (default). The host does not send PI signals.
- **Enable**. The host sends PI signals. The Data Bit 8 configuration option must be disabled to transmit the PI line to the printer.

#### Max PI 16

- **Enable** (default). A paper slew of 0-15 will move 1-16 lines.
- **Disable**. A paper slew of 1-15 will move 1-15 lines. A paper slew of 0 will always move 1 line.


---

## **Prt To Emulate**


This option allows you to select an earlier model printer/IGP board combination to emulate. When a printer emulation is selected, the scaling command causes the printer to generate a graphic image in the same density as the printer emulation chosen. Five types of printers can be emulated: MVP or MVP 150B, L150, P3040, P6000, and P9000. Once a printer emulation is selected, it remains active until the printer is turned off or another printer emulation is selected. All new users with new applications should select the "Disable" option, which insures the printer behaves as described in this manual. The other compatibility modes are required to emulate the behaviors of older printers which may be inconsistent with the documented VGL functionality. Proper use of this feature requires the printer to be equipped with high resolution hammer bank tips (12 mil).

## IGP/VGL Font Set Menu

\* = Factory Default



# IPDS Emulation



Your IPDS printer emulates the IBM 4234 twinax models 008 and 012.

IPDS Twinax printers can only print IPDS data streams and nothing else. Even a simple job, such as a screen print, is IPDS data in a twinax attachment. Because the printer definition on a twinax host is either set automatically (by auto configuration) or manually, the printer type is already known.

**NOTE:** A general discussion about starting and stopping IPDS can be found in the IBM 4234 Product and Programming Reference Manual (GC31-3879). Sending a non-IPDS data stream to an IPDS printer and vice versa will result in a hung spool file or writer.

### Font Size

This parameter chooses the font size which will be used by IPDS.

- **Select By Host** (default). The font ID is only affected by host commands.
- **Standard**. The font ID is converted to a decompressed font ID.
- **Compressed**. The font ID is converted to a compressed font ID.

### Print Quality

This parameter chooses the print quality.

- **Select By Host** (default). The application decides the print quality.
- **Default Font**. The default font the printer uses.

### Graphics Quality

This parameter chooses the print quality of graphics.

- **High** (default). Graphics are printed at 144 dot rows per inch.
- **Select By Host**. The application decides the quality of the graphics.
- **Low**. Graphics are printed at 72 dot rows per inch.

### Barcode Quality

This parameter chooses the horizontal print quality of barcode labels.

- **High** (default). Label is printed at 144 dots per inch.
- **Select By Host**. The application decides the quality of the labels.
- **Low**. Label is printed at 72 dots per inch.

### Barcode Speed

This parameter chooses the vertical print quality of barcode labels.

- **High** (default). Barcodes are printed with less vertical dots, increasing printing speed, but decreasing print quality.
- **Select By Host**. The application decides the quality of the labels.
- **Low**. Barcodes are printed with more vertical dots, decreasing printing speed, but increasing print quality.

---

## Barcode Size

This parameter will emulate the barcode sizes of the selected printer model.

- **4234** (default). IBM 4234
- **67XX**. Decision Data 67XX
- **64XX**. IBM 6400 series
- **4224**. IBM 4224

## Early Print Comp (Complete)

This parameter chooses when to send a Print Comp to the controller.

- **Off** (default). Print Comp is sent if page is printed completely.
- **On**. Print Comp is sent immediately. The next page will be created. This improves the print performance when starting the next page.

**NOTE:** When Early Print Comp is enabled and an error occurs, you may lose data.

## Graphics Scaling

This parameter chooses the scaling factor for graphics when the Mappin. Control option of the IPDS Write Graphics Control command is SCALE TO FIT:

- **Rounded** (default). Calculations are rounded up in the desired output resolution.
- **Exact**. Graphics will be scaled as accurately as possible.

## Graphic CharSize

This parameter will emulate the graphic character size of the selected printer model.

- **4234** (default). IBM 4234
- **67XX**. Decision Data 67XX

## I2/5 Checksum

This parameter defines the printer checksum calculation method for Interleaved 2 of 5 barcodes.

- **Standard (1/3)** (default). The odd numbers will be multiplied by 3 and the even numbers by 1 for calculation of the checksum.
- **Special (4/9)**. The odd numbers will be multiplied by 4 and the even numbers by 9 for calculation of the checksum.

**NOTE:** "Odd" refers to the 1st, 3rd, 5th... character in the barcode, while "even" refers to the 2nd, 4th, 6th... character in the barcode.

## Default Code Pag

Choose which code page to use with the IPDS emulation. This option is independent of the Character Set selection in the CTHI emulation.

## **Code Page Subset**

When the Thai code page is selected as the default, either from the front panel or by a host command, you may choose from three different versions.

## **Default Font**

Choose a font quality and size from the available selections. All fonts in the Default Font menu are available in standard and compressed vertical resolution (see page 205).

## **VPA Check**

- **Enable** (default). The printer checks for dots that fall outside the intersection of the logical and physical pages. If dots fall outside the area, the printer reports an error to the host if the IPDS Exception Handling Control command setting requires error reporting.
- **Disable**. The printer does not report dots outside the valid printable area.

## **Hexdump Mode**

A hex code printout (or hex dump) translates all incoming data to hexadecimal equivalents. A hex dump lists each ASCII data character received from the host computer, together with its corresponding two-digit hexadecimal code. Hex dumps can be used to troubleshoot some types of printer data reception problems.


## **Print IPDS Fonts**

This feature allows you to print a list of all resident fonts currently available in the active IPDS emulation



# PCL - II Emulation

\* = Factory Default





---

## Primary Char. Set

You can select one of 92 pre-defined character sets by ID (although character sets range from 0 - 109, not all sets are available on the LJ500 printer), or you can select pitch, symbol set, and typeface individually. If the combination you choose matches one of the 92 predefined sets, the ID submenu will reflect that selection. If not, the ID menu will display xx to indicate that the current character set does not match a pre-defined set. Set 0 is the default, and its attributes are 10 cpi, Data Processing typeface, and Roman 8 symbol set.

## Second Char. Set

Your printer can store an additional character set. To toggle between them, send the Shift In (Decimal 15, to select the Primary character set) or Shift Out (Decimal 14, to select the Secondary character set).

## Page Length Rep.

- **Inches/Page** (default). All page length calculations are based on the inches displayed on the panel.
- **Lines/Page**. All changes in LPI or density will be changed accordingly. The length of the page is the number of lines per inch, or lpi.

For example, if the form in use is 82 lines at 6 lpi, the page is physically 13.67 inches. Since 13.67 inches is not selectable from the Length in Inches menu, change the representation to lines, then set the number of lines to 82. The inches menu will display 13.6 inches although the printer internally keeps the exact form length of 13.67 inches.

## Max Line Width

Set the maximum line width at 13.2 inches (default) or 13.6 inches.

## Face CPI Delay

Allows the combination of different font densities on the same line.

- **Enable** (default). Different font densities can be used on the same line.
- **Disable**. Only the same font densities are allowed on the same line.

## Graphics Density

Graphics can be printed in 60 DPI (default) or 70 DPI.

## Perforation Skip

- **Disable** (default). Allows printing on page perforation.
- **Enable**. You may set up a skip-over margin. For example, a skip-over margin of one inch creates a one inch margin at the bottom of the page.

## Display Functions


- **Disable** (default). The default. Control characters are not printed.
- **Enable**. Control characters are printed before they get executed. This is a useful debugging tool.

## Line Terminator

You can define the action of the line. Four options are available: LF after CR, CR after LF, CR after FF, and CR after VT. Each of these options may be enabled or disabled independent of one another.

## PTX Linefeed

- **Disable** (disable). The default. Linefeed is to be performed as calculated from the bottom of the graphics or barcode, thereby disrupting the vertical text alignment.
- **Enable**. The Linefeed moves to the next line as calculated from the Top of Form position, thereby retaining vertical text alignment. When printing graphics or bar codes, you may want to set the PTX Linefeed parameter to Enable to maintain text alignment.



## LPI Adjust

This parameter lets you specify the lines per inch (lpi) values: 6 LPI (default) or 8 LPI.

## Page L./Lines

This parameter lets you set physical page length in lines from 12 to 96 at 6 lpi, or 16 to 128 at 8 cpi. The default is 66 lines at 6 lpi.

**NOTE:** If 6 lpi is selected, you will be able to scroll the menu to 128 (an invalid length). However, when you press ENTER to select this value, the menu will return with the maximum lines for 6 lpi (i.e., 96 lines). Similarly, selecting too few lines for 8 lpi will cause the menu to return with 16 lines.

## Page L./Inches

This parameter allows you to set physical page length from 2 to 16 inches, in increments of half an inch. The default is 11 inches.

## Config Print

This option prints the emulation's parameters and the currently selected values.

## Symbol Set Print


This option prints a list of all the available sets. The character set number prints to the left of the character set sample.

## Reset Cmd CFG Ld

When the printer receives a host data stream reset command in addition to resetting printer variables, the selected configuration will be loaded.

- **Current Config** (default). If you have preset and presaved multiple configurations, then the currently selected presaved configuration is loaded when the reset command is received.
- **Factory Config**. The factory installed configuration is loaded when the reset command is received.
- **Disable**. The printer ignores the reset command when it is received and continues to use the currently loaded configuration.
- **Power-Up Config**. The power-up configuration is loaded when the reset command is received.

## LG Emulation



**Font**  
(from page 213)

Style

Character Set

DP 10 6\*  
 DP 10 8  
 DP 12 6  
 DP 12 8  
 DP 15 6  
 DP 15 8  
 DP 15 10  
 HS 10 6  
 Corespon 5 6  
 Corespon 5 8  
 Corespon 6 6  
 Corespon 6 8  
 Corespon 10 6  
 Corespon 10 8  
 Corespon 12 6  
 Corespon 12 8  
 Corespon 15 6  
 Corespon 15 8  
 Corespon 15 10  
 OCR A  
 OCR B  
 Compress 6 6  
 Compress 6 8  
 Compress 8 6  
 Compress 8 8  
 Compress 13 6  
 Compress 13 8  
 Compress 13 10  
 Compress 16 6  
 Compress 16 8  
 Compress 16 10  
 DP 5 6  
 DP 5 8  
 DP 6 6  
 DP 6 8

GL Char Set  
 U.S. ASCII\*  
 DEC Finnish  
 French  
 DEC Fr. Can.  
 German  
 Italian  
 JIS Roman  
 DEC Nor./Dan.  
 Spanish  
 DEC Swedish  
 DEC Great Brit.  
 ISO Nor./Dan.  
 DEC Dutch  
 DEC Swiss  
 DEC Portuguese  
 VT100 Graphics  
 DEC Suppl.  
 DEC Technical  
 ISO Katakana  
 7-Bit Hebrew  
 7-Bit Turkish  
 Greek Suppl.  
 Hebrew Suppl.  
 Turkish Suppl.  
 GR Char Set  
 DEC Suppl.\*  
 DEC Technical  
 VT100 Graphics  
 ISO Katakana  
 ISO Latin 1  
 ISO Latin 2  
 ISO Latin 5  
 ISO Latin 9  
 ISO Cyrillic  
 ISO Greek  
 ISO Hebrew  
 Hebrew Suppl.  
 Turkish Suppl.

---

## Font

Select a default font style and character set for the LG emulation, as follows:

- **Style.** This option allows you to specify a print quality that includes a characters per inch (cpi) and lines per inch (lpi) setting, in the format Type cpi lpi. The default setting is DP 10 6 (Data Processing, 10 cpi, 6 lpi). The print quality types you may choose from are as follows:  
DP = Data Processing (standard quality)  
CORESPON = Correspondence (near letter quality)  
COMPRESS = Compressed (vertically compressed for printing long graphs and charts)  
OCR A & OCR B = Optical Character Recognition, sets A and B  
HS = High Speed (Draft quality for high speed printing)
- **Character Set.** This option allows you to select a character set. The character set you select can be any of the Digital Multinational sets, which include the U.S. ASCII set and several foreign language and special character sets.

## Vert Forms

- **Bot Frm 66/6** (default). This option sets the bottom margin for the forms. You must specify the bottom margin in lines (at 6 lines per inch), ranging from 0 to 198 lines (33 inches). The default setting is 66. Press the right arrow to increase the value, left arrow to decrease the value, and ENTER to change units. Selecting a value for this option resets the top margin to 0, so the top margin must be redefined after this option is selected.
- **Top Mrg 6/0.** This option sets the top margin for the forms. You must specify the top margin in lines (at 6 lines per inch), ranging from 0 to 198 lines (33 inches). The default setting is 0. Press the right arrow to increase the value, left arrow to decrease the value, and ENTER to change units. The margins will automatically adjust so that the top and bottom margins do not cross each other.
- **Bot Mrg 66/6.** This option sets the bottom margin for the forms. You must specify the bottom margin in lines (at 6 lines per inch), ranging from 0 to 198 lines (33 inches). The default setting is 66. Press the right arrow to increase the value, left arrow to decrease the value, and ENTER to change units. Selecting a value for this option resets the top margin to 0, so the top margin must be redefined after this option is selected.

## Horiz Forms

- **Left Mgr 0.00** (default). This sets the left margin for the forms. You must specify the left margin in 1/10 inch increments, from 0 to 13.1 inches. The default value is 0. Press the right arrow to increase the value, left arrow to decrease the value, and ENTER to change units. The margins will automatically adjust so that the left and right margins do not cross each other.
- **Right Mrg 13.2**. This sets the right margin for the forms. You must specify the right margin in 1/10 inch increments, from 0.1 to 13.2 inches. The default value is 13.2. Press the right arrow to increase the value, left arrow to decrease the value, and ENTER to change units. The margins will automatically adjust so that the left and right margins do not cross each other.

## Autowrap

This parameter determines if text will wrap to the next line when the line of text exceeds the right margin.

- **No** (default). Any print data received past the forms width setting is discarded.
- **Yes**. An automatic carriage return and line feed is performed when data is received past the forms width setting.

## CR

This option controls the action of the printer when it receives a Carriage Return code (hex 0D) from the host computer. If this feature is enabled, each time the printer receives a Carriage Return, it inserts an additional Line Feed code (hex 0A) into the data stream. Do not use this feature if the host computer sends line feeds to the printer.

- **= CR** (default). Does not insert an extra line feed after each carriage return.
- **= CR + LF**. If this feature is enabled, each time the printer receives a Carriage Return, it inserts an additional Line Feed code (hex 0A) into the data stream. (Do not use this feature if the host computer sends Line Feeds to the printer with each Carriage Return.)

## LF

This parameter forces the printer to insert an automatic Carriage Return code into the data stream whenever a Line Feed code occurs. This can be used in most installations, but it is required if the host computer does not send carriage returns to the printer.

- **= LF** (default). Does not perform an automatic carriage return. The next print position will be the current print position of the next line.
- **= CR + LF**. Each time the printer receives a Line Feed, it inserts an additional Carriage Return code (hex 0D) into the data stream. This feature can be used in most installations, but it is required if the host computer does not send Carriage Returns to the printer.



---

## FF

This parameter forces the printer to insert an automatic Carriage Return code into the data stream whenever a Form Feed code occurs. This can be used in most installations, but it is required if the host computer does not send carriage returns to the printer.

- = **FF** (default). Does not perform an automatic carriage return. The next print position will be the current print position of the next form.
- = **CR + FF**. Performs an automatic carriage return. The next print position will be print position 1 of the next form.

## Unsolicited Rpt

This option enables or disables Printer Device Status Reports to be sent to the host when a reportable status or error condition has occurred.

- **No** (default). Disables all unsolicited status reports from the printer.
- **Small**. Enables brief unsolicited status reports and sends an extended status report to the host.
- **Big**. Enables extended, unsolicited status reports and sends an extended status report to the host.

## Print Mode Opt

When enabled, this option affects the SPI, SHS, and DECShORP commands. The printer will no longer be forced into these commands and print speed improves significantly when in portrait orientation. For SHS and DECShORP, the character size will change with the selected pitch. In addition, SGR attributes such as bold, crossed-out, and italics, will be done in print mode with greater efficiency.

- **Enable** (default). Enables the print mode option.
- **Disable**. Disables the print mode option. This provides compatibility with older LG printer products.

## Plot Mode Opt


When enabled, this option will plot with greater efficiency, particularly with respect to the Postnet barcode. Postnet is printed in the same density as the current print mode font so that reverse motion will be inhibited when possible.

- **Enable** (default). Enables the print mode option.
- **Disable**. Disables the print mode option. This provides compatibility with older LG printer products.

## I-2/5 Guard Bars

- **Enable** (default). Horizontal guard bars are printed above and below each Interleaved 2/5 bar code. This option only applies to Interleaved 2/5 bar codes.
- **Disable**. Interleaved 2/5 bar codes are printed normally, with no guard bars.

# PRINTER CONTROL



## Ribbon End Point

This parameter adjusts the point at which the system will declare the ribbon as being expended. The life count will always be from 100% to 0%, but if a darker setting is selected 0% will be reached more quickly. If a lighter setting is selected, the system will extend the time it takes to reach 0%. The range of values are as follows:

- **Normal** (default)
- **Darker +1 through Darker +6**
- **Lighter -1 through Lighter -10**

**NOTE:** This value can be adjusted at any time and the display will automatically adjust to show the correct percentage relative to the new end point.

---

## Open Platen @ BOF (Bottom of Form)

Some special forms have perforation areas that are too thick to pass through the print station. This parameter, when enabled, opens and closes the platen when the perforations move across the platen. When enabling this parameter, you must set the forms length to match the physical distance between perforations.

## Bar Code Quality

Determines the bar code resolution for all emulations, except IPDS. (See "IPDS Emulation" on page 205 to set the bar code quality for IPDS.)

- **Dark** (default). Bar code resolution is set at 120 x 72.
- **Draft**. Bar code resolution is set at 60 x 72.

## Tear Bar Dist. (Distance)

Allows fine and course adjustment of the tear bar position. For a pedestal model printer using the top paper exit, the default (7.46 inches) is used. You can specify 4.5 to 10.5 inches in .01 inch increments to accommodate variations in cover and form design.

## View Function

- **Disable** (default). Disables the View Function which allows you to press the VIEW/EJECT key to move the last data printed to the tractor area for viewing.
- **Enable**. Enables the View Function

## Unidirectional

The Unidirectional feature affects both print quality and printing speed. By setting this feature, you can configure the printer to print in both directions of the shuttle sweep (bidirectional), or to print in one direction only (unidirectional).

- **Disable** (default). The printer will print all data in both directions of the shuttle sweep (bidirectional printing). This choice produces higher printing speed.
- **Enable**. The printer will print all data in only one direction of the shuttle sweep (unidirectional printing). Although enabling this feature reduces print speed, it enhances the vertical alignment of dots and produces cleaner, sharper barcodes and text.

### Display Language

This parameter chooses the language that will appear on the LCD: English, German, French, Italian, Spanish, or Portuguese. The factory default is English.

### Accented Char

Selects whether the accented characters are standard or tall. See Figure 23 for an example. Selecting tall will slow print speed and may cause the printer to back up during printing.





Figure 23. Accented Characters

# ADVANCED USER



## PTX Setup Option

Selects the Special Function Control Code for the PTX\_SETUP command and functions.

- **Setup Parse.** Disables or enables the PTX\_SETUP command.
- **Setup SFCC.** Allows you to choose the hex value of the ASCII character you wish to use as the SFCC for the PTX\_SETUP command. Valid hex values are 01-FF. The default value is hex 21, which corresponds to the “!” character.

## Hex Dump Mode

A hex code printout (or hex dump) translates all incoming data to hexadecimal equivalents. A hex dump lists each ASCII data character received from the host computer, together with its corresponding two-digit hexadecimal code. Hex dumps can be used to troubleshoot some types of printer data reception problems. The options include:

- **Disable** (default)
- **Enable**

Figure 28 on page 253. shows a hex dump sample.

## Power-Up State

- **Online** (default). The printer powers up in the online state.
- **Offline.** The printer powers up in the offline state.

**NOTE:** This option is not available in the PCL-II or LG emulation.

## Downloaded Fonts

Allows you to download a substitution table to replace any character in the current character set with a different character in the same font.

- **Char Operations.** Allows you to delete a character from flash, load a character from flash, save a character to flash, and delete a character from RAM.
- **Ld Char at Pwrup.** Allows you to disable or enable loading a character at power up.
- **Set Operations.** Allows you to delete a character set from flash, load a character set from flash, save a character set to flash, and delete a character set from RAM.
- **Ld Set at PwrUp.** Allows you to disable or enable loading a character set at power up.

**NOTE:** This option is not available in the PCL-II or LG emulation.

---

## PMD (Paper Motion Detection) Fault

- **Enable** (default). In the event of a paper jam, an audible alarm beeps, “CLEAR PAPER JAM” appears on the message display, and the printer stops printing.
- **Disable**. You should disable PMD only if special paper requires it.

### CAUTION

**Once PMD is disabled, paper motion is not monitored. If a paper jam occurs, the printer ignores the condition and continues to print, possibly causing damage to the printer.**

## Power Stacker

This parameter allows you to enable or disable the power paper stacker (provided this option is installed).

## Auto Elevator

This parameter exists only on printers with the power paper stacker installed. The power stacker has a sensor which detects paper movement and raises the stacker as the printed paper stack grows. If the printer has been printing for three minutes continually and the sensor has not detected any growth in the paper stack, the stacker raises itself 1/4 inch automatically.

- **Enable** (default). The automatic elevator on the power stacker operates normally.
- **Disable**. The stacker does not raise automatically every three minutes and is entirely dependent on the sensor. Disable is used with extremely high-quality print jobs that take a long time to print.

## Auto Locking

- **Disable** (default). The ENTER key must be locked manually.
- **Enable**. The printer automatically locks the ENTER key five minutes after the last front panel key press.

## File System

- **Overwrite Files**. Allows you to prevent files from being overwritten by disabling the overwrite function.
- **View File List**. Displays the list of files in the file system. Pressing the DOWN key displays the file size.
- **Delete Files**. Displays the list of files in the file system. Pressing the ENTER key deletes the file displayed on the front panel.
- **Flash Avail**. The amount of flash available for the user to save or download files into flash.
- **Optimize&Reboot**. Reclaims flash space from deleted flash files. After pressing ENTER, wait for the printer to reboot.

**NOTE:** When the Optimize&Reboot option is executed, the message, “Optimizing Flash Files” does not display before printer rebooting takes place.

- **Print File List.** Prints a summary of the files stored in flash memory and several statistics on File System usage.

**IMPORTANT** Do not turn the printer off until it has completely rebooted and is either back online or offline.

## Set Sharing

This option allows character sets to be shared between the active LP+ protocol and the active IGP emulation. If CT is installed and active, choosing a character set in the CT activates that character set in the active IGP and LP+ protocols. (These changes will not be visible on the front panel.) If Set Sharing is not selected, only the LP+ will share the CT's character set.

Switching host interfaces from CT to Centronics when the Set Sharing is enabled will cause the LP+ character set to be activated to the same character set of the active IGP, if possible.

In a non-CT system, changing characters sets in LP+ causes the active IGP to change to the same character set if the selected set exists in IGP. If the active IGP has no access to the selected set, no changes are made. Selecting a new character set in the active IGP causes the LP+ to change to the same character set if the selected character set exists in the active LP+ protocol. Not all sets are shared between emulations in the Standard group of character sets. As a result, selecting a set in the Standard group of LP+ or IGP emulation may or may not cause the other emulation to have the same set.

**NOTE:** The Set Sharing front panel option has no effect on the LP+ and CT/LP+ builds. The option only applies to the builds with IGP.

This option is not available in the PCL-II or LG emulation.

## Shuttle Timeout

The amount of time the shuttle continues moving after no data is received. If your host is slow, setting the number to a higher value will prevent the printer from spending time shuttling up and down between data bursts.

## Slow Paper Slew

- **Disable** (default). The paper will slew and stack paper at maximum speed.
- **Enable.** Causes the paper to stack at a slower rate. This ensures that certain forms will stack neatly.

## Alarm

- **On** (default). An audible alarm sounds (3 beeps) when a fault occurs, such as a paper jam.
- **Cont. Beep.** A continuous audible alarm sounds when a fault occurs, which can be stopped by pressing CLEAR.
- **Off.** No audible alarm will sound.



---

## Power Saver Time

The time interval you specify for this parameter sets the amount of idle time before the printer goes into Power Saver mode. When Instant is chosen, the printer goes into Power Saver mode as soon as it is able to stop the shuttle properly. The time allotted to perform this function depends upon the shuttle timeout value which can be set in the menu.

**NOTE:** Power Saver Mode will not be shown on the control panel even though the function still exists. Sending a print job to the printer will turn off Power Saver mode.

## Pwr Save Control

Allows you to enable or disable the Power Save (Energy Star) mode.

- **Enable** (default). Allows you to enable the Power Save (Energy Star) mode.
- **Disable**. Allows you to disable the Power Save (Energy Star) mode.

## Cancel Key

- **Disable** (default)
- **Enable**. The CANCEL key may be used to clear all data in the print buffer without printing any of the data.

## Set Lock Key

Normally, to lock or unlock the printer menu, the UP and DOWN keys are pressed at the same time. The Set Lock Key parameter lets you choose different keys to lock or unlock the printer menu. You may choose almost any group of keys as the new lock and unlock keys. You cannot use the ENTER key or any key combinations which are already used for another function. There is no limit to how many keys you can select.

To set the new lock key, follow these steps:

1. Work your way through the configuration menu until the display reads "Set Lock Key" (follow the menu structure on page 221).
2. Press ENTER. The display reads, "Select a new lock key."
3. Press the combination of keys you want to be the new lock key. Make sure you press all keys selected at the same time.
4. If the selection is valid, the display will read, "Enter the new lock key again." If the selection is invalid, the display will read, "Invalid key selection." Return to step 2 and start over.
5. Press the same combination of keys a second time. If the new lock key combination is entered again correctly, the display will read, "Lock key has been changed." If it was entered incorrectly, the display will read "Verification failed." Start over at step 2.
6. After entering the new lock combination successfully, press the ON LINE key to put the printer back online.

**NOTE:** The new lock combination will remain even if the printer is powered off and back on.

## RBN Low Warn @

This option allows the user to select the Ribbon Life value at which point the printer will declare a ribbon low condition and display the "RIBBON UNDER XX% / Change RBN Soon" warning message. The default is Under 2%. See "RBN Low Action" below for details of how the printer behaves once a ribbon low condition is reached.

The values are Under 2% (default), Under 5%, Under 10%, Under 20%, and Under 30%.

## RBN Low Action

This menu determines how the printer behaves once a ribbon low condition is reached.

- **Warn & Continue** (default). Once a ribbon low condition is reached the printer beeps and displays the "RIBBON UNDER XX% / Change RBN Soon" warning message. Printing will continue without interruption. The warning message can be cleared by pressing the ONLINE/Clear button, however the message will persist again in two minutes. This action will continue until a ribbon out (ribbon life reaches 0%) condition occurs.
- **Warn & Pause**. This setting is similar to the Warn & Continue selection with one exception. When a ribbon low condition is reached the printer will still display the "RIBBON UNDER XX%/Change RBN Soon" warning message, however the printer will stop printing. This is meant to get the user's attention. To resume printing the user must press the ONLINE/Clear key.

**NOTE:** Printing will only stop on the first occurrence of a ribbon low condition. Once the user clears the warning message, subsequent warnings will display the warning message but printing will continue.


## RBN End Action

This menu allows the user to override the normal ribbon low warning and ribbon out conditions.

- **Stop At RBN End** (default). When this factory default option is selected the printer displays a warning message when a ribbon low condition is reached and display a ribbon out fault when ribbon life reaches 0%.
- **Ignore RBN End**. When this menu option is selected it overrides the ribbon low and ribbon out conditions, i.e. no warning or fault messages is displayed and printing continues even after ribbon life reaches 0%. However, once the ribbon life reaches an excess wear condition as indicated by the fault message "EXCESS RBN WEAR / Install New RBN", printing will stop and the user must install a new ribbon before printing can resume.

**NOTE:** The excess ribbon wear is set below the "Lighter -10" Ribbon End Point setting.

# DIAGNOSTICS



## Printer Tests

These tests are used to check the print quality and operation of the printer.

**NOTE:** Your authorized service representative will typically run the tests. They are described in more detail in the *Maintenance Manual*.

- **Shift Recycle.** A sliding alphanumeric pattern which identifies missing or malformed characters, improper vertical alignment, or vertical compression.
- **All E's.** A pattern of all uppercase E's which identifies missing characters, misplaced dots, smeared characters, improper phasing problems, or light/dark character variations.
- **E's + TOF.** A pattern of all E's followed by a form feed to the next page top-of-form, which identifies paper motion or feeding problems.
- **All H's.** A pattern of all uppercase H's used to detect missing characters, misplaced dots, smeared characters, or improper phasing.
- **All Underlines.** An underline pattern useful for identifying hammer bank misalignment.
- **All Black.** A condition where all dot positions are printed, creating a solid black band.
- **Shuttle Slow.** Verifies proper operation by exercising shuttle and ribbon motion at low speed.

- **Shuttle Fast.** Verifies proper operation by exercising shuttle and ribbon motion at fast speed.
- **Shuttle Only.** Exercises only the shuttle at fast speed.
- **Phase Printer.** Checks for wavy print. The initial phase value is set in the factory. Run the test and check the quality. (The phase value prints on the left margin.) If the print looks too wavy, change the Phase Value parameter while the test is running. While the phase printer test runs, press the DOWN key. To change the value, press the PREV or NEXT key until the desired value displays and then press ENTER.
- **Paperout Adj..** Verifies the current Paper Out Dots setting, which determines where the last line of text will print when there is a paper out condition. Setting this parameter correctly prevents printing on the platen.
- **Burnin Test.** Reserved for factory use.
- **Print Error Log.** Prints the current log of errors. Most non-routine faults (ribbon stall, voltage faults) are stored in the error log.
- **Clear Error Log.** Clears entries in the error log.
- **Adapter Test.** Prints the Ethernet adapter statistics stored on the Ethernet adapter (if present).
- **Ethernet Test.** Prints the Ethernet statistics stored on the Ethernet (if present).
- **Acoustics.** A particular test pattern that is used to measure acoustics.
- **Demo.** Demonstration of various print attributes.
- **Dice 5.** Pattern used to measure print density.
- **Prnt Ribbon Log.** Prints log of ribbons that have been used in the printer.

### Test Width

Set this parameter to run the self-tests at full width or 80 columns.

### Paper Out Dots

**CAUTION** Only authorized service representatives should set this parameter.

This parameter is used to adjust the paper out distance from the perforation; you can specify where the last line on the page will print when there is a paper out condition. Setting this parameter correctly prevents printing on the platen.

### System Memory

Displays the amount of RAM installed.

---

## Print Statistics


You can view various printer statistics and refer to them for preventive maintenance purposes. Printer statistics accumulate continuously; they do not reset when you turn off the printer. All of the printer statistics are set to zero at the factory after burn-in testing.

- **On.** The cumulative time in hours the printer has been powered on. The range is 0 to 30,000 hours.
- **Print.** The cumulative time in hours the printer has actually been printing. The range is 0 to 30,000 hours.
- **Print Strokes.** The cumulative number of back-and-forth shuttle strokes the printer has printed during normal printer operation. The range is 0 to 2,147,483,647 shuttle strokes.
- **Print Lines.** The cumulative number of lines the printer has printed. The range is 0 to 2,147,483,647 print lines.
- **11 inch Pages.** The cumulative number of pages the printer has printed. The range in print pages is 0 to 2,147,483,647 total inches of paper movement divided by 11.

# DATE

\* = Factory Default

<sup>1</sup> Appears only if the real time clock option is installed.



## Hour

This option allows you to set the hour. The factory default is 00 and the range is from 00 to 23 hours.

## Minute

This option allows you to set the minutes. The factory default is 00 and the range is from 00 to 59 minutes.

## Year

This option allows you to set the year. The factory default is 2099 and the range is from the year 2000 to 2099.

## Month

This option allows you to set the month. The factory default is Jan and the range is from Jan to Dec.


## Day

This option allows you to set the day. The factory default is 01 and the range is from 01 to 31 days.

---

# Printer MGMT

---



## PNE Port

This menu selects which port the printer expects PNE to connect to, via Ethernet or Serial. The factory default is Ethernet.

## Mgmt Protocol

Since PXML and UCP management protocols share the same Ethernet Port, only one can be active at a time. This menu selects the active Management Protocol Interface, either PXML or UCP. The factory default is UCP.

## PNE Port Number

This menu selects the port number the printer expects the PNE to connect through. The factory default is 3001 and the range is from 1023 to 65535.

## PNE Port Timeout

If the PNE has not communicated to the printer within a timeout period, the PNE session closes. The factory default is 100 seconds. The range is from 1 to 255 seconds.

## Status Port Num

This menu selects the port number the printer sends the emulation status. The factory default is 3001 and the range is from 1023 to 65535.

## Mgmt Port Number

This menu selects the port number the printer expects the PXML or UCP to connect through. The factory default is 3007 and the range is from 1023 to 65535.





---

# 5

# *Interfaces*

---

## Overview

---

This chapter describes the host interfaces provided with the printer. The printer interface is the point where the data line from the host computer plugs into the printer. The interface processes all communications signals and data to and from the host computer. Plus, with the Auto Switching feature, you can configure the printer to accept several interfaces at the same time (see “Auto Switching Submenu” on page 73).

### **IMPORTANT**

**To comply with Electromagnetic Compatibility (EMC) regulatory requirements all electrical signal interface cables connected to this printer must be of a minimal quality level, be of the correct length, and be properly installed.**

**The RS-232 port and parallel port interface cables must meet the following specifications:**

- **The cable design must be double shielded with a copper braid over an aluminum mylar foil and not just a conductive foil spiral wrapped around a drain wire.**
- **The shield must terminate coaxially (360 degrees) to a metal connector housing and not be terminated by just a simple wire lead.**
- **The cable length, including connectors, must be 3 meters or less.**
- **The cable connector anchor screws must be securely seated into the printer receptor hardware.**

**For reference purposes only, two specific Centronics parallel port cables that have been tested and found to comply with these requirements are Belkin® part number F2A046-10 and Primelogic® part number PLU 2823224. Other electrically equivalent cables are acceptable.**

This chapter describes the interfaces provided with the printer.

### **Standard Host Interfaces:**

- Centronics parallel
- IEEE 1284 parallel bidirectional
- High Speed Serial Port (RS-232/RS-422)

**NOTE:** RS-422 is optional.

**Optional Host Interfaces:**

- Coax / Twinax
- Dataproducts parallel
- Ethernet 10/100BaseT

In addition to descriptions for the multi-line interfaces, this chapter also provides instructions for configuration of terminating resistors for the parallel interfaces.

## Dataproducts Parallel Interface

**Table 8. Dataproducts Parallel Interface Connector Pin Assignments  
(with a 50-pin AMP HDH-20 Data Cable Connector)**

Input Signals		Output Signals		Miscellaneous	
Signal	Pin	Signal	Pin	Signal	Pin
DATA LINE 1	19	READY	22	CABLE VERIFY	45, 46
Return	3	Return	6		
DATA LINE 2	20	ONLINE	21	GROUND	39
Return	4	Return	5		
DATA LINE 3	1	DEMAND/DATA REQ.	23		
Return	2	Return	7		
DATA LINE 4	41	PARITY ERROR	27		
Return	40		11		
DATA LINE 5	34				
Return	18				
DATA LINE 6	43				
Return	42				
DATA LINE 7	36				
Return	35				
DATA LINE 8	28				
Return	44				
DATA STROBE	38				
Return	37				
PAPER INSTRUCTION	30				
Return	14				
BUFFER CLEAR	31				
Return	15				

NOTE: Pins not listed are not connected.

The length of the data cable from the host computer to the printer must not exceed 40 feet (12 meters).

## Dataproducts Parallel Interface Signals

---

**Data Lines 1 through 8.** Provides eight standard or inverted levels from the host that specify character data, plot data, or a control code. Data Line 8 allows access to the extended ASCII character set. You can enable or disable this line via the Data Bit 8 parameter on the Dataproducts submenu (see page 79).

**Data Strobe.** Carries a high true pulse from the host when data is ready. The data strobe remains high until the Data Request line goes false. The active edge of the strobe signal can be configured as leading, middle (default), or trailing.

**Paper Instruction (PI).** Carries a DVFU signal from the host with the same timing and polarity as the data lines.

**Ready.** Carries a high true signal from the printer when AC power and DC voltages are present, paper is loaded properly, and the printer is not in a check condition.

**Online.** Carries a high true signal from the printer when the Ready Line is true and the ON LINE key on the control panel has been pressed. When the printer is in online mode, it may accept data from the host.

**Demand/Data Request.** Carries a high true signal from the printer when the printer is ready to accept character data from the host. This signal changes to false shortly after the leading edge of the data strobe signal.

**Cable Verify.** Two pins on the interface connector are jumpered together to allow the user to verify proper installation of the interface connector.

**Buffer Clear.** A high true level from the host to indicate the printer should perform a reboot.

**Parity Error.** Always carries a low false signal from the printer indicating there is no parity error.

## Centronics Parallel Interface

**Table 9. Centronics Interface Connector Pin Assignments**

Input Signals		Output Signals		Miscellaneous	
Signal	Pin	Signal	Pin	Signal	Pin
DATA LINE 1	2	ACKNOWLEDGE	10	CHASSIS GROUND	17
Return	20	Return	28		
DATA LINE 2	3	ONLINE	13	GROUND	30
Return	21	Return	28		
DATA LINE 3	4	FAULT	32	Spares	14
Return	22	Return	29		
DATA LINE 4	5	PAPER EMPTY	12	No Connection	34,35, 36
Return	23	Return	28		
DATA LINE 5	6	BUSY	11	+5 Volts	18
Return	24	Return	29		
DATA LINE 6	7				
Return	25				
DATA LINE 7	8				
Return	26				
DATA LINE 8	9				
Return	27				
DATA STROBE	1				
Return	19				
PAPER INSTRUCTION	15				
Return	29				
PRIME	31				
Return	30				

The length of the data cable from the host computer to the printer must not exceed 15 feet (5 meters).

## Centronics Parallel Interface Signals

---

**Data Lines 1 through 8.** Provides eight standard or inverted levels from the host that specify character data, plot data, or a control code. Data Line 8 allows access to the extended ASCII character set. You may enable or disable this line via the Data Bit 8 parameter on the Centronics submenu (see page 76).

**Data Strobe.** Carries a low true, 100 ns minimum pulse from the host that clocks data into the printer.

**Acknowledge.** A low true pulse from the printer indicating the character or function code has been received and the printer is ready for the next data transfer.

**Online.** A high true level from the printer to indicate the printer is ready for data transfer and the ON LINE key on the control panel has been activated. When the printer is in online mode, it may accept data from the host.

**Paper Empty (PE).** A high true level from the printer to indicate the printer is in a paper empty or paper jam fault.

**Busy.** A high true level from the printer to indicate the printer cannot receive data.

**Prime.** A high true level from the host to indicate the printer should perform a warm start (printer is reset to the power-up configuration values).

**Paper Instruction (PI).** Carries a CVFU signal from the host with the same timing and polarity as the data line.

**Fault.** A low true level from the printer indicates a printer fault.

## IEEE 1284 Parallel Interface

---

The 1284 supports three operating modes, which are determined by negotiation between the printer and the host.

### Compatibility Mode

---

This mode provides compatibility with Centronics-like host I/O (see Table 10). Data is transferred from the host to the printer in 8-bit bytes over the data lines.

Compatibility Mode can be combined with Nibble and Byte Modes to provide bidirectional communication.

### Nibble Mode

---

Eight bits equals one byte. When a byte of data is sent to the printer, the eight bits are sent over eight data lines.

Some devices cannot send data over their eight data lines. To bypass this, the 1284 permits data to be sent as half a byte over four status lines. (Half a byte equals one nibble.) Two sequential four-bit nibbles are sent over the lines.

Data is transferred from printer to host in four-bit nibbles over the status lines, and the host controls the transmission.

### Byte Mode

---

The printer and host send data to each other along eight data lines (one bit per line).

If bidirectional communication is supported by the printer and the host, the host will take control of the data transfer.

## Signals

Table 10 lists each of the signals associated with the corresponding pins on the 1284 interface. Descriptions of the signals follow.

**Table 10. 1284 Signals**

Pin	Source of Data	Type of Mode		
		Compatible	Nibble	Byte
1	Host	nStrobe	HostClk	Host/Clk
2	Host/Printer	Data 1 (LSB)		
3	Host/Printer	Data 2		
4	Host/Printer	Data 3		
5	Host/Printer	Data 4		
6	Host/Printer	Data 5		
7	Host/Printer	Data 6		
8	Host/Printer	Data 7		
9	Host/Printer	Data 8 (MSB)		
10	Printer	nAck	PtrClk	PtrClk
11	Printer	Busy	PtrBusy	PtrBusy
12	Printer	PError	AckDataReq	AckDataReq
13	Printer	Select	Xflag	Xflag
14	Host	nAutoFd	Host Busy	HostAck
15		Not Defined		
16		Logic Grid		
17		Chassis Grid		
18	Printer	Peripheral Logic High		
19		Signal Ground (nStrobe)		
20		Signal Ground (Data 1)		
21		Signal Ground (Data 2)		
22		Signal Ground (Data 3)		
23		Signal Ground (Data 4)		
24		Signal Ground (Data 5)		
25		Signal Ground (Data 6)		

Table 10. 1284 Signals (continued)

Pin	Source of Data	Type of Mode		
		Compatible	Nibble	Byte
26		Signal Ground (Data 7)		
27		Signal Ground (Data 8)		
28		Signal Ground (PErrror, Select, nAck)		
29		Signal Ground (Busy, nFault)		
30		Signal Ground (nAutoFd, nSelectIn, nInit)		
31	Host	nInit		
32	Printer	NFault	nDataAvail	aDataAvail
33		Not Defined		
34		Not Defined		
35		Not Defined		
36	Host	nSelectIn	1284 Active	1284 Active

**NOTE:** The length of the data cable from the host computer to the printer should not exceed 32 feet (10 meters).

**Host Clock / nWrite.** Driven by host. Data transferred from host to printer. When printer sends data, two types are available. If Nibble mode, signal is set high. If Byte mode, signal is set low.

**Data 1 through Data 8.** These pins are host-driven in Compatibility mode and bidirectional in Byte mode. They are not used in Nibble mode. Data 1 is the least significant bit; Data 8 is the most significant bit.

**Printer Clock / Peripheral Clock / Interrupt.** Driven by the printer. A signal from the printer indicating the character or function code has been received and the printer is ready for the next data transfer.

**Printer Busy / Peripheral Acknowledge / nWait.** Driven by the printer. Indicates the printer cannot receive data. (Data bits 4 and 8 in Nibble mode.)

**Acknowledge Data Request / nAcknowledge Reverse.** Driven by the printer. Indicates the printer is in a fault condition. (Data bits 3 and 7 in Nibble mode.)

**Xflag.** Driven by the printer. A high true level indicating the printer is ready for data transfer and the printer is on line. (Data bits 2 and 6 in Nibble mode.)

**Host Busy / Host Acknowledge / NDStrobe.** Driven by the host. Activates auto-line feed mode.

**Peripheral Logic High.** Driven by the printer. When the line is high, the printer indicates all of its signals are in a valid state. When the line is low, the printer indicates its power is off or its signals are in an invalid state.

**nReverse Request.** Driven by the host. Resets the interface and forces a return to Compatibility mode idle phase.



**nData Available / nPeripheral Request.** Driven by the printer. Indicates the printer has encountered an error. (Data bits 1 and 5 in Nibble mode.)

**1284 Active / nAstrobe.** Driven by the host. A peripheral device is selected.

**Host Logic High**—Driven by the host. When set to high, the host indicates all of its signals are in a valid state. When set to low, the host indicates its power is off or its signals are in an invalid state.

**nInit** —Resets init interface from the host.

## Terminating Resistor Configurations

### V5 Controller Board

The factory equips the printer with several resistors that are used for parallel interface configurations and are suitable for most applications. These 470 ohm pull-up and 1K ohm pull-down terminating resistors are located at RP1 and RP2, shown in Figure 24.

If the values of these terminating resistors are not compatible with the particular interface driver requirements of your host computer, you may need to install resistors with different pull-up and pull-down values.




Figure 24. Resistor Locations, V5 Controller Board

The shipping kit for this printer includes 220 ohm pull-up and 330 ohm pull-down alternate terminating resistors. If you install the 220 ohm pull-up resistor, you must also install the 330 ohm pull-down resistor. Table 11 lists the three terminating resistor configurations you can install:

**Table 11. Terminating Resistor Configurations**

<b>Configuration</b>	<b>Pull-Down (RP1)</b>	<b>Pull-Up (RP2)</b>
Factory Default	1K ohm	470 ohm
Alternate 1	330 ohm	220 ohm
Alternate 2	none	1K ohm

### V6 Controller Board

For parallel interface configurations, the printer is equipped with 470 Ohm and 1K Ohm terminating resistors on the controller board. These are suitable for most applications. See Figure 25.

If the standard terminating resistor pack is not compatible with the particular interface driver requirements of the host computer, other RP1 and RP2 values may be required. 220 Ohm and 330 Ohm alternate terminating resistors are provided with the printer. If you install the 220 Ohm resistor, you must also install the 330 Ohm resistor. Possible terminating resistor combinations are shown below.

Configuration	RP1	RP2
Factory Default	470 Ohm	1K Ohm
Alternate	220 Ohm	330 Ohm




Figure 25. Terminating Resistors, V6 Controller Board

### Removal And Installation

The procedure for removing and installing terminating resistors is provided in your *Maintenance Manual*.

**CAUTION** This is an involved maintenance procedure. To avoid damage to the equipment, only a trained technician should perform this procedure.

## RS-232 And RS-422 Serial Interfaces

**NOTE:** The RS-232 and RS-422 serial interface circuit characteristics are compatible with the Electronic Industry Association Specifications EIA-232-E and EIA-422-B.

The RS-232 and RS-422 serial interfaces enable the printer to operate with bit serial devices that are compatible with an RS-232 controller. The input serial data transfer rate (in baud) is selectable from the printer's control panel. Baud rates of 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, and 115200 baud rates are available.

**NOTE:** If you select a baud rate that is greater than 19200, you may need to use RS-422 to prevent data loss.

The length of the data cable from the host computer to the printer must not exceed 50 feet (15 meters) for RS-232 or 4000 feet (1220 meters) for RS-422. (A copper conductor, twisted-pair telephone cable with a shunt capacitance of 16 pF/foot [52.5 pF/meter] terminated in a 100 ohm resistive load must be used for the RS-422.)

### RS-232

**Table 12. Standard 500, 1000, 1500 lpm Models  
RS-232 Serial Interface Connector Pin Assignments**

Input Signals		Output Signals		Miscellaneous	
Signal	Pin	Signal	Pin	Signal	Pin
Receive Data (RXD)	3	Transmit Status & Control Data (TXD)	2	Chassis Ground	1
Clear To Send (CTS)	5	Request To Send (RTS)	4	Signal Ground	7
Data Set Ready (DSR)	6	Data Terminal Ready (DTR)	20		
Data Carrier Detect (DCD)	8				

**Table 13. RS-232 Serial Interface Connector Pin Assignments**

Input Signals		Output Signals		Miscellaneous	
Signal	Pin	Signal	Pin	Signal	Pin
Receive Data (RXD)	2	Transmit Status & Control Data (TXD)	3	Chassis/Signal Ground	5
Clear To Send (CTS)	8	Request To Send (RTS)	7		
Data Set Ready (DSR)	6	Data Terminal Ready (DTR)	4		
Data Carrier Detect (DCD)	1				

**Receive Data (RXD).** Serial data stream to the printer.

**Transmit Data (TXD).** Serial data stream from the printer for transmitting status and control information to the host. Subject to protocol selection.

**Request To Send (RTS).** Control signal from the printer. Subject to configuration.

**Clear To Send (CTS).** Status signal to the printer indicating the host is ready to receive data/status signals from the printer.

**Data Set Ready (DSR).** Status signal to the printer indicating the host is in a ready condition.

**Data Carrier Detect (DCD).** Status signal to the printer. The ON condition is required for the printer to receive data.

**Data Terminal Ready (DTR).** Control signal from the printer. Subject to configuration.

## RS-422

**Table 14. PSA3 RS-422 Serial Interface Connector Pin Assignments**

Input Signals		Output Signals		Miscellaneous	
Signal	Pin	Signal	Pin	Signal	Pin
- Receive Data (-RXD)	1	- Transmit Data (-TXD)	3	Chassis/Signal Ground	5
+ Receive Data (+RXD)	6	+ Transmit Data (+TXD)	8		

**+RXD, -RXD.** Serial data stream differentially received by printer.

**+TXD, -TXD.** Differentially driven serial data stream for transmitting status and control information to the host. Subject to protocol selection.

**NOTE:**  $\pm$ RXD and  $\pm$ TXD form signal and return paths of a differential line signal.



---

# 6

## *Reprogramming the Security Key*

---

### **Reprogramming The Security Key**

---


The security key on the PSA3 controller board can be reprogrammed with a Software Program Exchange (SPX) module. The SPX is an intelligent module that plugs into the debug port on the back of printers equipped with the PSA3 "Hurricane" controller board. The SPX is used only once; it automatically overwrites itself after successfully reprogramming a security key. This allows the end user or a service technician to enable features such as new emulations without having to remove covers and install a new security key on the controller board.

The SPX is used at power-up only and is not left in the printer during normal operation. Because it is a single-use disposable item the user is not required to return it to the vendor or manufacturer.

#### **How To Program The Security Key**

---

1. Power off the printer.
2. On cabinet models, open the rear door. On pedestal models, refer to Figure 26 to locate the debug port at the rear of the printer.
3. Insert the SPX into the debug port as shown.



**Figure 26. Inserting The SPX into the Debug Port**

4. Power on the printer. The printer will begin its boot-up sequence.
5. When the printer detects a valid SPX, the control panel displays: “NEW SPX DETECTED  
PRESS ENTER”

**NOTE:** If an error message displays, find the message in the Message List in Chapter 7 and follow the troubleshooting instructions.

6. Press the **ENTER** key to activate the reprogramming sequence. The display will read:  
“PROGRAMMING. PLEASE WAIT.”
7. When the security key is reprogrammed, the display will read:  
“REMOVE USED SPX  
THEN PRESS ENTER”
8. Remove the SPX from the debug port at the rear of the printer.
9. Press the **ENTER** key. The printer will reboot itself and you may resume normal printing.
10. You may need to download a new program file to use the new feature.
11. You may need to set additional menu parameters for any new features that have been added or enabled.



---

# 7

## *Troubleshooting*

---

### **Cleaning Requirements**

---

Clean the printer every six months or after every 1000 hours of operation, whichever occurs first. If the printer is located in a dusty area or is used for heavy duty printing, clean it more often.

**WARNING**

**Disconnect the power source before cleaning the printer.**

**Vor dem Säubern des Druckers ist die Netzverbindung zu unterbrechen.**

**Débranchez l'alimentation avant de nettoyer l'imprimante.**

**Desconecte la fuente de energía antes de limpiar la impresora.**

**Staccare la fonte di energia prima della pulitura della stampante.**


### **Exterior Cleaning**

---

Clean the outside of the cabinet with a soft, lint-free cloth and mild detergent soap. (Dishwashing liquid works well.) Do not use abrasive powders or chemical solvents. Clean the windows with plain water or mild window cleaner. Always apply the cleaning solution to the cloth; never pour cleaning solution directly onto the printer.

## Interior Cleaning

Over time, particles of paper and ink accumulate inside the printer. This is normal. Paper dust and ink build-up must be periodically removed to avoid degraded print quality. Most paper dust accumulates around the ends of the platen and ribbon path.



**Figure 27. Interior Printer Components**

To clean the interior of the printer perform the following steps.

1. Power off the printer and unplug the printer power cord.
2. Open the printer cover.
3. Fully raise the platen lever.
4. Unload the paper.
5. Unlatch the ribbon and ribbon spool and carefully lift them off the hubs.

**NOTE:** If there are ink stained fingerprints on the ribbon barcode (located on the ribbon spool), wipe it clean with a soft cloth or towelette moistened with alcohol.

6. Lift the ribbon out of the ribbon path.
7. Brush the paper dust and ribbon lint off the tractors, shuttle cover assembly, base casting, and ribbon guides with a soft-bristled, non-metallic brush (such as a toothbrush). Vacuum up the residue.

**CAUTION** Vacuum carefully around the hammer bank and surrounding area to avoid damage. To avoid corrosion damage, use only alcohol when cleaning the printer mechanical elements. Solutions used to clean mechanical elements must contain no water.

8. Wipe the splined shaft with a soft cloth.
9. Check the ribbon mask and hammer bank cover for bits of torn paper or ribbon lint.
10. Remove dust and ink from the platen using a soft cloth lightly moistened with anhydrous alcohol. (The platen is the thick silver bar behind the hammer bank cover that rotates when the platen lever is rotated.)

**CAUTION** When cleaning the platen, be very careful not to get any alcohol in the hammer bank, because alcohol will cause severe damage to the hammer bank. Only a trained service technician should clean the shuttle assembly.

11. Clean the ribbon guides by wiping the medal guideposts and area between them with a soft cloth or towelette moistened with alcohol.
12. Brush and vacuum the accumulated dust or residue inside the lower cabinet.
13. Wipe the lower cabinet interior with a clean, lint-free cloth dampened (not wet) with water and mild detergent or window cleaning solution. Dry the lower cabinet interior by wiping it down with a clean, lint-free cloth.
14. Install the ribbon and load paper.

## Diagnosing Problems

---

This section is designed to help you fix problems which may arise with normal printer operation.

### Bar Code Verification

---

The most important consideration when printing a bar code is to ensure that the bar code will be scanned properly. Incorporating a bar code quality procedure in the printing process is the best way to ensure that bar codes are being printed correctly. A properly implemented verification procedure will increase overall bar code quality, reduce waste from misprinted bar codes, and achieve high first-time read rates. A high first-time read rate is an increasingly important factor in newer, more efficient systems where manually entered data is not acceptable as a backup function. Verification also minimizes the costs of returned products due to poor reading or unaccountable bar codes.

RJS designs and manufactures the world's most complete line of bar code verification products, including their portable Inspector and Laser Inspector models, On-Line Inspector and AutoScan II series. For more information on RJS bar code verifiers, visit their web site at [www.rjs1.com](http://www.rjs1.com).

## Printing A Hex Dump

A hex code printout (or hex dump) is a translation of all host interface data to its hexadecimal equivalent, listing all ASCII character data received from the host computer with their corresponding two-digit hexadecimal codes. Hex dumps are used to troubleshoot printer data reception problems.

Printable characters print as the assigned symbol; nonprintable characters are indicated by a period (.).

Figure 28 shows an example of a hex dump.

!"#\$%&'()*+,-./	20	21	22	23	24	25	26	27	28	29	2A	2B	2C	2D	2E	2F
0123456789:;<=>?	30	31	32	33	34	35	36	37	38	39	3A	3B	3C	3D	3E	3F
@ABCDEFGHIJKLMNO	40	41	42	43	44	45	46	47	48	49	4A	4B	4C	4D	4E	4F
PQRSTUVWXYZ[\]^_`	50	51	52	53	54	55	56	57	58	59	5A	5B	5C	5D	5E	5F
abcdefghijklmnopqrstuvwxyz~	60	61	62	63	64	65	66	67	68	69	6A	6B	6C	6D	6E	6F
!"#\$%&'()*+,-./0	70	71	72	73	74	75	76	77	78	79	7A	7B	7C	7D	7E	7F
123456789:;<=>@	80	81	82	83	84	85	86	87	88	89	8A	8B	8C	8D	8E	8F
ABCDEFGHIJKLMN	90	91	92	93	94	95	96	97	98	99	9A	9B	9C	9D	9E	9F
OPQRSTUVWXYZ[\]^_`	00	01	02	03	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F
abcdefghijklmnopqrstuvwxyz~	10	11	12	13	14	15	16	17	18	19	1A	1B	1C	1D	1E	1F
!"#\$%&'()*+,-./0	20	21	22	23	24	25	26	27	28	29	2A	2B	2C	2D	2E	2F
123456789:;<=>@	30	31	32	33	34	35	36	37	38	39	3A	3B	3C	3D	3E	3F
ABCDEFGHIJKLMN	40	41	42	43	44	45	46	47	48	49	4A	4B	4C	4D	4E	4F
OPQRSTUVWXYZ[\]^_`	50	51	52	53	54	55	56	57	58	59	5A	5B	5C	5D	5E	5F
abcdefghijklmnopqrstuvwxyz~	60	61	62	63	64	65	66	67	68	69	6A	6B	6C	6D	6E	6F
!"#\$%&'()*+,-./0	70	71	72	73	74	75	76	77	78	79	7A	7B	7C	7D	7E	7F
123456789:;<=>@	80	81	82	83	84	85	86	87	88	89	8A	8B	8C	8D	8E	8F
ABCDEFGHIJKLMN	90	91	92	93	94	95	96	97	98	99	9A	9B	9C	9D	9E	9F
OPQRSTUVWXYZ[\]^_`	00	01	02	03	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F
abcdefghijklmnopqrstuvwxyz~	10	11	12	13	14	15	16	17	18	19	1A	1B	1C	1D	1E	1F
!"#\$%&'()*+,-./0	20	21	22	23	24	25	26	27	28	29	2A	2B	2C	2D	2E	2F
123456789:;<=>@	30	31	32	33	34	35	36	37	38	39	3A	3B	3C	3D	3E	3F
ABCDEFGHIJKLMN	40	41	42	43	44	45	46	47	48	49	4A	4B	4C	4D	4E	4F
OPQRSTUVWXYZ[\]^_`	50	51	52	53	54	55	56	57	58	59	5A	5B	5C	5D	5E	5F
abcdefghijklmnopqrstuvwxyz~	60	61	62	63	64	65	66	67	68	69	6A	6B	6C	6D	6E	6F
!"#\$%&'()*+,-./0	70	71	72	73	74	75	76	77	78	79	7A	7B	7C	7D	7E	7F
123456789:;<=>@	80	81	82	83	84	85	86	87	88	89	8A	8B	8C	8D	8E	8F
ABCDEFGHIJKLMN	90	91	92	93	94	95	96	97	98	99	9A	9B	9C	9D	9E	9F
OPQRSTUVWXYZ[\]^_`	00	01	02	03	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F
abcdefghijklmnopqrstuvwxyz~	10	11	12	13	14	15	16	17	18	19	1A	1B	1C	1D	1E	1F
!"#\$%&'()*+,-./0	20	21	22	23	24	25	26	27	28	29	2A	2B	2C	2D	2E	2F
123456789:;<=>@	30	31	32	33	34	35	36	37	38	39	3A	3B	3C	3D	3E	3F
ABCDEFGHIJKLMN	40	41	42	43	44	45	46	47	48	49	4A	4B	4C	4D	4E	4F
OPQRSTUVWXYZ[\]^_`	50	51	52	53	54	55	56	57	58	59	5A	5B	5C	5D	5E	5F
abcdefghijklmnopqrstuvwxyz~	60	61	62	63	64	65	66	67	68	69	6A	6B	6C	6D	6E	6F
!"#\$%&'()*+,-./0	70	71	72	73	74	75	76	77	78	79	7A	7B	7C	7D	7E	7F
123456789:;<=>@	80	81	82	83	84	85	86	87	88	89	8A	8B	8C	8D	8E	8F
ABCDEFGHIJKLMN	90	91	92	93	94	95	96	97	98	99	9A	9B	9C	9D	9E	9F
OPQRSTUVWXYZ[\]^_`	00	01	02	03	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F
abcdefghijklmnopqrstuvwxyz~	10	11	12	13	14	15	16	17	18	19	1A	1B	1C	1D	1E	1F

Figure 28. Hex Dump Sample

## Fault Messages

If a fault condition occurs in the printer, the status indicator on the control panel flashes on and off, and the message display indicates the specific fault. Fault messages are summarized in Table 15.

Displayed faults fall into one of two categories:

- Operator correctable
- Field service required

For the operator-correctable faults, follow the suggested solution in Table 15. After correcting the displayed fault, press the CLEAR key to clear the error message and status indicator and resume printing. If the fault message reappears, contact your authorized service representative.

**NOTE:** The *Maintenance Manual* provides more detailed information and procedures for resolving fault conditions. However, many of the procedures described there must be performed only by your authorized service representative.

### Fault Messages Requiring Field Service Attention

If a fault is not correctable by the operator, the fault message is followed by an asterisk (\*). This usually indicates that an authorized service representative is needed. You may try two steps to clear the fault before calling your authorized service representative:

1. Set the printer power switch to O (Off), wait 15 seconds, then turn the printer on again. Run your print job again. If the message does not appear, it was a false indication and no further attention is required.
2. If the message reappears, press the CLEAR key. If the message disappears, it was a false indication and no further attention is required. If the message reappears, call your authorized service representative.

**Table 15. LCD Message Troubleshooting Table**

Displayed Message	Can User Correct?	Explanation	Solution
06 HOST REQUEST	Yes	Host attention message.	The host computer or printer controller requires attention.
08 HOLD PRINT TIMEOUT	Yes	Printer was offline more than 10 minutes, and the "Intervention Required" parameter is set to "Send to Host."	Press ON LINE to put printer in online state.
8.5V PWR FAIL*	No	8.5 Volt power failed. Internal power failure.	Contact your authorized service representative. <sup>1</sup>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
15 COMM CHECK	Yes	A message that appears in the CT emulation meaning the line is not active on a twinax interface.	Check cable connection.
15V CTL FAIL*	No	Controller voltage failure.	Contact your authorized service representative. <sup>1</sup>
22 INVALID ADDR	Yes	Unit address not recognized by printer. (Twinax interface)	Ensure that printer address matches host setting.
23.5V CTL FAIL*	No	23.5 Volt Controller failed: a voltage failure on the controller board.	Contact your authorized service representative. <sup>1</sup>
31 PAPER OUT TIMEOUT	Yes	A timeout message is sent to the host if paper is not loaded 10 minutes after CLEAR was pressed to clear the paper out fault.	Load paper and run a print test. If the message reappears, contact your authorized service representative. <sup>1</sup>
32 PAPER JAM TIMEOUT	Yes	A timeout message is sent to the host if no paper motion has occurred for 10 minutes after CLEAR was pressed to clear the jam fault.	Clear paper jam and reload paper.
33 PLATEN OPEN TIMEOUT	Yes	The forms thickness lever has been open for at least one minute.	Load paper, close the forms thickness lever, and press CLEAR.
34 RIBBON STALL TIMEOUT	Yes	In the CT emulation with a coax interface, the ribbon has not moved for 10 minutes after CLEAR was pressed to clear the ribbon drive fault.	Reload the ribbon.
48V CIRCUIT* See User Manual	No	Either the power supply is not generating a proper 48 Volts or the controller board is not detecting a 48 Volt output from the power supply board.	Contact your authorized service representative. <sup>1</sup>
48V PWR FAIL*	No	Internal power failure.	Contact your authorized service representative. <sup>1</sup>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
426 BC READ ERR See User Manual	Yes	Bar code read error: The printer does not detect the presence of the ribbon bar code sensor.	<ol style="list-style-type: none"> <li>1. Power down the printer.</li> <li>2. Remove the ribbon and wipe the two lenses of the ribbon bar code sensor with a lint-free cloth or cotton swab.</li> <li>3. Install the ribbon and power on the printer. If the message reappears, replace the ribbon.</li> </ol>
733 DP FIFO Busy*	Yes	There is a timing problem in the Engine Controller firmware.	<ol style="list-style-type: none"> <li>1. Cycle power. Run the print job again. If the message reappears, download the emulation software again.</li> <li>2. Cycle power. Run the print job again. If the message reappears, contact your authorized service representative.<sup>1</sup></li> </ol>
A TO D OVERUN*	No	Analog to Digital Overrun. The analog-to-digital converter overflowed.	Contact your authorized service representative. <sup>1</sup>
ACCESS NULL PTR*	No	Access Null Pointer: The processor tried to access a pointer that contains nothing (null).	Contact your authorized service representative. <sup>1</sup>
ACTIVATE LOST	No	The printer detects a twinax protocol communication error and reports the error.	Contact your authorized service representative. <sup>1</sup>
B00 STATUS: SDRAM DETECTION 166MHZ	No	Status message: the printer has begun its boot-up routines and is checking for the presence of SDRAM.	No action required.
B01 STATUS: 8245 SDRAM TEST 32MB	No	Status message: printer boot-up routines are testing SDRAM.	No action required.
B10 ERROR: NO DRAM DETECTED*	No	SDRAM DIMM may not be properly installed. Boot-up routines did not detect the presence of the SDRAM DIMM.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>



Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
B11 ERROR: RAM TEST FAILED*	No	SDRAM failed the boot initialization test. SDRAM DIMM may not be properly installed.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B12 ERROR: PROGRAM MISSING*	Yes	The printer does not see a program in flash memory.	There is no program in printer memory. Download an emulation.
B13 ERROR: NOT COMPATIBLE*	No	Attempting to download a program that is not compatible with the printer.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B19 ERROR: DC RETURNED*	No	The message indicates an incorrectly assembled and tested machine.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B20 STATUS :00% DOWNLOAD MODE	No	Status message informing the operator that software is being downloaded. Percentage figure indicates approximate amount loaded into the printer.	No action is required.
B21 STATUS: PRINTER RESET	No	Status message informing the operator that the printer is undergoing a system reset.	No action is required.
B22 ERROR: DECOMPRESS SIZE*	No	FLASH memory has not passed boot initialization tests.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B23 ERROR: DECOMPRESS CKSUM*	No	FLASH memory has not passed boot initialization tests.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B30 STATUS: INITIALIZING...	N/A	Status message: the printer is running its initialization routines after startup and successful memory tests.	No action is required.

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
B35 STATUS: WAITING FOR EC STATUS	N/A	Status message: the DC on the controller board is waiting for communication with the EC. If this message does not clear within a few seconds there is an electrical or electronic problem on the controller board.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B40 ERROR: SDRAM EEPROM CKSUM BAD*	No	Flash memory has not passed boot initialization tests.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B41 ERROR: DIM MEMORY NOT SDRAM*	No	The DRAM DIMM installed on the controller board is not Synchronous DRAM (SDRAM).	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B42 ERROR: SDRAM ROWS NOT ALLOWED*	No	Printer boot initialization tests detect incorrect SDRAM.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B43 ERROR: SDRAM TOO MANY BANKS*	No	Printer boot initialization tests detect incorrect SDRAM.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B44 ERROR: SDRAM NOT 64 BITS WIDE*	No	Printer boot initialization tests detect incorrect SDRAM.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B45 ERROR: SDRAM IS WRONG VOLTAGE*	No	Printer boot initialization tests detect incorrect SDRAM.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B46 ERROR: SDRAM HAS MIXED SIZES*	No	Printer boot initialization tests detect incorrect SDRAM.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B47 ERROR: SDRAM LARGER THAN 256M*	No	Printer boot initialization tests detect incorrect SDRAM.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B49 ERROR: SDRAM # LOGICAL BANKS*	No	Printer boot initialization tests detect incorrect SDRAM.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B50 ERROR: SDRAM LOGIC COMB BANKS*	No	SDRAM DIMM is not compatible with the computer. SDRAM DIMM may not be properly installed.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
B51 STATUS: XX% LOADING..	No	Status message: printer boot-up routines are loading printer system software into flash memory and SDRAM.	No action required.
B53 ERROR: 12C NO ARBITRATION	No	There is a problem on the 1 <sup>2</sup> C bus which allows the SDRAM DIMM to communicate with the GPIO or CT interface.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
B54 ERROR: SDA LINE STUCK LOW	No	The SDRAM or a PCI card is shorting out the serial data bus on the controller board.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
BARCODE DAMAGED Reverse Spools	Yes	Barcode detected, but not fully decoded.	If barcode appears damaged, reverse ribbon spools. If barcode label is present and undamaged, clean sensor lens using damp cloth or swab. Check that platen gap may be too tight constricting ribbon motion. Loosen gap if needed.
BARCODE MISSING Install New RBN	Yes	The ribbon sensor does not detect the presence of the ribbon spool, indicating a missing label or a damaged sensor.	If label is missing, install new ribbon. If barcode label is present and undamaged, clean sensor lens using damp cloth or swab.
BC SENSOR ERR See User Manual	Yes	Bar code read error: The printer does not detect the presence of the ribbon bar code sensor.	<ol style="list-style-type: none"> <li>1. Power down the printer. Remove the ribbon and wipe the two lenses of the ribbon bar code sensor with a lint-free cloth or cotton swab.</li> <li>2. Install the ribbon and power on the printer. If the message appears again, replace the ribbon.</li> </ol>
BUFFER OVERRUN	Yes	The print buffer has overflowed on a serial interface. The printed output may contain random * (asterisk) characters. Make a configuration printout.	Verify that the printer matches the host serial interface configuration settings for Data Protocol, Baud Rate, Data Bits, Stop Bits, Parity, Data Terminal Ready, and Request to Send. Set printer serial interface parameters to match those of the host.

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
CLEAR PAPER JAM	Yes	No paper motion.	Clear jam and reload paper. If this message recurs, contact your authorized service representative. <sup>1</sup>
CLEARING PROGRAM FROM FLASH	No	Status message: emulation software successfully loaded into printer RAM and the checksum matched. The old program is now being deleted from flash memory.	No action is required.
CLOSE PLATEN	Yes	The platen lever is open.	Close the platen lever.
CTL VOLT FAIL*	No	Controller Voltage Failure. 15 V failure on the controller board.	Contact your authorized service representative. <sup>1</sup>
D50 Status %XX Clearing Flash	No	Status message: The printer is clearing its flash memory, where %XX represents the percentage completed.	No action is required.
D51 Status %XX Programming...	No	Status message: The printer is loading firmware, where %XX represents the percentage completed.	No action is required.
D55 Status: Send Program to EC	No	Status message: The printer is loading the engine controller program into the engine controller (EC).	No action is required.
DIAGNOSTIC PASSED	No	Status message: the printer passed its memory and hardware initialization tests.	No action is required.
DO NOT POWER OFF	No	Status message: The printer is performing an operation that must be completed before you can cycle power.	No action is required, but do not power off the printer until the operation is complete.

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
DP FIFO Busy*	Yes	There is a timing problem in the Engine Controller firmware.	<ol style="list-style-type: none"> <li>1. Cycle power. Run the print job again. If the message appears, download the emulation software again.</li> <li>2. Cycle power. Run the print job again. If the message appears again, contact your authorized service representative.<sup>1</sup></li> </ol>
DRVR CIR BAD*	No	Driver Circuit Bad. The hammer coil count test failed.	Contact your authorized service representative. <sup>1</sup>
E00 EXE @ ADDR0 See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E01A TYPE 0x40 See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E01B TYPE 0x60 See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
E02 MACHINE CHK See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E03A DSI HASH L See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E03B DSI HASH S See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E03C DSI BAT PL See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
E03D DSI BAT PS See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E03E DSI CXIWX See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E03F DSI CXOWX See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E03G DSI ECXIWX See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
E03H DSI ECXOWX See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E04A ISI NO TRA See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E04B ISI DIRECT See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E04C ISI PROTEC See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>



Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
E06 NOT ALIGNED See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E07 ILLEGAL INS See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E08 FLOATINGPNT See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E12 SYSTEM CALL See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
E13 TRACE INT See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E16 ITRANS MISS See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E17 DLOAD MISS See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E18 DSTORE MISS See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
E19 BREAKPOINT See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E20 SYS MANAGE See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E30 DEBUGGER See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E31A EVENT O BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
E31B EVENT 1 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E31C EVENT 2 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E31D EVENT 3 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E31E EVENT 4 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
E31F EVENT 5 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E31G EVENT 6 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E31H EVENT 7 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E32A CND 0 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
E32B CND 1 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E32C CND 2 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E32D CND 3 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E32E CND 4 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
E32F CND 5 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E32G CND 6 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E32H CND 7 BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E33 WRITE BP See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
E34 TRACE CMPLT See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E99 UNKNOWN INT See User Manual	Yes	An illegal or unsupported instruction was attempted in the application program.	<ol style="list-style-type: none"> <li>1. Cycle Power. Run the print job again. If the message appears, load the latest emulation software.</li> <li>2. Cycle power. Run the print job again. If the message appears, record the display message and send it to your next higher support facility.</li> </ol>
E Net Test Unavailable	Yes	The ethernet PCBA did not initialize correctly.	Cycle power. Wait for "E Net Ready" to display, then retry operation. If it still fails, contact your authorized service representative. <sup>1</sup>
ERROR OCCURRED FLUSHING QUEUES*	Yes	An interim message that displays while the printer discards host data it cannot use because a fault condition exists. While this message displays, the asterisk (*) rotates.	Wait. When the asterisk (*) stops rotating, a different fault message will appear: troubleshoot the final message.
ERROR: CPLD NOT PROGRAMMED	No	The Complex Programmable Logic Device (CPLD) on the controller board is not programmed. The EC cannot read the version bits in the CPLD which tell the EC which configuration version is installed.	Contact your authorized service representative. <sup>1</sup>
ERROR: DC PROGRAM NOT VALID	Yes	The printer cannot find the data controller program or the validation checksum is corrupt.	Download the program again. If the message appears, contact your authorized service representative. <sup>1</sup>





Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
ERROR: PROGRAM NOT VALID	Yes	The printer does not see a program in flash memory.	There is no program in printer memory. Download the emulation.
ERROR: SECURITY KEY NOT DETECTED	No	The security key is not present or failed.	Contact your authorized service representative. <sup>1</sup>
ERROR: SHORT AT ADDRESS XXXX	No	Hardware failure in SDRAM or controller circuitry.	Contact your authorized service representative. <sup>1</sup>
ERROR: WRITING TO FLASH	No	Hardware or software fault in flash memory.	Contact your authorized service representative. <sup>1</sup>
ERROR: WRONG CHECKSUM	No	The printer received the complete program but the checksum did not match. The data may have been corrupted during downloading.	Contact your authorized service representative. <sup>1</sup>
ERROR: WRONG OEM	No	The SPX inserted in the debug port is not intended for this model printer or this OEM.	Contact your authorized service representative. <sup>1</sup>
ERROR: WRONG PRINTER TYPE	No	The SPX inserted in the debug port is not intended for this model printer or this OEM.	Contact your authorized service representative. <sup>1</sup>
ETHERNET ADAPTER BEING INITIALIZED	N/A	Status message indicating that the ethernet interface is processing the boot procedure.	No action is required.
ETHERNET DETECTED	N/A	Status message indicating that the Network Interface Card has established connection.	No action is required.
ETHERNET INITIALIZING	No	Status message: the internal Network Interface Card is processing the boot procedure. (May occur with older versions of microcode.)	No action is required.

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
EXCESS RBN WEAR Install New RBN	Yes	Status message that displays when ribbon reaches end of life, whether the Integrated Print Management System is enabled or not.	Install a new ribbon.
EXHAUST FAN FLT (Cabinet model only)	Yes	Sensors cannot detect current in fan circuit.	Power off the printer and remove the paper path (see <i>Maintenance Manual</i> ). Check that the fan cable connector is connected. Check for obstruction of vents and fan airway, and remove any obstructions. Check for items beneath the printer blocking cabinet vents. Power back on the printer. If this message appears again, contact your authorized service representative. <sup>1</sup>
FIRMWARE ERROR*	No	Application software tried to perform an illegal printer function or damaged memory detected on the controller board.	Contact your authorized service representative. <sup>1</sup>
FM HEADER ERROR*	No	Frame Header Error. Application software has violated header parameters.	Contact your system administrator.
FRAMING ERROR	Yes	The printed output may contain random ! (exclamation point) characters.	Make a configuration printout. Set printer serial interface parameters to match host configuration settings for Data Protocol, Baud Rate, Data Bits, Stop Bits, Parity, Data Terminal Ready, and Request to Send.
GRF CHK ERROR PRESS STOP	Yes	Graphic Check Error: in the CT emulation over a twinax interface, the printer received a non-printable character.	Press CLEAR and then ON LINE.
H00: PCI SLOT ? See User Manual	No	The controller board is not communicating with a PCI card. This could indicate a bad PCI card, poor connection, or problem in the PCI bus.	Contact your authorized service representative. <sup>1</sup>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
H01: PCI J12 See User Manual	No	The controller board is not communicating with the PCI card in PCI slot J12. This could indicate a bad PCI card, poor connection, or problem in the PCI bus.	Contact your authorized service representative. <sup>1</sup>
H02: PCI J13 See User Manual	No	The controller board is not communicating with the PCI card in PCI slot J13. This could indicate a bad PCI card, poor connection, or problem in the PCI bus.	Contact your authorized service representative. <sup>1</sup>
<Online, etc...> Half Speed Mode	No	Status message: The controller samples the operating temperature of key components of the print mechanism. When higher than normal temperatures are sensed, the print speed is automatically reduced by 50% and the message sent the LCD. When the components cool down, the print speed returns to 100% and the message clears.	No action is required. If the message appears often, contact your authorized service representative. <sup>1</sup>
HAM. COIL OPEN*	No	Hammer Coil Open. Electrical malfunction of one or more hammer coils.	Contact your authorized service representative. <sup>1</sup>
HAMMER COIL BAD* #, #, #, ...etc	No	Hammer coil # failed current test at power up.	Contact your authorized service representative. <sup>1</sup>
HAMMER SHORT* See User Manual	No	Electrical malfunction of one or more hammer coils.	Contact your authorized service representative. <sup>1</sup>
HB NOT INSTALLED*	No	Hammer Bank Not Installed. Self-test routines do not detect hammer coils at printer start-up.	Contact your authorized service representative. <sup>1</sup>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
HMR BANK FAN FLT	Yes	Sensors cannot detect current in fan circuit.	Check that fan cable is connected. Check for obstruction of vents and fan airway; remove any obstructions. Check for items beneath the printer blocking cabinet vents. Power back on the printer. If this message recurs, contact your authorized service representative. <sup>1</sup>
ILL EXT BUS ACC*	No	Illegal External Bus Access. Firmware error on the controller board.	Contact your authorized service representative. <sup>1</sup>
ILL INST ACCSS*	No	Illegal Instruction Accessed. Firmware error on the controller board.	Contact your authorized service representative. <sup>1</sup>
ILLGL OPR ACCSS*	No	Illegal Operand Accessed. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
INCOMPAT E-NET Remove NIC	Yes	Incompatible network interface card (NIC) is installed.	Install a compatible NIC to the printer then reboot. If this message still appears, contact your authorized service representative. <sup>1</sup>
INTAKE FAN FAULT	Yes	Sensors cannot detect current in fan circuit.	Cycle power. If the message appears, press CLEAR. If the message does not clear, contact your authorized service representative. <sup>1</sup>
INTERRUPT UNUSED VECTOR 00	No	The controller board receives an interrupt it does not understand. The problem can be created by electrical noise, by a software problem, or by a hardware problem.	Cycle power. If this message occurred once and never again, you can ignore it. If the message reappears or appears consistently, contact your authorized service representative. <sup>1</sup>
INVALID ACTIVATE	No	Printer detects a twinax protocol communication error.	Contact your authorized service representative. <sup>1</sup>
INVALID COMMAND	No	Printer detects a twinax protocol communication error and reports the error.	Contact your authorized service representative. <sup>1</sup>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
LO DRV. SHORT *	No	Lower Driver Short. Circuit(s) on the hammer bank or in the hammer bank power cable shorted to ground.	Contact your authorized service representative. <sup>1</sup>
LOAD PAPER	Yes	Printer is out of paper.	Load paper and press CLEAR.
LOADING PROGRAM FROM PORT XX%	No	Status message: the new emulation program is loading into printer RAM. XX% indicates how much of the program has loaded.	No action is required.
LOADING PROGRAM INTO FLASH	No	The printer has deleted the previous program from flash memory and is loading the new program into flash memory.	No action is required.
NEW SPX DETECTED PRESS ENTER	No	The printer detects an SPX installed at the debug port and the SPX is valid for the printer.	Contact your authorized service representative. <sup>1</sup>
NON VOLATILE MEMORY FAILED	No	Large emulations reduce the amount of space available for saving configurations, which means that sometimes fewer than eight configurations can be saved.	Contact your authorized service representative. <sup>1</sup>
OLD RIBBON Install New RBN	Yes	The sensor detects a ribbon that was previously declared to be at the end of its service life.	Install a new ribbon.
ON LINE	N/A	Printer state message: printer is online and in communication with host.	No action is required.
ONLINE 28 CU NOT ENAB	Yes	Controller Unit Not Enabled. Poll time-out error. The printer was not polled for one minute across a coax interface.	Check cable connection and host system.
ONLINE 8344 FAILED*	No	Link-level code test detects hardware failure.	Contact your authorized service representative. <sup>1</sup>

**Table 15. LCD Message Troubleshooting Table**

Displayed Message	Can User Correct?	Explanation	Solution
ONLINE CU TIMED OUT	Yes	Controller Unit Timed Out. The printer was not enabled for one minute or more on a coax interface.	Check cable connection and host system.
PAP BAD TABLE*	No	Paper Bad Table. The paper feed process on the controller board has a corrupted table.	Contact your authorized service representative. <sup>1</sup>
PAP BSY TOO LNG*	No	Paper Busy Too Long. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
PAP FD DRVR CIR* See Manual	No	Paper Feed Driver Circuit. The paper feed driver circuit on the controller board is drawing too much current.	Contact your authorized service representative. <sup>1</sup>
PAP FIFO OVERFL*	No	Paper First In First Out Overflow. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
PAP FIFO UNDRFL*	No	Paper First In First Out Underflow. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
PAP ILLGL ST*	No	Paper Illegal State. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
PAP INCMPL ENER*	No	Paper Incompletely Energized. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
PAP INVLD CMD*	No	Paper Invalid Command. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
PAP INVLD PARM*	No	Paper Invalid Parameter. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
PAP NOT SCHED*	No	Paper Not Scheduled. The paper feed process is not scheduling on the controller board, and the printer cannot feed paper.	Contact your authorized service representative. <sup>1</sup>
PAP NT AT SPEED*	No	Paper Not At Speed. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
PAP UNEXP INT*	No	Paper Unexpected Interrupt. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
PARAMETER ERROR*	No	Illegal parameter value received in command code over a coax/twinax interface.	Contact your system administrator.
PARITY ERROR	Yes	The printed output may contain a random ? (question mark) characters.	Check your printer serial interface parameter settings; if necessary, adjust them so that they match the settings of the attached host.
PLAT INV CMD*	No	Platen Invalid Command. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
PLAT INV PARM*	No	Platen Invalid Parameter. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
PLAT INV STATE*	No	Platen Invalid State. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
PLEASE WAIT... RESET IN PROGRESS	N/A	Status message: the printer finished loading the program into flash memory and is automatically resetting itself.	No action is required.
POWER SUPPLY HOT	Yes	Power supply sensors report high temperatures.	Check printer environment. If hot or dusty, relocate printer. Contact your authorized service representative if this occurs frequently. <sup>1</sup>
PRINTER HOT	Yes	This message indicates internal temperatures over 60° Celsius (140° Fahrenheit).	Check printer environment. If hot or dusty, relocate printer. Contact your authorized service representative if this occurs frequently. <sup>1</sup>
PRINTER UNDER REMOTE CONTROL	No	Status message: The printer is under the control of PrintNet Enterprise (PNE) remote management software.	No action is required.
PROTECTED INSTR*	No	Protected Instruction. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>



Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
PWR SUPP VOLT *	No	Power Supply Voltage. The power supply has failed.	Replace power supply board.
QUEUE OVERRUN	No	In CT twinax emulation, the print buffer has overflowed.	Contact your authorized service representative. <sup>1</sup>
REMOVE USED SPX THEN PRESS ENTER	No	Status message: An SPX is depleted because it has successfully reprogrammed the security key on the controller board.	Contact your authorized service representative. <sup>1</sup>
RESTORING BOOT CODE	No	Normal download initialization message.	No action is required.
RIB INVLD CMD* See User Manual	Yes	Ribbon Invalid Command. Firmware error on the controller board.	Cycle power. Run the print job again. If the message appears, download the emulation software again. If the message appears again, contact your authorized service representative. <sup>1</sup>
RBN AT END POINT Change Ribbon	Yes	Integrated Print Management System software has determined that the ribbon is out of ink.	Install a new ribbon.
RIBBON STALL	Yes	The controller board does not detect ribbon movement.	Check the ribbon path for jams; if necessary, install a new ribbon.
RIBBON UNDER 2% Change RBN Soon	Yes	Status message indicating the Integrated Print Management System is enabled and ribbon ink level is 2%.	Install a new ribbon.
SCS COMMAND ERROR*	No	In the CT emulation, the printer received undefined control character (hex 40).	Contact your system administrator.
SECURITY VIOLATION*	No	Security code of PAL on controller board does not match code of firmware on the controller board.	Contact your authorized service representative. <sup>1</sup>
SECURITY KEY NOT DETECTED	No	The security key is not present or has failed.	Contact your authorized service representative. <sup>1</sup>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
SENDING PROGRAM TO EC PROCESSOR	No	Status message: the printer is loading the engine controller program into the engine controller.	No action is required.
SF ERROR	No	Structured Field Error. Application software has violated structured data field parameters.	Not a printer problem. Have the system administrator correct applications data or configuration.
SHUT DRVR CIR* See User Manual	No	The shuttle driver circuit on the controller board is drawing too much current.	Contact your authorized service representative. <sup>1</sup>
SHUTL INV CMD*	No	Shuttle Invalid Command. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
SHUTL INV PARM*	No	Shuttle Invalid Parameter. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
SHUTL OVR SPEED*	No	The shuttle is oscillating too rapidly.	Contact your authorized service representative. <sup>1</sup>
SHUTTLE JAM	Yes	No shuttle movement or shuttle moving at the wrong speed.	Check for obstruction to shuttle, a twisted ribbon, or platen lever closed too tightly. If fault source is not apparent, contact your authorized service representative. <sup>1</sup>
SHUTTLE STALL	Yes	The shuttle is not moving. See "SHUTTLE JAM" on page 282.	Set the platen lever to match the thickness of paper, but not too tightly. Check and adjust the platen gap. Inspect the ribbon mask for deformation that snags and interferes with shuttle movement. If fault source is not apparent, contact your authorized service representative. <sup>1</sup>
SHUTTLE TYPE NOT SUPPORTED*	No	The shuttle type was not detected at power-up or the shuttle installed in the printer is not supported by the firmware.	Contact your authorized service representative. <sup>1</sup>
SOFTWARE ERROR* CYCLE POWER	No	Application software tried to perform illegal printer function, or damaged logic circuits found on controller board.	Contact your authorized service representative. <sup>1</sup>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
SPX FOUND, ERROR: KEY NOT DETECTED	No	The controller board does not have a security key.	Contact your authorized service representative. <sup>1</sup>
SPX NOT NEEDED OPTIONS ENABLED	No	The user has attempted to use the SPX to turn on printer options that are already enabled.	Contact your authorized service representative. <sup>1</sup>
STACK OVERFLOW*	No	Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
STACK UNDERFLOW*	No	Firmware error on the controller board.	Contact your authorized service representative. <sup>1</sup>
STACKER FAULT	Yes	Stacker is not functioning correctly.	Check for obstructions in the stacker area. If fault persists, contact your authorized service representative. <sup>1</sup>
STACKER FULL	Yes	Status message: the power paper stacker is full of paper.	Unload the stacker. If fault persists, contact your authorized service representative. <sup>1</sup>
STACKER JAM	Yes	This message is triggered if there is paper inside the throat of the stacker elevator, but the elevator is not moving.	1. Open the cabinet rear door and check for obstructions preventing elevator movement. Remove any obstructions. 2. Run the print job again. If the message appears again, contact your authorized service representative. <sup>1</sup>
TCB CORRUPTED*	No	Task Control Block Corrupted. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
TCP PORT BUSY	Yes	Error message reported by the Printer Manager when ethernet interface option is installed. The network address given in the printer properties was reached, but the printer port is busy.	Refer to the <i>Printronix P7000 Maintenance Manual</i> .
UNDEF INTERRUPT*	No	Undefined Interrupt. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>
UNDFNED OPCODE*	No	Undefined Opcode. Firmware error on controller board.	Contact your authorized service representative. <sup>1</sup>

Table 15. LCD Message Troubleshooting Table

Displayed Message	Can User Correct?	Explanation	Solution
UNKNOWN RBN1 Install New RBN	Yes	The sensor detects a bar code, but the ribbon model is not permitted on this printer.	Install a new ribbon.
UNKNOWN RBN2 Install New RBN	Yes	The sensor detects a bar code, but the region code does not match the printer.	Install a new ribbon.
UP DRV. SHORT*	No	Upper Driver Short. Hammer driver circuits on the boards shorted to ground.	Cycle power to see if the message clears, if not, contact your authorized service representative. <sup>1</sup>
WAITING FOR ETHERNET ADAPTER	N/A	Status message: Appears when the printer is first powered on if the optional Network Interface Card is installed.	No action is required.

<sup>1</sup> Before contacting an authorized service representative, power off the printer, wait 15 seconds, then power it back on and rerun your print job. If the message reappears, press CLEAR. If the fault message still displays, then contact your authorized service representative.

---

# A

## *Printer Specifications*

### **Ribbon Specifications**

---

<b>Standard Ribbons</b>	<b>Part Number</b>
P7000 Ultra Capacity (recommended for most text and barcode OCR)	179499-001
P7000 High Label (recommended for coated or shiny label stock)	179488-001
<b>Specialty Ribbons</b>	
P7000 Red Ribbon	179490-001
P7000 Blue Ribbon	179491-001
P7000 Green Ribbon	179492-001
P7000 Security Ribbon	179493-001
P7000 Quick Dry Ribbon	179494-001
P7000 Tamper Evident	179496-001
P7000 UV Ribbon	179497-001
P7000 Laundry Ribbon	179498-001

## Paper Specifications

---

Type:	Edge-perforated, fan-fold, 3 to 17 inches (7.62 to 43.18 cm) wide, 2 to 12 inches (5.08 to 30.48 cm) long. SureStak Power Stacker option works with forms 5 to 12 inches (12.7 to 30.48 cm) long and up to 16 inches (41 cm) wide without the paper tent or 15.5 inches (39.5 cm) wide with the paper tent installed.
Thickness:	Single-part: 15 to 100 pound (6.80 to 45.36 kg) stock; Multi-part: 1- to 6-part forms (maximum 12 lb [5.44 kg] ply of upper plies)
Sheet Thickness:	0.025 inch (0.064 cm) maximum
Drive:	Adjustable tractors (6-pin engagement)

### Labels

On Backing:	One-part continuous perforated fanfold back form. Labels must be placed at least 1/6 inch (0.42 cm) from the fan-fold perforation. Backing adhesive must not be squeezed out during printing.
Sheet Size:	3 to 17 inches (7.62 to 43.18 cm) wide, including the two standard perforated tractor feed strips. A maximum sheet length of 16 inches (40.64 cm) between top and bottom perforations. <b>NOTE:</b> A 16 inch rear door is needed for the cabinet model. Power Paper Stacker option is 5 to 12 inches (12.7 to 30.48 cm) long.
Thickness:	Not to exceed 0.025 inch (0.064 cm) (including backing sheet)

---

## Printer Weight And Dimensions

---

Cabinet Type	Dimensions			Weight	
	Height	Width	Depth	Unpacked	Packaged
Floor Cabinet	42.5 inches	27 inches	29 inches*	225 lbs.	285 lbs.*
Pedestal	35 inches*	26 inches	21 inches	105 lbs.**	115 lbs.**

\* With a power stacker, the weight increases by 21 lbs. and the depth increases by 4.75 inches for a deeper rear door.

\*\* With the ZTP option, the weight increases by 12 lbs. and the height is increased by 7 inches.

---

## Environmental Characteristics

---

### Temperature:

Operating: 50° to 104° F (10° to 40° C) up to 5000 feet (1524 meters)  
50° to 90° F (10° to 32° C) up to 8000 feet (2438 meters)

Storage: -40° to 158° F (- 40° to 70° C)

### Relative Humidity

Operating: 15% to 80% (noncondensing)

Storage: 15% to 90% (noncondensing)

**Acoustic Noise Level**

<b>Acoustic Noise Levels per ISO 9296</b>	<b>Cabinet Models</b>	<b>Pedestal Models</b>
Printing	50 dB (500 lpm/1000 lpm) 52 dB (1500 lpm) 54 dB (2000 lpm)	65 dB 65 dB NA NA
	6.8 Bel	8.0 Bel
Standby	48 dB	50 dB
	6.3 Bel	6.5 Bel
Geraeuschemission nach ISO 9296		
Druckend	52 dB 52 dB (1500 lpm) 54 dB (2000 lpm)	65 dB 65 dB NA NA
	6.8 Bel	8.0 Bel
Betriebsbereit	48 dB	50 dB
	6.3 Bel	6.5 Bel

**Energy Star**

The printers described in this *User's Manual* comply with the requirements of the ENERGY STAR<sup>®</sup> Office Equipment Program of the U.S. Environmental Protection Agency.



## Electrical Characteristics

	Voltage (+/-10%)	Freq (+/-10%)	Amps	Watts	BTU/Hr
<b>P7005</b>	AC 100-120V	50-60 Hz	3A	275W	940
	AC 200-240V	50-60 Hz	1.5A	275W	940
<b>P7010</b>	AC 100-120V	50-60 Hz	3.5V	300W	1025
	AC 200-240V	50-60 Hz	1.6A	300W	1025
<b>P7015</b>	AC 100-120V	50-60 Hz	4.5A	430W	1469
	AC 200-240V	50-60 Hz	1.9A	430W	1469
<b>P7205</b>	AC 100-120V	50-60 Hz	3.5A	350W	1195
	AC 200-240V	50-60 Hz	1.6A	350W	1195
<b>P7210</b>	AC 100-120V	50-60 Hz	3.5A	350W	1195
	AC 200-240V	50-60 Hz	1.6A	350S	1195
<b>P7215</b>	AC 100-120V	50-60 Hz	5A	460W	1571
	AC 200-240V	50-60 Hz	2A	460W	1571
<b>P7220</b>	AC 100-120V	50-60 Hz	5.5A	540W	1844
	AC 200-240V	50-60 Hz	2.1A	540W	1844

The above values are calculated while printing 136 column, all upper case high speed "E's". The stand-by (Energy Saver mode) wattage is 28W (96 BTU/Hr) for all models.

## Interfaces

Type:	Standard:	IEEE 1284 Parallel, Centronics Parallel, RS-232 serial, Dataproducts Parallel
	Optional:	Coax, Twinax, RS-422 serial, Ethernet 10/100Base-T.
Logic Levels:		TTL/EIA <sup>®</sup> -232E/EIA-422B
Transfer Rates:		Up to 200 Kilobytes on parallel interface. Up to 19.2K baud on RS-232 serial interface. Up to 115.2K baud on RS-422 serial interface

## Printing Rates


---

The printing speed of text is measured in lines per minute (lpm) and is a function of the selected font and the vertical dot density. Printing speed is independent of the number of characters configured in the character set repertoire. Print rates for lines containing attributes such as bold or emphasized printing, superscripts, subscripts, or elongated attributes will decrease to not less than half the rates of the font without such attributes. The exact print rate of lines containing these attributes depends on the specific print job, but software maximizes the throughput by dynamically determining which dot rows contain adjacent dots and must be printed in two strokes.

The reverse paper feed capability allows the printing of multiple densities on a single line. This is useful in printing forms and text together or in mixing different fonts on a print line. Use of multiple densities and reverse paper feed also affects throughput.

# B

# ASCII Character Set



B7 B6 B5 BITS		0 0 0	0 0 1	0 1 0	0 1 1	1 0 0	1 0 1	1 1 0	1 1 1
B4 B3 B2 B1		COLUMN		3		4		7	
ROW		0	1	2	3	4	5	6	7
0 0 0 0	0	NUL 0 0 0	DLE 20 16 10	SP 40 32 20	0 60 48 30	@ 100 64 40	P 120 80 50	\ 140 96 60	p 160 112 70
0 0 0 1	1	SOH 1 1 1	DC1 (XON) 21 17 11	! 41 33 21	1 61 49 31	A 101 65 41	Q 121 81 51	a 141 97 61	q 161 113 71
0 0 1 0	2	STX 2 2 2	DC2 22 18 12	" 42 34 22	2 62 50 32	B 102 66 42	R 122 82 52	b 142 98 62	r 162 114 72
0 0 1 1	3	ETX 3 3 3	DC3 (XOFF) 23 19 13	# 43 35 23	3 63 51 33	C 103 67 43	S 123 83 53	c 143 99 63	s 163 115 73
0 1 0 0	4	EOT 4 4 4	DC4 24 20 14	\$ 44 36 24	4 64 52 34	D 104 68 44	T 124 84 54	d 144 100 64	t 164 116 74
0 1 0 1	5	ENQ 5 5 5	NAK 25 21 15	% 45 37 25	5 65 53 35	E 105 69 45	U 125 85 55	e 145 101 65	u 165 117 75
0 1 1 0	6	ACK 6 6 6	SYN 26 22 16	& 46 38 26	6 66 54 36	F 106 70 46	V 126 86 56	f 146 102 66	v 166 118 76
0 1 1 1	7	BEL 7 7 7	ETB 27 23 17	' 47 39 27	7 67 55 37	G 107 71 47	W 127 87 57	g 147 103 67	w 167 119 77
1 0 0 0	8	BS 8 8 8	CAN 30 24 18	( 50 40 28	8 70 56 38	H 110 72 48	X 130 88 58	h 150 104 68	x 170 120 78
1 0 0 1	9	HT 11 9 9	EM 31 25 19	) 51 41 29	9 71 57 39	I 111 73 49	Y 131 89 59	i 151 105 69	y 171 121 79
1 0 1 0	10	LF 12 10 0A	SUB 32 26 1A	* 52 42 2A	: 72 58 3A	J 112 74 4A	Z 132 90 5A	j 152 106 6A	z 172 122 7A
1 0 1 1	11	VT 13 11 0B	ESC 33 27 1B	+ 53 43 2B	; 73 59 3B	K 113 75 4B	[ 133 91 5B	k 153 107 6B	{ 173 123 7B
1 1 0 0	12	FF 14 12 0C	FS 34 28 1C	, 54 44 2C	< 74 60 3C	L 114 76 4C	\ 134 92 5C	l 154 108 6C	 174 124 7C
1 1 0 1	13	CR 15 13 0D	GS 35 29 1D	- 55 45 2D	= 75 61 3D	M 115 77 4D	] 135 93 5D	m 155 109 6D	} 175 125 7D
1 1 1 0	14	SO 16 14 0E	RS 36 30 1E	. 56 46 2E	> 76 62 3E	N 116 78 4E	^ 136 94 5E	n 156 110 6E	~ 176 126 7E
1 1 1 1	15	SI 17 15 0F	US 37 31 1F	/ 57 47 2F	? 77 63 3F	O 117 79 4F	_ 137 95 5F	o 157 111 6F	DEL 177 127 7F



---



# C

## *Zero Tear Printer*

### **Overview**


---

The P7000 Zero Tear (ZT) printer can print a form and present it for tear off without losing a form between print jobs. The printer automatically presents the current print line to the tear bar when it finishes printing and no data are being sent to the printer. When it receives more data from the host computer, the printer pulls the form down to the print station and resumes printing.

The ZT printer is available as a 500 lpm, 1000 lpm, 1500 lpm standard ASCII printer and as a 200 lpm, 300 lpm, and 600 lpm H-Series (DBCS) printer.

## Operation


### Position The Paper Input And Adjust The Paper Guides



**Figure 29. Adjusting The Paper Guides**

**NOTE:** Ensure that the paper guides are not damaged.

1. Remove the left paper guide knob and the left, front paper guide leaf. (See Figure 29.)
2. Remove the right paper guide knob and the right, front paper guide leaf.
3. Remove the center paper guide knob and the center, front paper guide leaf.



**Figure 30. Adjusting Paper Guide Leaves**

4. Slide the left outboard mount block so that the left outer paper guide leaf is .5 inches from the left tractor. (See Figure 30).
5. Slide the right outboard mount block so that the right outer paper guide leaf is .5 inches from the right tractor.
6. Slide the center mount block so that the center paper guide leaf is centered between the left and right outer paper guide leaves.
7. Install the paper guide knobs and front paper guide leaves. (See Figure 29.)

## Load Paper





Figure 31. Loading Paper Onto The Printer




1. Align the paper supply box with the label on the bottom left side of the modesty panel. (See Figure 31 on page 296.)
2. Unlock and open the tractor doors and slide the paper from below, through the black paper out sensor slot on the left side, and up between all front and rear paper guides.
3. Load the paper on the left tractor sprockets and close the tractor door.
4. Load the paper onto the right tractor sprockets and close the tractor door.




**Figure 32. Adjusting the Horizontal Paper Tension**

5. Adjust the paper web tightness by sliding the right tractor to remove slack or to adjust for various paper widths. (See Figure 32.)
6. Lock the tractors in position by pressing down on the tractor locks.



**Figure 33. Paper Exiting the Top of the Printer**

## Position The Paper Out Sensor



**Figure 34. The Paper Out Sensor**

The paper out sensor indicates when the printer runs out of paper. (The sensor does not work with black backed forms.) Unlike the standard pedestal printer, the ZT printer requires you to load the paper through the paper out sensor slot (Figure 31 and Figure 34). Correct positioning of the paper out sensor ensures that the last form the printer prints will be properly presented to the tear bar. To position the paper out sensor, do the following:

1. Position the paper properly at the tear bar (page 300).
2. Loosen the paper out sensor by turning the sensor knob counterclockwise.
3. Position the paper out sensor so that there are at least 2 inches between the bottom of the aluminum extrusion bar and the top of the paper out sensor.

### **IMPORTANT**


**For optimal performance, 2 inches is recommended for 11 inch forms. For shorter forms, position the paper out sensor so that there are at least 2 inches between a perforation and the top of the paper out sensor.**

4. Tighten the paper out sensor by turning the sensor knobs clockwise.
5. Press **ONLINE/CLEAR**. When the first print job is sent to the printer, the paper is drawn into the printer, the top of form aligns with the print station, and the print job begins.

## Set The Tear Bar Distance

To set the tear bar distance, do the following steps:

1. Make sure the printer is offline.
2. Press the right arrow ► until "OFFLINE/ZTP SETTINGS" displays.
3. Press the down arrow ▼. "ZTP DataTime" displays.
4. Press the right arrow ► until "ZTP TearDist" displays.
5. Press the down arrow ▼. "ZTP TearDist/xx/144 Inch" displays.
6. Press the **Enter** key. A scale prints to indicate the tear bar distance in relation to the tear bar.
7. Press the left arrow ◀ or right arrow ► to decrease or increase the tear bar distance in increments of 1/144th of an inch.
8. Press **Enter** to select the desired value. An asterisk appears next the selected value.
9. Press **Enter** again to print a new scale. For correct tear bar distance, the zero should align with the tear bar. See Figure 35.




**Figure 35. Correct Tear Bar Distance**

**NOTE:** When a new ZTP Tear Bar Dist value is selected, the printer will lose the current print position until you reset the top of form to automatically save the new value.

10. Reset the top of form using the procedure on page 300.

## Set The Top Of Form



**Figure 36. Setting The Tear Off Position**

The ZT printer uses the tear bar as the reference point for setting the tear off position. To set the position of the forms perforation to the tear bar, use the **SET TOF** button as follows:

1. Make sure the paper guides are adjusted correctly and the paper is properly loaded.
2. Press the **SET TOF** button on the control panel. The printer display will read "Align at TearBar/Then Press TOF".
3. Use the form advance knob to move the top of the form to the tear off bar.
4. Position the perforation so it aligns with the tear off bar.

**NOTE:** This is easily done by advancing one complete sheet above the tear off bar and folding it over at the perforation.

5. Position the fold exactly at the tear bar.
6. Tear the sheet off to ensure proper positioning.

**NOTE:** If you do not want to lose a form, position the top of the form at the tear bar. Run a finger along the back of the form along the tear bar to ensure the perforation is presented at the tear off point.

7. Press the **SET TOF** button again. The printer display will read "Top Of Form Set/Press ONLINE". The printer will then be brought OFFLINE and the top of form will be set.
8. Press the **ONLINE/CLEAR** key to bring the printer online.

## Control Panel Menus

---

The ZTP SETTINGS menu includes the ability to enable and disable features unique to the Zero Tear printer (ZTP), set the tear bar distance, set the auto present data time, and set the auto present wait time. This section defines these options.

### ZTP Function

This option enables or disables all unique ZTP functions. The default is Enable.

**NOTE:** When the ZTP Function is enabled, the View/Eject key is disabled and Slow Paper Slew is enabled.

### ZTP TearDist

This option sets the tear off distance from the current print position to the tear bar. Adjustable values in increments of 1/144th of an inch range from 200 to 2880. The up and down arrows adjust the display value. When you press the **Enter** key, the selected value is stored and a scale is printed to indicate the current tear off position. The default value is 1060.

**NOTE:** When a new value is selected, the printer will lose the current print position. You must reset the top of form to automatically save the new value.

### ZTP DataTime

This option sets the pause time in the data stream that the ZTP requires before moving the form to the tear bar once a print job is completed. The values range from .5 to 5 seconds. The default is .5 seconds.

### ZTP WaitTime

This option sets the minimum amount of time that the form stays at the tear bar. This allows you time to remove the form before the form is retracted to print the next form. The adjustable values range from 500 to 5000 milliseconds in increments of 500 milliseconds. The default value is 2 seconds.

### ZTP Platen Open

This option allows the user to have the platen open whenever forms are reversed. Enabled is the default, used for most papers and labels. The feature can be disabled as required by some multi-part forms.

## Performance Limitations

### Forms Type

The paper feed tractors on the ZT printer push the paper up through the print station instead of pulling it through, as in the standard pedestal printer. This limits the variety of forms the ZT printer can use. If the forms do not fall within the range specified in Table 16, dot compression and line separation may occur. The user should match the media to the application to ensure acceptable print quality. Also, because paper is pushed from below the print station, the last form in the tractors may not print fully or may not be presented to the printer exit for retrieval.

All paper used in the ZT printer requires standard half inch spaced tractor feed holes. Cut sheet and continuous friction fed paper is not supported. The forms specified in Table 16 can have no more than one form per page horizontally.

**Table 16. Forms Type**

Description	Length	Width (edge to edge)
One to three part, continuous, with carbon, fan-folded, edge-perforated paper forms	3 to 12 inches	7 to 16.5 inches
One to four part, continuous, with carbon, fan-folded, edge-perforated paper forms	3 to 12 inches	7 to 12 inches
One to four part, continuous, carbonless, fan-folded, edge-perforated paper forms	3 to 12 inches	7 to 16.5 inches
One to six part, continuous, carbonless, fan-folded, edge-perforated paper forms	3 to 12 inches	7 to 12 inches
Forms with a paper weight of 20 to 100 pounds and a maximum thickness of 0.025 inches	3 to 12 inches	7 to 16.5 inches
Forms with a paper weight of 18 to 100 pounds and a maximum thickness of 0.025 inches	3 to 12 inches	7 to 12 inches
Forms with all approved types of interleaf edge attachment except those using metallic or other hard devices		

**NOTE:** If you use forms outside these limits, the print quality may not be optimum, the printer may lose top-of-form, or the frequency of paper jams will increase.

## Paper Jams

Printer jams can occur if you tear off the form incorrectly. If you experience two or more paper jams per box of forms, follow these guidelines to help reduce jams:

- Position the lower paper guides properly
- Align the paper web tightness properly
- Position the form perforation against the tear bar
- Time the tear, while the paper is not moving
- Direct the tear force toward the user and across the tear bar, not upward.

## To Clear Paper Jams

1. Raise the platen lever to open the platen.
2. Open the left and right tractor doors.
3. Pull the paper upward through the top of the printer.

**NOTE:** DO NOT pull the paper downwards from the bottom. This could cause the paper guides to bend.

4. Reload the paper (see page 296).





---

# D

## *Customer Support*

---

### **Printronix Customer Support Center**

---

**IMPORTANT** Please have the following information available prior to calling the Printronix Customer Support Center:

- Model number
- Serial number (located on the back of the printer)
- Installed options (i.e., interface and host type if applicable to the problem)
- Configuration printout:  
Line Matrix Printer  
Press PRT CONFIG on the control panel, then press Enter.
- Is the problem with a new install or an existing printer?
- Description of the problem (be specific)
- Good and bad samples that clearly show the problem (faxing of these samples may be required)

Americas (714) 368-2686

Europe, Middle East, and Africa (31) 24 6489 311

Asia Pacific (65) 6548 4114

<http://www.primtronix.com/support.aspx>

---

### **Printronix Supplies Department**

---

Contact the Printronix Supplies Department for genuine Printronix supplies.

Americas (800) 733-1900

Europe, Middle East, and Africa (33) 1 46 25 1900

Asia Pacific (65) 6548 4116  
or (65) 6548 4182

<http://www.primtronix.com/supplies-parts.aspx>

## **Corporate Offices**

---

Printronix, Inc.  
14600 Myford Road  
P.O. Box 19559  
Irvine, CA 92623-9559  
Phone: (714) 368-2300  
Fax: (714) 368-2600

Printronix, Inc.  
Nederland BV  
P.O. Box 163, Nieuweweg 283  
NL-6600 Ad Wijchen  
The Netherlands  
Phone: (31) 24 6489489  
Fax: (31) 24 6489499

Printronix Schweiz GmbH  
42 Changi South Street 1  
Changi South Industrial Estate  
Singapore 486763  
Phone: (65) 6542 0110  
Fax: (65) 6546 1588

Visit the Printronix web site at [www.primtronix.com](http://www.primtronix.com)

---

# E

## *Communication Notices*

---

### Notices

---

This information was developed for products and services offered in the U.S.A.

Printronix may not offer the products, services, or features discussed in this document in other countries. Consult your Printronix representative for information on the products and services currently available in your area. Any reference to an Printronix product, program, or service is not intended to state or imply that only that Printronix product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any Printronix intellectual property rights may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-Printronix product, program, or service.

Printronix may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquires, in writing, to:

Printronix, Inc.  
14600 Myford Road  
P.O. Box 19559  
Irvine, CA 92623-9559 U.S.A.

**The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law:**

PRINTRONIX PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. Printronix may make improvements and/or changes in the product(s) described in this publication at any time without notice.

Any references in this information to non-Printronix Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this Printronix product and use of those Web sites is at your own risk.

Any performance data contained herein was determined in a controlled environment. Therefore, the results obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurement may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

Information concerning non-Printronix products was obtained from the suppliers of those products, their published announcements or other publicly available sources. Printronix has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-Printronix products. Questions on the capabilities of non-Printronix products should be addressed to the suppliers of those products.

Printronix encourages owners of information technology (IT) equipment to responsibly recycle their equipment when it is no longer needed. Printronix offers a variety of programs and services to assist equipment owners in recycling their IT products. Information on these product recycling offerings can be found on Printronix's Internet site at <http://www.printronix.com>.

**Note!**

Before using this information and the product it supports, read the information and Communication Statements on page 310.

If you are viewing this information softcopy, the photographs and color illustrations may not appear.

For online versions of this book, we authorize you to:

- Copy, modify, and print the documentation contained on the media, for use within your enterprise, provided you reproduce the copyright notice, all warning statements, and other required statements on each copy or partial copy.
- Transfer the original unaltered copy of the documentation when you transfer the related Printronix product (which may be either machines you own, or programs, if the program's license terms permit a transfer). You must, at the same time, destroy all other copies of the documentation.

You are responsible for payment of any taxes, including personal property taxes, resulting from this authorization.

Your failure to comply with the terms above terminates this authorization. Upon termination, you must destroy your machine readable documentation.

---

## Energy Star

---



The Environmental Protection Agency ENERGY STAR® Computers program is a partnership effort with manufacturers of data processing equipment to promote the introduction of energy-efficient personal computers, monitors, printers, fax machines, and copiers to help reduce air pollution and global warming caused by electricity generation.

Printronix participates in this program by introducing printers that reduce power consumption when they are not being used. As an ENERGY STAR® Partner, Printronix has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

**NOTE:** The ENERGY STAR® emblem does not represent EPA endorsement of any product or service.

## Product Recycling and Disposal

---

This unit may have lead-containing materials – such as circuit boards and connectors – that require special handling. Before this unit is disposed of, these materials must be removed and recycled or discarded according to applicable regulations. This book contains specific information on batteries and refrigerant where applicable.

This product may contain a sealed, lead-acid battery; lithium battery; nickel-metal-hydride battery; or nickel-cadium battery. Batteries of these types must be recycled or disposed of properly. Recycling facilities may not be available in your area.

In the United States, Printronix has established a collection process for reuse, recycling, or proper disposal of used batteries and battery packs from Printronix equipment. For information on proper disposal of the batteries in this product, please contact Printronix.

For information on disposal of batteries outside the United States, contact your local waste disposal facility.

## Communication Statements

---

### Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. Printronix is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### European Union (EU) Conformity Statement



Hereby, Printronix declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Printronix cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product, including the fitting of non-Printronix option cards.

This product has been tested and found to comply with the limits for Class A Information Technology Equipment according to European standard EN 55022. The limits for Class A equipment were derived for commercial and industrial environments to provide reasonable protection against interference with licensed communication devices.

#### WARNING

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

---

Properly shielded and grounded cables and connectors must be used in order to reduce the potential for causing interference to radio and TV communications and to other electrical or electronic equipment. Printronix cannot accept responsibility for any interference caused by using other than recommended cables and connectors.

### **Industry Canada Compliance Statement**

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A conformé à la norme NMB-003 du Canada.

### **Statement of CISPR 22 Edition 2 Compliance**

**Attention:** This is a Class A Product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

### **Japanese VCCI Class A**

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

### **German Conformity Statement**

#### **Handbuchtex: FCC class A entspricht: EMVG Klasse A**

Text Für alle in Deutschland vertriebenen EN 55022 Klasse A Geräte:

Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG) vom 18. September 1998 (bzw. der EMC EG Richtlinie 89/336):

Dieses Gerät ist berechtigt in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen. Verantwortlich für die Konformitätserklärung nach Paragraph 5 des EMVG ist die: Printronix Deutschland GmbH, 70548 Stuttgart. Informationen in Hinsicht EMVG Paragraph 4 Abs. (1) 4:

Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55022 Klasse A.

EN 55022 Klasse A Geräte müssen mit folgendem Warnhinweis versehen werden: "Warnung: dies ist eine Einrichtung der Klasse A. Diese Einrichtung kann im Wohnbereich Funkstörungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen durchzuführen und dafür aufzukommen."

EN 55024 Hinweis:

Wird dieses Gerät in einer industriellen Umgebung betrieben (wie in EN 55024 festgelegt), dann kann es dabei eventuell gestört werden. In solch einem Fall ist der Abstand bzw. die Abschirmung zu der industriellen Störquelle zu übergrößen.

Anmerkung:

Um die Einhaltung des EMVG sicherzustellen sind die Geräte, wie in den Printronix Handbüchern angegeben, zu installieren und zu betreiben.

## China

### Declaration:

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may need to perform practical actions.

## 声 明

此为 A 级产品, 在生活环境中,  
该产品可能会造成无线电干扰。  
在这种情况下, 可能需要用户对其  
干扰采取切实可行的措施。

## Taiwan

### Warning:

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user will be required to take adequate measures.

警告使用者：  
這是甲類的資訊產品，在  
居住的環境中使用時，可  
能會造成射頻干擾，在這  
種情況下，使用者會被要  
求採取某些適當的對策。



---

## Korea

### A급 기기(업무용)

이 기기는 업무용으로 전자파적합등록을 받은 기기이오니 판매자 또는 이용자는 이점을 주의하시기 바라며, 만약 구입하였을 때에는 구입한 곳에서 가정용으로 교환하시기 바랍니다.


#### CAUTION:

This product is equipped with a 3-wire power cord and plug for the user's safety. Use this power cord in conjunction with a properly grounded electrical outlet to avoid electrical shock.

## Lithium Battery Warning

---

The controller board contains a lithium battery sealed inside the real-time clock chip. Do not disassemble the chip to replace the battery. Do not dispose of the chip by incineration. Failure to comply may cause the battery to explode. Contact your local waste agency for the correct disposal procedure.

廢電池請回收 

## Software License Agreement

---

Your printer contains, among other software, Printronix operating software including, but not limited to the Embedded Configurable Operating System (the “eCos Software”) as embedded software. The terms of this Agreement apply only to the eCos Software, and all other embedded software supplied with the printer. You accept the terms of this Agreement by your initial use of your printer.

### 1. Object Code License

Printronix grants you a nonexclusive license to use the Printronix Software, the eCos Software and all other embedded software (collectively, the “Embedded Software” or the “Software”) only in conjunction with the printer. As the rightful possessor of the printer, you may make a reasonable number of copies of the Software as necessary for backup, configuration, and restoration of the printer. You must reproduce the copyright notice and any other legend of ownership on each copy of the Software you make.

You may transfer possession of the Software and its media to another party only with the transfer of the printer on which the Software is used. If you do so, you must give the other party a copy of these terms and provide all user documentation to that party. When you do so, you must destroy any copies of Software not resident in the printer.

Your license for the Software terminates when you no longer rightfully possess the printer. No other rights under this license are granted.

### 2. Source Code

A source code version of eCos Software is available under the terms of the Red Hat eCos Public License v1.1 at [www.primtronix.com](http://www.primtronix.com). Printronix grants no rights whatsoever in the source code for the Printronix Software.

### 3. No Warranty

THE EMBEDDED SOFTWARE IS PROVIDED UNDER THIS LICENSE ON AN “AS IS” BASIS, WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, WARRANTIES THAT THE EMBEDDED SOFTWARE IS FREE OF DEFECTS, MERCHANTABILITY, FIT FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE EMBEDDED SOFTWARE IS WITH YOU. SHOULD ANY OF THE EMBEDDED SOFTWARE PROVE DEFECTIVE IN ANY RESPECT, YOU (NOT RED HAT, PRINTRONIX, ANY OTHER CONTRIBUTOR OR ANY DISTRIBUTOR) ASSUME THE COST OF ANY NECESSARY SERVICING, REPAIR OR CORRECTION. THIS DISCLAIMER OF WARRANTY CONSTITUTES AN ESSENTIAL PART OF THIS LICENSE. NO USE OF ANY OF THE EMBEDDED SOFTWARE IS AUTHORIZED HEREUNDER EXCEPT UNDER THIS DISCLAIMER.

### 4. Conflicting Terms

You agree that this Agreement provides you no more rights with regards to warranty, support, indemnity or liability terms with respect to Red Hat, Inc., Printronix Inc, or any contributor to the Embedded Software than that provided by the Red Hat eCos Public License v.1.1 or any express warranty that may be made by Printronix, Inc.

---

## **5. Limitation of Liability**

UNDER NO CIRCUMSTANCES AND UNDER NO LEGAL THEORY, WHETHER TORT (INCLUDING NEGLIGENCE), CONTRACT OR OTHERWISE, SHALL RED HAT, PRINTRONIX, ANY OTHER CONTRIBUTOR, OR ANY DISTRIBUTOR OF THE EMBEDDED SOFTWARE, OR ANY PART THEREOF, OR ANY SUPPLIER OF ANY OF SUCH PARTIES, BE LIABLE TO YOU OR ANY OTHER PERSON FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY CHARACTER INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF GOODWILL, WORK STOPPAGE, COMPUTER FAILURE OR MALFUNCTION. OR ANY AND ALL OTHER COMMERCIAL DAMAGES OR LOSSES, EVEN IF SUCH PARTY SHALL HAVE BEEN INFORMED OF THE POSSIBILITY OF SUCH DAMAGES. THIS LIMITATION OF LIABILITY SHALL NOT APPLY TO LIABILITY FOR DEATH OR PERSONAL INJURY RESULTING FROM SUCH PARTY'S NEGLIGENCE TO THE EXTENT APPLICABLE LAW PROHIBITS SUCH LIMITATION. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THAT EXCLUSION AND LIMITATION MAY NOT APPLY TO YOU.

## **6. U.S. Government Users**

The Embedded Software is a "commercial item," as that term is defined in 48 C.F.R. 2.101 (Oct 1995), consisting of "commercial computer software" and "commercial computer software documentation," as such terms are used in 48 C.F.R. 12.212 (Sept. 1995). Consistent with 48 C.F.R. 12.212 and 48 C.F.R. 227.7202-1 through 227.7202-4 (June 1995), all U.S. Government End Users acquire Covered Code with only those rights set forth herein.

## **7. Miscellaneous**

This Agreement represents the complete agreement concerning subject matter hereof. If any provision of this Agreement is held to be unenforceable. This Agreement shall be governed by California law provisions (except to the extent applicable law, if any, provides otherwise), excluding its conflict-of-law provisions.

**8. Red Hat Statement With Regards to eCos Software**

Part of the software embedded in this product is eCos - Embedded Configurable Operating System, a trademark of Red Hat. Portions created by Red Hat are Copyright (C) 1998, 1999, 2000 Red Hat, Inc. (<http://www.redhat.com>). All Rights Reserved.

THE SOFTWARE IN THIS PRODUCT WAS IN PART PROVIDED BY RED HAT AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANT ABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OR SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---

# Index

## A

- A TO D OVERUN \* message, 256
- Absorb After ^PN, 199
- Absorb After ^PY, 197
- Accented Char, PRINTER CONTROL, 220
- ACCESS NULL PTR \* message, 256
- Acknowledge, Centronics Parallel Interface Signals, 237
- Acoustic noise level, 288
- ACTIVATE LOST message, 256
- Active Char Set, 108, 117
  - 3270 Params menu, 123
  - 5250 Params menu, 130
- Active Emulation, 65
- ACTIVE IGP EMUL menu, 102
- Active IGP Emulation, 65
- Adapter Address, 64
- ADAPTER ADDRESS menu, 87
  - DHCP, 88
  - Gateway address, 88
  - IP address, 87
  - MAC address, 88
  - Subnet mask, 87
- ADAPTER PARAMS menu
  - ASCII data port, 89
  - Ethernet speed, 90
  - IPDS Data Port, 89
  - Job Control, 90
  - Keep alive timer, 90
  - Nest Serv Type, 89
  - NetBIOS protocol, 89
  - Novell frame, 89
  - Novell protocol, 89
- ADVANCED USER menu, 221
  - Alarm, 224
  - Auto Elevator, 223
  - Auto Locking, 223
  - Cancel Key, 225
  - Downloaded Fonts, 222
  - File System, 223
  - PMD (Paper Motion Detection) Fault, 223
  - Power Saver Time, 225
  - Power Stacker, 223
  - Pwr Save Control, 225
  - Set Lock Key, 225
  - Set Sharing, 224
  - Shuttle Timeout, 224
  - Slow Paper Slew, 224
- AI 00 Spaces, 183, 198
- Alarm, ADVANCED USER menu, 224
- Alt. Char Set, Proprinter XL Emulation, 160
- Alt. Set 80-9F, 110, 147
  - Epson FX Emulation, 164
  - PTX Transparent, 118
  - Serial Matrix Emulation, 156
- ANSI Emulation menu, 168
  - Auto LF, 172
  - Barcode Darkmode, 174
  - BC Check Digit, 174
  - Character Set, 173
  - CPI/LPI Select, 170
  - Define CR Code, 172
  - Define LF Code, 172
  - ESC c Sequence, 173
  - ETX/ACK, 174
  - Font Attributes, 170
  - Page Format, 171

- Pos. on BC/OvrSz, 174
- Printer Select, 173
- Private Mode, 173
- PUM Default, 174
- Received CR, 173
- Received DEL, 173
- Reset Cmd CFG Ld, 173
- Truncate PI Slew, 174
- Antenna, WLAN PARAMS menu, 97
- Ant. Diversity, WLAN PARAMS menu, 97
- Append Rotated, 196
- ASCII Character Set, 291
- ASCII data port, Adapter Params menu, 89
- ASCII data port, Ethernet Parameters menu, 92
- Auth Method, WLAN LEAP menu, 101
- Auth Method, WLAN PARAMS menu, 98
- Auto Elevator, ADVANCED USER menu, 223
- Auto FF at ^PN, 200
- Auto LF, 146
  - ANSI Emulation menu, 172
  - Epson FX Emulation, 163
  - Proprinter XL Emulation, 159
  - P-Series XQ Emulation, 152
  - Serial Matrix Emulation, 155
- Auto Locking, ADVANCED USER menu, 223
- Auto Save Configuration, 52
- Auto Save CONFIG. CONTROL menu
  - Auto Save, 71
- Auto Skip At End, 112, 126
- Auto Switching submenu, 73
  - Auto Switching submenu, 73
  - Port Type, 74
  - Report Status, 74
  - Switch Out On, 74
  - Timeout, 74
  - Trickle Time, 74
- Auto Trickle
  - Centronics (Parallel) submenu, 78
  - Dataproducts submenu, 80
  - IEEE 1284 Parallel (Bidirectional) Submenu, 75
- Auto Uppercase, 181

- Autowrap, 180
- Autowrap, LG Emulation, 216

## B

- Bar Code Quality, PRINTER CONTROL, 219
- Bar Code Verification, 252
- BARCODE DAMAGED message, 259
- Barcode Darkmode, ANSI Emulation menu, 174
- Barcode Errors, 201
- BARCODE MISSING message, 259
- Barcode Options, 182
  - AI 00 Spaces, 183
  - C39 Compatbl., 184
  - I 2/5 Selection, 183
  - Optimized Ratio, 183
  - Select SO Char, 183
  - UPC Descenders, 182
  - User-Def Ratio, 183
- Barcode Quality, IPDS Emulation, 206
- Barcode Size, IPDS Emulation, 207
- Barcode Speed, IPDS Emulation, 206
- Barcode, clean, 45, 251
- Baud Rate, Serial submenu, 83
- BC Check Digit, ANSI Emulation menu, 174
- BC SENSOR ERR message, 259
- Buffer Clear, Dataproducts Parallel Interface Signals, 235
- BUFFER OVERRUN message, 259
- Buffer Print, 114, 120, 133
  - SPC Twx Params, 136
- Buffer Reprint, 109, 134
- Buffer Size in K
  - Centronics (Parallel) submenu, 78
  - Dataproducts submenu, 80
  - Ethernet submenu, 86
  - IEEE 1284 Parallel (Bidirectional) Submenu, 75
  - Serial submenu, 84
- Busy On Strobe, Centronics (Parallel) submenu, 77
- Busy, Centronics Parallel Interface Signals, 237
- Byte Mode, IEEE 1284 Parallel Interface, 238
- B00 STATUS SDRAM DETECTION 166MHZ message, 256

---

B01 STATUS 8245 SDRAM TEST 32MB  
message, 256

B10 ERROR NO DRAM DETECTED\*  
message, 256

B11 ERROR RAM TEST FAILED\* message, 257

B12 ERROR PROGRAM MISSING\* message, 257

B13 ERROR NOT COMPATIBLE\* message, 257

B19 ERROR DC RETURNED\* message, 257

B20 STATUS 00% DOWNLOAD MODE  
message, 257

B21 STATUS PRINTER RESET message, 257

B22 ERROR DECOMPRESS SIZE\* message, 257

B23 ERROR DECOMPRESS CKSUM\*  
message, 257

B30 STATUS INITIALIZING, 257

B35 WAITING FOR EC STATUS, 258

B40 ERROR PROM CKSUM BAD\* message, 258

B41 ERROR DIM MEMORY NOT SDRAM\*  
message, 258

B42 ERROR SDRAM ROWS NOT ALLOWED\*  
message, 258

B43 ERROR SDRAM TOO MANY BANKS\*  
message, 258

B44 ERROR SDRAM NOT 64 BITS WIDE\*  
message, 258

B45 ERROR SDRAM IS WRONG VOLTAGE\*  
message, 258

B46 ERROR SDRAM HAS MIXED SIZES\*  
message, 258

B47 ERROR SDRAM LARGER THAN 256M\*  
message, 258

B49 ERROR SDRAM # LOGICAL BANKS\*  
message, 258

B50 ERROR SDRAM LOGIC COMB BANKS\*  
message, 258

B51 XX% LOADING, 259

B53 ERROR 12C NO ARBITRATION, 259

B54 ERROR SDA LINE STUCK LOW, 259

## C

Cable Verify, Dataproducts Parallel Interface  
Signals, 235

Cancel a print job, 46

Cancel IGP/DCU, 109, 117

CANCEL key, 27

Cancel Key, ADVANCED USER menu, 225

Centronics Parallel Interface, 236

Centronics Parallel Interface Signals, 237

- Acknowledge, 237
- Busy, 237
- Data Lines 1 through 8, 237
- Data Strobe, 237
- Fault, 237
- Online, 237
- Paper Empty (PE), 237
- Paper Instruction (PI), 237
- Prime, 237

Centronics (Parallel) submenu, 76

- Auto Trickle, 78
- Buffer Size in K, 78
- Busy On Strobe, 77
- Data Bit 8, 77
- Data Polarity, 77
- Latch Data On, 77
- PI Ignored, 77
- Prime Signal, 77
- Resp. Polarity, 77
- TOF Action, 78
- Trickle Time, 78

Change Case, 110

Change Case, 3270 Params menu, 124

Changing parameter settings, 47

Changing parameters, example, 49

Changing Ribbons, 43

Channel, WLAN PARAMS menu, 96

Char Set Select, 108, 117

---

Character Set, 147  
     ANSI Emulation menu, 173  
     ASCII, 291  
     Epson FX Emulation, 164  
     Proprinter XL Emulation, 160  
     Serial Matrix Emulation, 156  
 Characteristics, environmental, 287  
 Cleaning  
     exterior, 249  
     interior, 250  
     ribbon barcode, 45, 251  
 Cleaning requirements, 249  
 CLEAR key, 26  
 CLEAR PAPER JAM message, 260  
 Clear to Send (CTS), RS-232, 245  
 CLEARING PROGRAM FROM FLASH message, 260  
 Clock Skew, WLAN Kerberos menu, 100  
 CLOSE PLATEN message, 260  
 Coax Emulation menu, 106  
     Active Char Set, 108  
     Buffer Print, 114  
     Buffer Reprint, 109  
     Cancel IGP/DCU, 109  
     Change Case, 110  
     Char Set Select, 108  
     Compatibility Op, 111  
     Early Print Cmpl, 109  
     Format Control, 113  
     Host Override, 113  
     Image Buf Size, 111  
     Intervention Req, 111  
     Max. Print Width, 114  
     PA1, 108  
     PA2, 109  
     Prt Partial Line, 108  
     PTX Transparent, 110  
     SCS Buffer Cntrl, 109  
     Set Text Orientn, 111  
     Translate Table, 113  
     Translation Tbl, 108  
     Coax/Twinax (CTHI) Emulation menu, 104  
         Simple Prot Conv, 105  
         Standard, 104  
     Code Page Subset, IPDS Emulation, 208  
     Column 132 Wrap, 133  
     Compatbl. Mode, 185  
     Compatibility Mode, IEEE 1284 Parallel Interface, 238  
     Compatibility Op, 111  
         Auto Skip At End, 112, 126  
         CR at MPP+1, 111, 125  
         CR, EM, and NL (3287 only), 126  
         CR, EM, & NL (3287 only), 113  
         FF After Job, 113, 126  
         FF Validity, 112, 126  
         Last Char = FF, 112, 125  
         NL At MPP+1, 111, 125  
         Null Suppression, 112, 125  
         Position Aft FF (4234 only), 112, 125  
     Compatibility Op, 3270 Params menu, 125  
     Compliance, Energy Star, 288  
     Component locations, printer, 23  
     Compressed CPI, 184  
     Compressed Print, P-Series XQ Emulation, 153  
     Config Print, PCL-II Emulation, 213  
     Configurations  
         custom, 48  
         default, 48  
         overview, 47  
         saving, 52  
     Configuration, Auto Save, 52  
     CONFIG. CONTROL menu, 69  
         Delete Config., 70  
         Load Config., 70  
         Name Configs, 71  
         Power-Up Config., 70  
         Print Config., 70  
         Protect Configs., 70  
         Reset Cfg Names, 71  
         Save Config., 70  
     Contact information, 16



---

- Control Code 06, 145
  - P-Series XQ Emulation, 152
  - Serial Matrix Emulation, 155
- Control Control Code 08, 145
- Control panel, 26
- Control panel keys
  - CANCEL, 27
  - CLEAR, 26
  - ENTER, 28
  - JOB SELECT, 28
  - ON LINE, 26
  - PAPER ADVANCE, 26
  - PREV or NEXT, 28
  - PREV + NEXT, 28
  - PRT CONFIG, 27
  - SET TOF, 27
  - UP or DOWN, 28
  - UP + DOWN, 28
  - VIEW/EJECT key, 27
- Conventions, manual, 15
- CPI/LPI Select, 139
  - ANSI Emulation menu, 170
- CR at MPP+1, 111, 125
- CR Edit, 180
- CR, EM, and NL (3287 only), 126
- CR, EM, & NL (3287 only), 113
- CR, LG Emulation, 216
- CTL VOLT FAIL \* message, 260
- Custom configurations, 48
- Customer Support Center, 16, 305
- C128 Mode Comp, 200
- C39 Compatbl., 184, 200

**D**

- Darker print, Integrated Print Management System, 42
- Data Bit 8, 202
  - Centronics (Parallel) submenu, 77
  - Dataproducts submenu, 79
- Data Carrier Detect (DCD), RS-232, 245
- Data Lines 1 through 8
  - Centronics Parallel Interface Signals, 237
  - Dataproducts Parallel Interface Signals, 235

- Data Polarity
  - Centronics (Parallel) submenu, 77
  - Dataproducts submenu, 79
- Data Protocol, Serial submenu, 82
- Data Set Ready (DSR), RS-232, 245
- Data Strobe
  - Centronics Parallel Interface Signals, 237
  - Dataproducts Parallel Interface Signals, 235
- Data Term Ready, Serial submenu, 84
- Data Terminal Ready (DTR), RS-232, 245
- Dataproducts Parallel Interface, 234
- Dataproducts Parallel Interface Signals, 235
  - Buffer Clear, 235
  - Cable Verify, 235
  - Data Lines 1 through 8, 235
  - Data Strobe, 235
  - Demand/Data Request, 235
  - Online, 235
  - Paper Instruction (PI), 235
  - Parity Error, 235
  - Ready, 235
- Dataproducts submenu, 79
  - Auto Trickle, 80
  - Buffer Size in K, 80
  - Data Bit 8, 79
  - Data Polarity, 79
  - Latch Data On, 80
  - PI Ignored, 79
  - Prime Signal, 80
  - Resp. Polarity, 80
  - TOF Action, 80
  - Trickle Time, 81
- DATE menu, 230
  - Day, 230
  - Hour, 230
  - Minute, 230
  - Month, 230
  - Year, 230
- Day, DATE menu, 230
- Default Code Page, IPDS Emulation, 207
- Default configurations, 48
- Default Font, IPDS Emulation, 208

Default WEP Key, WLAN PARAMS menu, 98  
 Define CR Code, 145, 179  
     ANSI Emulation menu, 172  
     Epson FX Emulation, 163  
     Proprinter XL Emulation, 159  
     P-Series XQ Emulation, 152  
     Serial Matrix Emulation, 155  
 Define LF Code, 146, 180  
     ANSI Emulation menu, 172  
     Epson FX Emulation, 163  
     Proprinter XL Emulation, 159  
     P-Series XQ Emulation, 153  
     Serial Matrix Emulation, 155  
 Delete Config., 70  
 Demand/Data Request, Dataproducts Parallel  
 Interface Signals, 235  
 Device Address, 117, 135  
 Device ID, 63, 117  
 DHCP  
     Adapter Address menu, 88  
     Ethernet Address menu, 91  
     WLAN Address menu, 94  
 DIAGNOSTIC PASSED message, 260  
 DIAGNOSTICS menu, 227  
     Paper Out Dots, 228  
     Print Statistics, 229  
     Printer Tests, 227  
     System Memory, 228  
     Test Width, 228  
 Dimensions, printer, 20, 287  
 Display Functions, PCL-II Emulation, 212  
 Display Language, PRINTER CONTROL, 220  
 DO NOT POWER OFF message, 260  
 Documentation list, 15  
 Downloaded Fonts, ADVANCED USER menu, 222  
 DP FIFO Busy\* message, 261  
 DRVRCIRBAD \* message, 261  
 D50 STATUS%XX Clearing Flash message, 260  
 D50 STATUS%XX Programming, 260  
 D55 STATUS Send Program to EC, 260

## E

E Net Test Unavailable, 272  
 Early Print Cmpl, 109  
     3270 Params menu, 123  
 Early Print Comp (Complete), IPDS Emulation, 207  
 Electrical Characteristics, 289  
 Elong/Alt. Font, P-Series XQ Emulation, 153  
 EMULATION Menu, 103  
 Emulation, IGP/PGL, 175  
 Energy Star compliance, 288  
 E-Net Adapter submenu, 86  
 ENTER key, 28  
 Environmental characteristics, 287  
 Epson FX Character Set menu, 165  
     PCL-II, 166  
 Epson FX Emulation, 163  
     Alt. Set 80-9F, 164  
     Auto LF, 163  
     Character Set, 164  
     Define CR Code, 163  
     Define LF Code, 163  
     Printer Select, 164  
     20 CPI Condensed, 164  
 ERROR CPLD NOT PROGRAMMED  
 message, 272  
 ERROR DC PROGRAM NOT VALID message, 272  
 ERROR DRAM AT ADDRESS XXXXXXXX  
 message, 273  
 ERROR EC PROGRAM NOT VALID message, 273  
 ERROR EC STOPPED AT STATE XXXX  
 message, 273  
 ERROR FLASH DID NOT PROGRAM  
 message, 273  
 ERROR FLASH NOT DETECTED message, 273  
 Error Handling, 200  
     Barcode Errors, 201  
     Error Markers, 201  
     Error Msgs, 200  
     Offpage Errors, 201  
 ERROR LOCKED SN=nnnnnnnnnnnnnnnnnnnnnnnnnnnnnn  
 message, 273  
 Error Markers, 201

---

Error Msgs, 200  
 ERROR NO DRAM DETECTED message, 273  
 ERROR NVRAM FAILURE message, 273  
 ERROR OCCURRED FLUSHING QUEUES\* message, 272  
 ERROR PROGRAM NEEDS MORE DRAM message, 273  
 ERROR PROGRAM NEEDS MORE FLASH message, 273  
 ERROR PROGRAM NOT COMPATIBLE message, 273  
 ERROR PROGRAM NOT VALID message, 274  
 Error Report, 187  
 ERROR SECURITY KEY NOT DETECTED message, 274  
 ERROR SHORT AT ADDRESS XXXX message, 274  
 ERROR WRITING TO FLASH message, 274  
 ERROR WRONG CHECKSUM message, 274  
 ERROR WRONG OEM message, 274  
 ERROR WRONG PRINTER TYPE message, 274  
 ESC c Sequence, ANSI Emulation menu, 173  
 ESC d command, Serial Matrix Emulation, 156  
 ETHERNET ADAPTER BEING INITIALIZED message, 274  
 Ethernet Address, 64  
 ETHERNET ADDRESS menu, 91
 

- DHCP, 91
- Gateway address, 91
- IP address, 91
- MAC address, 91
- Subnet mask, 91

 ETHERNET DETECTED message, 274  
 ETHERNET INITIALIZING message, 274  
 ETHERNET PARAMETERS menu
 

- ASCII data port, 92
- Ethernet speed, 93
- IPDS Data Port, 92
- Job Control, 93
- Keep alive timer, 92
- NetBIOS protocol, 92

 ETHERNET PARAMS menu, 92
 

- Ethernet speed, Adapter Params menu, 90
- Ethernet speed, Ethernet Parameters menu, 93
- Ethernet submenu, 86
  - Buffer Size in K, 86
- ETX/ACK, ANSI Emulation menu, 174
- EVFU, SPC Type, 136
- EXCESS RBN WEAR message, 275
- EXHAUST FAN FLT message, 275
- Expanded Font, 185, 197
- Ext Execute Copy, 182
- Exterior cleaning, 249
- E00 EXE @ ADDR0 message, 261
- E01A TYPE 0x40 message, 261
- E01B TYPE 0x60 message, 261
- E02 MACHINE CHK message, 262
- E03A DSI HASH L message, 262
- E03B DSI HASH S message, 262
- E03C DSI BAT PL message, 262
- E03D DSI BAT message, 263
- E03E DSI CXIWX message, 263
- E03F DSI CXOWX message, 263
- E03G DSI ECXIWX message, 263
- E03H DSI ECXOWX message, 264
- E04A ISI NO TRA message, 264
- E04B ISI DIRECT message, 264
- E04C ISI PROTEC message, 264
- E06 NOT ALIGNED message, 265
- E07 ILLEGAL INS message, 265
- E08 FLOATINGPNT message, 265
- E12 SYSTEM CALL message, 265
- E13 TRACE INT message, 266
- E16 ITRANS MISS message, 266
- E17 DLOAD MISS message, 266
- E18 DSTORE MISS message, 266
- E19 BREAKPOINT message, 267
- E20 SYS MANAGE message, 267
- E30 DEBUGGER message, 267
- E31A EVENT 0 BP message, 267
- E31B EVENT 1 BP message, 268
- E31C EVENT 2 BP message, 268
- E31D EVENT 3 BP message, 268
- E31E EVENT 4 BP message, 268

E31F EVENT 5 BP message, 269  
 E31G EVENT 6 BP message, 269  
 E31H EVENT 7 BP message, 269  
 E32A CND 0 BP message, 269  
 E32B CND 1 BP message, 270  
 E32C CND 2 BP message, 270  
 E32D CND 3 BP message, 270  
 E32E CND 4 BP message, 270  
 E32F CND 5 BP message, 271  
 E32G CND 6 BP message, 271  
 E32H CND 7 BP message, 271  
 E33 WRITE BP message, 271  
 E34 TRACE CMPLT message, 272  
 E99 UNKNOWN INT message, 272

## F

Face CPI Delay, PCL-II Emulation, 211  
 Fault messages, 254

A TO D OVERUN \*, 256  
 ACCESS NULL PTR \*, 256  
 ACTIVATE LOST, 256  
 BARCODE DAMAGED, 259  
 BARCODE MISSING, 259  
 BC SENSOR ERR, 259  
 BUFFER OVERRUN, 259  
 B00 STATUS SDRAM DETECTION  
     166MHZ, 256  
 B01 STATUS 8245 SDRAM TEST 32MB, 256  
 B10 ERROR NO DRAM DETECTED\*, 256  
 B11 ERROR RAM TEST FAILED\*, 257  
 B12 ERROR PROGRAM MISSING\*, 257  
 B13 ERROR NOT COMPATIBLE\*, 257  
 B19 ERROR DC RETURNED\*, 257  
 B20 STATUS 00% DOWNLOAD MODE, 257  
 B21 STATUS PRINTER RESET, 257  
 B22 ERROR DECOMPRESS SIZE\*, 257  
 B23 ERROR DECOMPRESS CKSUM\*, 257  
 B30 STATUS INITIALZING, 257  
 B35 STATUS WAITING FOR EC STATUS, 258  
 B40 ERROR SDRAM EE PROM CKSUM  
     BAD\*, 258  
 B41 ERROR DIM MEMORY NOT  
     SDRAM\*, 258

B42 ERROR SDRAM ROWS NOT  
     ALLOWED\*, 258  
 B43 ERROR SDRAM TOO MANY  
     BANKS\*, 258  
 B44 ERROR SDRAM NOT 64 BITS  
     WIDE\*, 258  
 B45 ERROR SDRAM IS WRONG  
     VOLTAGE\*, 258  
 B46 ERROR SDRAM HAS MIXED SIZES\*, 258  
 B47 ERROR SDRAM LARGER  
     THAN 256M\*, 258  
 B49 ERROR SDRAM # LOGICAL  
     BANKS\*, 258  
 B50 ERROR SDRAM LOGIC COMB  
     BANKS\*, 258  
 B51 XX% LOADING, 259  
 B53 ERROR 12C NO ARBITRATION, 259  
 B54 ERROR SDA LINE STUCK LOW, 259  
 CLEAR PAPER JAM, 260  
 CLEARING PROGRAM FROM FLASH, 260  
 CLOSE PLATEN, 260  
 CTL VOLT FAIL \*, 260  
 DIAGNOSTIC PASSED, 260  
 DO NOT POWER OFF, 260  
 DP FIFO Busy\*, 261  
 DRVR CIR BAD \*, 261  
 D50 STATUS%XX Clearing Flash, 260  
 D51 STATUS%XX Programming, 260  
 D55 STATUS Send Program to EC, 260  
 ERROR CPLD NOT PROGRAMMED, 272  
 ERROR DC PROGRAM NOT VALID, 272  
 ERROR DRAM AT ADDRESS  
     XXXXXXXX, 273  
 ERROR EC PROGRAM NOT VALID, 273  
 ERROR EC STOPPED AT STATE XXXX, 273  
 ERROR FLASH DID NOT PROGRAM, 273  
 ERROR FLASH NOT DETECTED, 273  
 ERROR LOCKED  
     SN=nnnnnnnnnnnnnnnnnnnnnnnnnnnn, 273  
 ERROR NO DRAM DETECTED, 273  
 ERROR NVRAM FAILURE, 273

---

ERROR OCCURRED FLUSHING  
  QUEUES\*, 272  
ERROR PRINTER TYPE, 274  
ERROR PROGRAM NEEDS MORE  
  DRAM, 273  
ERROR PROGRAM NEEDS MORE  
  FLASH, 273  
ERROR PROGRAM NOT COMPATIBLE, 273  
ERROR PROGRAM NOT VALID, 274  
ERROR SECURITY KEY NOT  
  DETECTED, 274  
ERROR SHORT AT ADDRESS XXXX, 274  
ERROR WRITING TO FLASH, 274  
ERROR WRONG CHECKSUM, 274  
ERROR WRONG OEM, 274  
ETHERNET ADAPTER BEING  
  INITIALIZED, 274  
ETHERNET DETECTED, 274  
ETHERNET INITIALIZING, 274  
EXCESS RBN WEAR, 275  
EXHAUST FAN FLT, 275  
E00 EXE @ ADDR0, 261  
E01A TYPE 0x40, 261  
E01B TYPE 0x60, 261  
E02 MACHINE CHK, 262  
E03A DSI HASH L, 262  
E03B DSI HASH S, 262  
E03C DSI BAT PL, 262  
E03D DSI BAT, 263  
E03E DSI CXIWX, 263  
E03F DSI CXOWX, 263  
E03G DSI ECXIWX, 263  
E03H DSI ECXOWX, 264  
E04A ISI NO TRA, 264  
E04B ISI DIRECT, 264  
E04C ISI PROTEC, 264  
E06 NOT ALIGNED, 265  
E07 ILLEGAL INS, 265  
E08 FLOATINGPNT, 265  
E12 SYSTEM CALL, 265  
E13 TRACE INT, 266  
E16 ITRANS MISS, 266  
E17 DLOAD MISS, 266  
E18 DSTORE MISS, 266  
E19 BREAKPOINT, 267  
E20 SYS MANAGE, 267  
E30 DEBUGGER, 267  
E31A EVENT 0 BP, 267  
E31B EVENT 1 BP, 268  
E31C EVENT 2 BP, 268  
E31D EVENT 3 BP, 268  
E31E EVENT 4 BP, 268  
E31F EVENT 5 BP, 269  
E31G EVENT 6 BP, 269  
E31H EVENT 7 BP, 269  
E32A CND 0 BP, 269  
E32B CND 1 BP, 270  
E32C CND 2 BP, 270  
E32D CND 3 BP, 270  
E32E CND 4 BP, 270  
E32F CND 5 BP, 271  
E32G CND 6 BP, 271  
E32H CND 7 BP, 271  
E33 WRITE BP, 271  
E34 TRACE CMPLT, 272  
E99 UNKNOWN INT, 272  
FIRMWARE ERROR, 275  
FM HEADER ERROR, 275  
FRAMING ERROR, 275  
GRF CHECK ERROR PRESS STOP, 275  
HAMMER COIL BAD, ###, 276  
HAM. COIL OPEN \*, 276  
HB NOT INSTALLD \*, 276  
HMR BANK FAN FLT, 277  
H00: PCI SLOT ?, 275  
H01: PCI J12, 276  
H02: PCI J13, 276  
ILL EXT BUS ACC \*, 277  
ILLGL OPR ACCSS \*, 277  
INCOMPAT E-NET, 277  
INTAKE FAN FAULT, 277  
INTERRUPT UNUSED VECTOR 00, 277  
INVALID ACTIVATE, 277  
INVALID COMMAND, 277

---

LO DRV. SHORT \*, 278  
 LOAD PAPER, 278  
 LOADING PROGRAM FROM PORT XX%, 278  
 LOADING PROGRAM INTO FLASH, 278  
 NEW SPX DETECTED, 278  
 NON VOLATILE MEMORY FAILED, 278  
 OLD RIBBON, 278  
 ON LINE, 278  
 ONLINE CU TIMED OUT, 279  
 ONLINE 28 CU NOT ENAB, 278  
 ONLINE 8344 FAILED, 278  
 PAP BAD TABLE \*, 279  
 PAP BSY TOO LNG \*, 279  
 PAP FIFO OVERFL \*, 279  
 PAP FIFO UNDRFL \*, 279  
 PAP ILLGL ST \*, 279  
 PAP INCMPL ENER \*, 279  
 PAP INVLD CMD \*, 279  
 PAP INVLD PARM \*, 279  
 PAP NOT SCHED \*, 279  
 PAP NT AT SPEED \*, 279  
 PAP UNEXP INT \*, 280  
 PARAMETER ERROR, 280  
 PARITY ERROR, 280  
 PLAT INV CMD \*, 280  
 PLAT INV PARM \*, 280  
 PLAT INV STATE \*, 280  
 PLEASE WAIT...RESET IN PROGRESS, 280  
 POWERSUPPLY HOT \*, 280  
 PRINTER HOT \*, 280  
 PRINTER UNDER REMOTE CONTROL, 280  
 PROTECTED INSTR \*, 280  
 PWRSUPP VOLT \*, 281  
 QUEUE OVERRUN\*, 281  
 RBN AT END POINT, 281  
 REMOVE USED SPX, 281  
 RESTORING BOOT CODE, 281  
 RIB INVLD CMD\*, 281  
 RIBBON STALL, 281  
 RIBBON UNDER 2%, 281  
 SCS COMMAND ERROR, 281  
 SECURITY KEY NOT DETECTED, 281  
 SECURITY VIOLATION, 281  
 SENDING PROGRAM TO EC  
     PROCESSOR, 282  
 SF ERROR, 282  
 SHUTL INV CMD \*, 282  
 SHUTL INV PARM \*, 282  
 SHUTL OVR SPEED\*, 282  
 SHUTTLE JAM, 282  
 SHUTTLE STALL, 282  
 SHUTTLE TYPE NOT SUPPORTED\*, 282  
 SOFTWARE ERROR\* CYCLE POWER, 282  
 SPX FOUND, ERROR KEY NOT  
     DETECTED, 283  
 SPX NOT NEEDED OPTIONS ENABLED, 283  
 SSTACKER JAM, 283  
 STACK OVERFLOW\*, 283  
 STACK UNDERFLOW\*, 283  
 STACKER FAULT, 283  
 STACKER FULL, 283  
 TCB CORRUPTED\*, 283  
 TCP PORT BUSY, 283  
 UNDEF INTERRUPT\*, 283  
 UNDFNED OPCODE\*, 283  
 UNKNOWN RBN1, 284  
 UNKNOWN RBN2, 284  
 UP DRV. SHORT\*, 284  
 WAITING FOR ETHERNET ADAPTER, 284  
 06 HOST REQUEST, 254  
 08 HOLD PRINT TIMEOUT, 254  
 15 COMM CHECK, 255  
 15V PWR FAIL \*, 255  
 22 INVALID ADDR, 255  
 23.5V PWR FAIL \*, 255  
 31 PAPER OUT TIMEOUT, 255  
 32 PAPER JAM TIMEOUT, 255  
 33 PLATEN OPEN TIMEOUT, 255  
 34 RIBBON STALL TIMEOUT, 255  
 426 BC READ ERR, 256  
 48V CIRCUIT\*, 255  
 48V PWR FAIL \*, 255  
 733 DP FIFO Busy\*, 256  
 8.5V PWR FAIL \*, 254

---

Fault, Centronics Parallel Interface Signals, 237  
Features, printer, 11  
FF After Job, 113, 126  
FF Valid at TOF, Proprinter XL Emulation, 159  
FF Validity, 112, 126  
FF, LG Emulation, 217  
File System, ADVANCED USER menu, 223  
FIRMWARE ERROR message, 275  
FM HEADER ERROR message, 275  
Font Attributes, 140  
    ANSI Emulation menu, 170  
Font Set, 202  
Font Size, IPDS Emulation, 206  
Font, LG Emulation, 215  
Form Length, 66, 67  
Form Width, 66, 67  
Format Control, 113, 120  
    3270 Params menu, 127  
    5250 Params menu, 132  
Forms Handling, 181  
FRAMING ERROR message, 275  
Framing Errors, Serial submenu, 85

## G

Gateway address  
    Adapter Address menu, 88  
    Ethernet Address menu, 91  
    WLAN Address menu, 94  
Graphic CharSize, IPDS Emulation, 207  
Graphic Chek Cod, 119  
Graphic Chek Cod, 5250 Params menu, 131  
Graphic Chek Err, 118  
Graphic Chek Err, 5250 Params menu, 131  
Graphics Density, PCL-II Emulation, 211  
Graphics enhancement, 14  
Graphics Options, 196  
    Absorb After ^PN, 199  
    Absorb After ^PY, 197  
    AI 00 Spaces, 198  
    Append Rotated, 196  
    Auto FF at ^PN, 200  
    C128 Mode Comp, 200  
    C39 Compatbl., 200

Expanded Font, 197  
Ignore Dots, 196  
Ignore Spaces, 197  
Ignore ^Lxx Cmd., 200  
IGP110 Compatbl., 199  
I25 Selection, 198  
LP+ Font, 198  
Midline PY (includes ^PN), 197  
MSI Check Digit, 198  
PDF Size Comp., 200  
Print Quality, 197  
Rot. Char Size, 197  
Slash 0, 196  
True Vert 1/10, 196  
Truncate Alpha, 196  
UPC Descenders, 197  
Width Limit, 199  
Graphics Print, IPDS Emulation, 206  
Graphics Quality, IPDS Emulation, 206  
Graphics Scaling, IPDS Emulation, 207  
GRF CHECK ERROR PRESS STOP  
message, 275

## H

HAMMER COIL BAD, ### Message, 276  
HAM. COIL OPEN \* message, 276  
HB NOT INSTALLED \* message, 276  
Hex Dump Mode, MAINT/MISC menu, 222  
Hex Dump, printing, 253  
Hexdump Mode, IPDS Emulation, 208  
HMR BANK FAN FLT Message, 277  
Horiz Forms, 67  
Horiz Forms, LG Emulation, 216  
Host Command, 140  
Host Form Length, 184  
Host Interface, 63  
HOST INTERFACE menu, 72  
Host Override, 113, 119  
    3270 Params menu, 126  
    5250 Params menu, 131  
Host PI, 202  
Hour, DATE menu, 230  
HS Print (High Speed Print), P-Series XQ

---

Emulation, 153  
H00: PCI SLOT ? message, 275  
H01: PCI J12 message, 276  
H02: PCI J13 message, 276

|

I 2/5 Selection, 183  
Idle Response, Serial submenu, 85  
IEEE 1284 Parallel Interface, 238  
    Byte Mode, 238  
    Compatibility Mode, 238  
    Nibble Mode, 238  
    Signals, 239  
IEEE 1284 Parallel (Bidirectional) Submenu, 75  
    Auto Trickle, 75  
    Buffer Size in K, 75  
    Offline Process, 76  
    Prime Signal, 75  
    TOF Action, 75  
    Trickle Time, 76  
Ignore Char, 185  
Ignore Chars, 201  
Ignore CH#1, 201  
Ignore CH#2, 201  
Ignore Dots, 196  
Ignore Spaces, 197  
Ignore ^Lxx Cmd., 200  
Ignore/DB8 Setup, 201  
    Data Bit 8, 202  
    Ignore Chars, 201  
    Ignore CH#1, 201  
    Ignore CH#2, 201  
IGP/PGL Emulation, 175  
    configuring with the control panel, 176  
IGP/PGL submenu, 177  
    Auto Uppercase, 181  
    Autowrap, 180  
    Barcode Options, 182  
    Compatbl. Mode, 185  
    Compressed CPI, 184  
    CR Edit, 180  
    Define CR (Carriage Return) Code, 179  
    Define LF (Line Feed) Code, 180  
Error Report, 187  
Expanded Font, 185  
Ext Execute Copy, 182  
Forms Handling, 181  
Host Form Length, 184  
Ignore Char, 185  
LG, 179  
PCL-II, 178  
PGL SFCC, 180  
PI Slew Range, 180  
Power On IGP/PGL, 182  
Power on S-Mode, 186  
Print Quality, 186  
Printer PI Line, 186  
Scalable Size, 185  
Select Font, 180, 187  
Select LPI, 181  
Skip Cmd Prefix, 181  
Slash 0, 181  
True Form Slew, 186  
Trunc Dyn Data, 187  
Var Form Adjust, 184  
Var Form Type, 184  
IGP/PGL, Font Set menu, 188  
IGP/VGL Emulation, 189  
    configuring with the control panel, 190  
IGP/VGL Font Set Menu, 204  
IGP/VGL submenu, 190  
    Error Handling, 200  
    Font Set, 202  
    Graphics Options, 196  
    Ignore/DB8 Setup, 201  
    LG, 194  
    LPI, 196  
    PCL-II, 192  
    PI Control, 202  
    Prt to Emulate, 203  
    SFCC & Pwrap, 195  
IGP110 Compatbl., 199  
ILL EXT BUS ACC \* message, 277  
ILLGL OPR ACCSS \* message, 277  
Image Buf Size, 111



---

INCOMPAT E-NET message, 277  
INTAKE FAN FAULT message, 277  
Integrated Print Management System, 12, 42  
    Darker Print, 42  
    Lighter Print, 42  
Interface Type, Serial submenu, 82  
Interfaces  
    printer, 233  
    specifications, 289  
Interior cleaning, 250  
Internat. Mode, WLAN PARAMS menu, 97  
INTERRUPT UNUSED VECTOR 00 message, 277  
Intervention Req, 111, 133  
Intervention Req, 3270 Params menu, 124  
INVALID ACTIVATE message, 277  
INVALID COMMAND message, 277  
IP address  
    Adapter Address menu, 87  
    Ethernet Address menu, 91  
    WLAN Address menu, 94  
IPDS Data Port, Adapter Params menu, 89  
IPDS Data Port, Ethernet Parameters menu, 92  
IPDS Emulation, 205  
    Barcode Quality, 206  
    Barcode Size, 207  
    Barcode Speed, 206  
    Code Page Subset, 208  
    Default Code Page, 207  
    Default Font, 208  
    Early Print Comp (Complete), 207  
    Font Size, 206  
    Graphic CharSize, 207  
    Graphics Quality, 206  
    Graphics Scaling, 207  
    Hexdump Mode, 208  
    I2/5 Checksum, 207  
    Print IPDS Fonts, 208  
    Print Quality, 206  
    VPA Check, 208  
I2/5 Checksum, IPDS Emulation, 207  
I-2/5 Guard Bars, LG Emulation, 217  
I25 Selection, 198

## J

Job Control, Adapter Params menu, 90  
Job Control, Ethernet Parameters menu, 93  
JOB SELECT key, 28

## K

KDC Port Number, WLAN Kerberos menu, 100  
Keep alive timer, Adapter Params menu, 90  
Keep alive timer, Ethernet Parameters menu, 92  
Kerberos Enable, WLAN Kerberos menu, 99  
Kerb. Passwrd, WLAN Kerberos menu, 100

## L

Label specifications, 286  
LAC Approx., 119  
LAC Option, 119  
Last Char = FF, 112, 125  
Latch Data On  
    Centronics (Parallel) submenu, 77  
    Dataproducts submenu, 80  
Lead-in Chars, 110  
    PTX Transparent, 118  
LEAP Password, WLAN LEAP menu, 101  
LEAP Username, WLAN LEAP menu, 101  
LG Emulation  
    Autowrap, 216  
    CR, 216  
    FF, 217  
    Font, 215  
    Horiz Forms, 216  
    I-2/5 Guard Bars, 217  
    LP, 216  
    Plot Mode Opt, 217  
    Print Mode Opt, 217  
    Unsolicited Rpt, 217  
    Vert Forms, 215  
Lighter print, Integrated Print Management System, 42  
Line Terminator, PCL-II Emulation, 212  
LinePrinter Plus Emulation submenu, 137  
    Barcode x-Offset, 143  
    CPI/LPI Select, 139

---

Font Attributes, 140  
Host Command, 140  
Page Format, 142  
PCL-II, 139  
Print Char. Set, 143  
Printer Protocol, 139  
Reset Cmd CFG Ld, 143  
Set Substitution, 143  
LO DRV. SHORT \* message, 278  
Load Config., 70  
LOAD PAPER message, 278  
LOADING PROGRAM FROM PORT XX%  
message, 278  
LOADING PROGRAM INTO FLASH message, 278  
Loading Used Ribbon, 13  
Logical Buf Size, 133  
LPI, 196  
LPI Adjust, PCL-II Emulation, 212  
LP+ Font, 198  
LP, LG Emulation, 216

## M

MAC address  
    Adapter Address menu, 88  
    Ethernet Address menu, 91  
    WLAN Address menu, 94  
Main menu, 59  
Maintenance, 14  
MAINT/MISC menu  
    Hex Dump Mode, 222  
    Power-Up State, 222  
    PTX Setup Option, 222  
Manual  
    conventions, 15  
    related documents, 15  
    special information, 15  
    warnings, 15  
Margins, 66  
Max Line Width, 67  
Max Line Width, PCL-II Emulation, 211  
Max PI 16, 202

Max. Print Width, 114, 120  
    3270 Params menu, 127  
    5250 Params menu, 132

## Menu

ACTIVE IGP EMUL, 102  
ADVANCED USER, 221  
CONFIG. CONTROL, 69  
DATE, 230  
DIAGNOSTICS, 227  
EMULATION, 103  
HOST INTERFACE, 72  
IGP/PGL Font Set, 188  
Main, 59  
    navigating, 48  
NETWORK SETUP, 87  
PRINTER CONTROL, 218  
Printer MGMT, 231  
ZTP SETTINGS, 68  
Mgmt Port Number, Printer MGMT, 231  
Mgmt Protocol, Printer MGMT, 231  
Midline PY (includes ^PN), 197  
Min Xfer Rate, WLAN PARAMS menu, 96  
Minute, DATE menu, 230  
Month, DATE menu, 230  
MSI Check Digit, 198

## N

Name Configs, 71  
Navigating the menus, 48  
Nest Serv Type, Adapter Params menu, 89  
NetBIOS protocol, Adapter Params menu, 89  
NetBIOS protocol, Ethernet Parameters menu, 92  
NETWORK SETUP menu, 87  
    ADAPTER ADDRESS, 87  
    ETHERNET ADDRESS, 91  
    ETHERNET PARAMS, 92  
    WLAN ADDRESS, 94  
    WLAN PARAMS, 95  
NEW SPX DETECTED message, 278  
Nibble Mode, IEEE 1284 Parallel Interface, 238  
NL At MPP+1, 111, 125, 134  
noise level, acoustic, 288  
NON VOLATILE MEMORY FAILED message, 278

---

Novell frame, Adapter Params menu, 89  
Novell Protocols, 88  
Novell protocol, Adapter Params menu, 89  
Null Suppression, 112, 125

## O

Offline Process  
    IEEE 1284 Parallel (Bidirectional) Submenu, 76  
Offpage Errors, 201  
OLD RIBBON message, 278  
ON LINE key, 26  
ON LINE message, 278  
One Char Enquiry, Serial submenu, 85  
Online  
    Centronics Parallel Interface Signals, 237  
    Dataproducts Parallel Interface Signals, 235  
ONLINE CU TIMED OUT message, 279  
ONLINE 28 CU NOT ENAB message, 278  
ONLINE 8344 FAILED message, 278  
Open Platen @ BOF (Bottom of Form)  
    PRINTER CONTROL, 219  
Operating modes, 25  
Operation Mode, WLAN PARAMS menu, 96  
Operational procedures  
    cancel a print job, 46  
    reload paper, 30  
    unload paper, 39  
Optimized Ratio, 183  
Optimizing print quality, 57  
Optimizing print speed, 58  
Output Darkness, 13  
Overstrike, 146  
    Serial Matrix Emulation, 155  
Overview, printer models, 11

## P

Page Format, 142  
    ANSI Emulation menu, 171  
Page Length Rep, 67  
Page Length Rep, PCL-II Emulation, 211  
Page L./Inches, PCL-II Emulation, 212  
Page L./Lines, PCL-II Emulation, 212  
PAP BAD TABLE \* message, 279

PAP BSY TOO LNG \* message, 279  
PAP FIFO OVERFL \* message, 279  
PAP FIFO UNDRFL \* message, 279  
PAP ILLGL ST \* message, 279  
PAP INCMPL ENER \* message, 279  
PAP INVLD CMD \* message, 279  
PAP INVLD PARM \* message, 279  
PAP NOT SCHED \* message, 279  
PAP NT AT SPEED \* message, 279  
PAP UNEXP INT \* message, 280  
Paper  
    reload, 30  
    unload, 39  
PAPER ADVANCE key, 26  
Paper Empty (PE)  
    Centronics Parallel Interface Signals, 237  
Paper Instruction (PI)  
    Centronics Parallel Interface Signals, 237  
    Dataproducts Parallel Interface Signals, 235  
Paper Out Dots, DIAGNOSTICS, 228  
Paper specifications, 286  
Parallel Interface  
    Centronics, 236  
    Dataproducts, 234  
PARAMETER ERROR message, 280  
Parameter settings  
    changing, 47  
    saving, 47  
Parameters, changing, example, 49  
Parity Error  
    Dataproducts Parallel Interface Signals, 235  
PARITY ERROR message, 280  
Parity, Serial submenu, 84  
PA1, 108, 133  
PA2, 109, 134  
PCL-II Emulation, 209  
    Config Print, 213  
    Display Functions, 212  
    Face CPI Delay, 211  
    Graphics Density, 211  
    Line Terminator, 212  
    LPI Adjust, 212

---

Max Line Width, 211  
 Page Length Rep, 211  
 Page L./Inches, 212  
 Page L./Lines, 212  
 Perforation Skip, 211  
 Primary Char. Set, 211  
 PTX Linefeed, 212  
 Reset Cmd CFG Ld, 213  
 Second Char. Set, 211  
 Symbol Set Print, 213  
 PDF Size Comp., 200  
 Perforation Skip, PCL-II Emulation, 211  
 PGL SFCC, 65, 180  
 PI Control, 202  
     Host PI, 202  
     Max PI 16, 202  
     Printer PI, 202  
 PI Ignored  
     Centronics (Parallel) submenu, 77  
     Dataproducts submenu, 79  
 PI Slew Range, 180  
 PLAT INV CMD \* message, 280  
 PLAT INV PARM \* message, 280  
 PLAT INV STATE \* message, 280  
 PLEASE WAIT...RESET IN PROGRESS  
 message, 280  
 Plot Mode Opt, LG Emulation, 217  
 PMD (Paper Motion Detection) Fault, ADVANCED  
 USER, 223  
 PNE Port Number, Printer MGMT, 231  
 PNE Port Timeout, Printer MGMT, 231  
 PNE Port, Printer MGMT, 231  
 Poll Character, Serial submenu, 85  
 Poll Response, Serial submenu, 85  
 Port Type, Auto Switching submenu, 74  
 Position Aft FF (4234 only), 112, 125  
 Pos. on BC/OvrSz, ANSI Emulation menu, 174  
 Power Consumption, 289  
 Power Mgmt, WLAN PARAMS menu, 97  
 Power On IGP/PGL, 182  
 Power requirements, 19  
 Power Saver Time, ADVANCED USER, 225  
 Power Stacker, ADVANCED USER menu, 223  
 POWER SUPPLY HOT \* message, 280  
 Power Up ^ F, 195  
 Power Up ^ X, 195  
 Power Up ^PY, 196  
 Powering on the printer, 25  
 Power-on S-Mode, 186  
 Power-Up Config, 68  
 Power-Up Config., 70  
 Power-Up State, MAINT/MISC menu, 222  
 Preamble, WLAN PARAMS menu, 97  
 PREV or NEXT key, 28  
 PREV + NEXT key, 28  
 Primary Char. Set, PCL-II Emulation, 211  
 Prime Signal  
     Centronics (Parallel) submenu, 77  
     Dataproducts submenu, 80  
     IEEE 1284 Parallel (Bidirectional) Submenu, 75  
 Prime, Centronics Parallel Interface Signals, 237  
 Print Char. Set, 143  
 Print Config., 70  
 Print IPDS Fonts, IPDS Emulation, 208  
 Print job, cancel, 46  
 Print Mode Opt, LG Emulation, 217  
 Print Quality, 186, 197  
     optimizing, 57  
 Print speed, optimizing, 58  
 Print Statistics, DIAGNOSTICS, 229  
 Printer  
     component locations, 23  
     control panel, 26  
     dimensions, 20, 287  
     exterior cleaning, 249  
     features, 11  
     interior cleaning, 250  
     maintenance, 14  
     models, 11  
     operating modes, 25  
     powering on, 25  
     site requirements, 19  
     weight, 287  
 PRINTER CONTROL menu, 218

---

Accented Char, 220  
Bar Code Quality, 219  
Display Language, 220  
Open Platen @ BOF (Bottom of Form), 219  
RBN End Action, 226  
RBN Low Action, 226  
RBN Low Warn @, 226  
Ribbon End Point, 218  
Tear Bar Dist. (Distance), 219  
Unidirectional, 219  
View Function, 219  
PRINTER HOT \* message, 280  
Printer interfaces, 233  
Printer MGMT menu, 231  
    Mgmt Port Number, 231  
    Mgmt Protocol, 231  
    PNE Port, 231  
    PNE Port Number, 231  
    PNE Port Timeout, 231  
    Status Port Numb, 231  
Printer PI, 202  
Printer PI Line, 186  
Printer Protocol, 66, 139  
Printer Select  
    ANSI Emulation menu, 173  
    Epson FX Emulation, 164  
    Serial Matrix Emulation, 156  
Printer Tests, DIAGNOSTICS, 227  
Printer Type, SPC Type, 136  
PRINTER UNDER REMOTE CONTROL  
message, 280  
Printing rates, 290  
Printing, Hex Dump, 253  
PrintNet Enterprise, consumable monitoring, 14  
Private Mode, ANSI Emulation menu, 173  
Proprinter XL Character Set menu, 161  
    LG, 162  
    PCL-II, 162  
Proprinter XL Emulation, 159  
    Alt. Char Set, 160  
    Auto LF, 159  
    Character Set, 160  
    Define CR Code, 159  
    Define LF Code, 159  
    FF Valid at TOF, 159  
    20 CPI Condensed, 160  
Protect Configs., 70  
PROTECTED INSTR \* message, 280  
PRT CONFIG key, 27  
Prt Partial Line, 108, 117  
    3270 Params menu, 123  
    5250 Params menu, 130  
Prt to Emulate, 203  
P-Series Character Set menu, 148  
    LG, 151  
    PCL-II, 150  
PSeries Dbl High, 147  
P-Series Emulation, 144, 145  
    Alt. Set 80-9F, 147  
    Auto LF, 146  
    Character Set, 147  
    Control Code 06, 145  
    Control Code 08, 145  
    Define CR Code, 145  
    Define LF Code, 146  
    FF Valid at TOF, 147  
    LG, 145  
    Overstrike, 146  
    PCL-II, 144  
    PSeries Dbl High, 147  
    P-Series SFCC, 146  
    SFCC d Command, 147  
    VFU Select, 147  
P-Series SFCC, 66, 146  
P-Series XQ Emulation, 152  
    Auto LF, 152  
    Compressed Print, 153  
    Control Code 06, 152  
    Define CR Code, 152  
    Define LF Code, 153  
    Elong/Alt. Font, 153  
    HS Print (High Speed Print), 153  
    Slew Relative, 154

---

Upr. Case Select, 154  
VFU Select, 153  
PTX Linefeed, PCL-II Emulation, 212  
PTX Setup Option, MAINT/MISC menu, 222  
PTX Transparent, 110, 118  
    Alt. Set 80-9F, 110, 118  
    Lead-in Chars, 110, 118  
    Usr Defined HTRN, 110, 118  
    3270 Params menu, 123  
    5250 Params menu, 130  
PUM Default, ANSI Emulation menu, 174  
Pwr Save Control, ADVANCED USER, 225  
PWRSUPP VOLT \* message, 281

## Q

QUEUE OVERRUN\* message, 281  
QUICK SETUP menu  
    Active Emulation, 65  
    Active IGP Emulation, 65  
    Adapter Address, 64  
    Device ID, 63  
    Ethernet Address, 64  
    Form Length, 66, 67  
    Form Width, 66, 67  
    Horiz Forms, 67  
    Host Interface, 63  
    Margins, 66  
    Max Line Width, 67  
    Page Length Rep, 67  
    PGL SFCC, 65  
    Power-Up Config, 68  
    Printer Protocol, 66  
    P-Series SFCC, 66  
    Ribbon End Point, 68  
    Save Config, 68  
    Select CPI, 66  
    Select LPI, 66  
    Vert Forms, 67  
    WLAN Address, 64  
    ZTP Data Time, 65  
    ZTP TearDistance, 65  
    ZTP Wait Time, 65

## R

RBN AT END POINT message, 281  
RBN End Action, PRINTER CONTROL, 226  
RBN Low Action, PRINTER CONTROL, 226  
RBN Low Warn @, PRINTER CONTROL, 226  
Ready, Dataproducts Parallel Interface Signals, 235  
Receive Data (RD), RS-232, 245  
Received CR, ANSI Emulation menu, 173  
Received DEL, ANSI Emulation menu, 173  
Reload paper, 30  
REMOVE USED SPX message, 281  
Renew Lifetime, WLAN Kerberos menu, 100  
Report Status, Auto Switching submenu, 74  
Request to Send  
    RS-232, 245  
    Serial submenu, 84  
Requirements  
    power, 19  
    printer site, 19  
Reset Cfg Names, 71  
Reset Cmd CFG Ld, 143  
    ANSI Emulation menu, 173  
Reset Cmd CFG Ld, PCL-II Emulation, 213  
Reset Kerb. Pwd, WLAN Kerberos menu, 100  
Reset LEAP Password, WLAN LEAP menu, 101  
Reset LEAP User, WLAN LEAP menu, 101  
Reset SSID Name, WLAN PARAMS menu, 96  
Reset WEP Keys, WLAN PARAMS menu, 98  
Reset WPA P-Phs, WLAN PARAMS menu, 99  
Resistor configurations, terminating, 241  
Resistors  
    installation, 243  
    removal, 243  
Resistors, terminating  
    location of, 243  
Resp. Polarity  
    Centronics (Parallel) submenu, 77  
    Dataproducts, 80  
RESTORING BOOT CODE message, 281  
RIB INVLD CMD\* message, 281

---

Ribbon Barcode  
    clean, 45, 251  
Ribbon End Point, 68  
Ribbon End Point, PRINTER CONTROL, 218  
Ribbon Flipping, 13  
Ribbon Log, 13  
RIBBON STALL message, 281  
RIBBON UNDER 2% message, 281  
Ribbons, changing, 43  
Rot. Char Size, 197  
RS-232, 244  
    Clear to Send (CTS), 245  
    Data Carrier Detect (DCD), 245  
    Data Set Ready (DSR), 245  
    Data Terminal Ready (DTR), 245  
    Receive Data (RD), 245  
    Request to Send (RTS), 245  
    Transmit Data (TD), 245  
RS-232 Serial Interfaces, 244  
RS-422, 245  
RS-422 Serial Interfaces, 244

**S**

Save Config, 68, 70  
Save, Auto, 52  
Saving new configurations, 52  
Saving parameter settings, 47  
Scalable Size, 185  
SCS Buffer Cntrl, 109  
SCS COMMAND ERROR message, 281  
Second Char. Set, PCL-II Emulation, 211  
SECURITY KEY NOT DETECTED message, 281  
SECURITY VIOLATION message, 281  
Select CPI, 66  
Select Font, 180, 187  
Select LPI, 66, 181  
Select SO Char, 183  
SENDING PROGRAM TO EC PROCESSOR  
message, 282  
Serial Interfaces  
    RS-232, 244  
    RS-422, 244  
Serial Matrix Character Set menu, 157

Serial Matrix Emulation, 154  
    Alt. Set 80-9F, 156  
    Auto LF, 155  
    Character Set, 156  
    Control Code 06, 155  
    Define CR Code, 155  
    Define LF Code, 155  
    ESC d command, 156  
    Overstrike, 155  
    Printer Select, 156  
Serial submenu, 81  
    Baud Rate, 83  
    Buffer Size in K, 84  
    Data Protocol, 82  
    Data Term Ready, 84  
    Framing Errors, 85  
    Idle Response, 85  
    Interface Type, 82  
    One Char Enquiry, 85  
    Parity, 84  
    Poll Character, 85  
    Poll Response, 85  
    Request to Send, 84  
    Stop Bits 1, 84  
    Word Length, 84  
Set Lock Key, ADVANCED USER menu, 225  
Set Sharing, ADVANCED USER menu, 224  
Set Text Orientn, 111, 119  
    3270 Params menu, 124  
    5250 Params menu, 131  
SET TOF key, 27  
SF ERROR message, 282  
SFCC Char, SPC Type, 136  
SFCC d Command, 147  
SFCC & Pwrap, 195  
    Power Up ^ F, 195  
    Power Up ^ PY, 196  
    Power Up ^ X, 195  
    VGL SFCC, 195  
SHUTL INV CMD \* message, 282  
SHUTL INV PARM \* message, 282  
SHUTL OVR SPEED\* message, 282

---

SHUTTLE JAM message, 282

SHUTTLE STALL message, 282

Shuttle Timeout, ADVANCED USER menu, 224

SHUTTLE TYPE NOT SUPPORTED\* message, 282

Signal Strength, WLAN PARAMS menu, 96

Signals

- Centronics Parallel Interface, 237
- Dataproducts Parallel Interface, 235
- IEEE 1284 Parallel Interface, 239

Simple Prot Conv, 105

Site requirements, 19

Skip Cmd Prefix, 181

Slash 0, 181, 196

Slew Relative, P-Series XQ Emulation, 154

Slow Paper Slew, ADVANCED USER menu, 224

SOFTWARE ERROR\* CYCLE POWER message, 282

SPC Char Set, SPC Type, 136

SPC Coax Params, 132

- Buffer Print, 133
- Buffer Reprint, 134
- Column 132 Wrap, 133
- Intervention Req, 133
- Logical Buf Size, 133
- NL At MPP+1, 134
- PA1, 133
- PA2, 134
- SPC Null Supp, 134
- SPC Space Supp, 134
- Translation Tbl, 133
- Usr Defined HTRN, 133

SPC Null Supp, 134

SPC Space Supp, 134

SPC Twx Params, 135

- Buffer Print, 136
- SPC Type, 136
- Translation Tbl, 136

SPC Type, 136

- EVFU, 136
- Printer Type, 136
- SFCC Char, 136
- SPC Char Set, 136
- Usr Defined HTRN, 136

Special information, 15

Specifications

- interfaces, 289
- label, 286
- paper, 286

Speed print, 290

SPX FOUND, ERROR KEY NOT DETECTED message, 283

SPX NOT NEEDED OPTIONS ENABLED message, 283

SSID Name, WLAN PARAMS menu, 96

STACK FAULT message, 283

STACK OVERFLOW\* message, 283

STACK UNDERFLOW\* message, 283

STACKER FULL message, 283

STACKER JAM message, 283

Standard, CTHI, 104

Status Port Numb, Printer MGMT, 231

Stop Bits 1, Serial submenu, 84

Submenu

- IGP/PGL, 177
- IGP/PGL with LG, 179
- IGP/PGL with PCL-II, 178
- IGP/VGL, 190
- IGP/VGL with LG, 194
- IGP/VGL with PCL-II, 192

Subnet mask

- Adapter Address menu, 87
- Ethernet Address menu, 91
- WLAN Address menu, 94

Supplies Department, 16, 305

Switch Out On, Auto Switching submenu, 74

Symbol Set Print, PCL-II Emulation, 213

System Memory, DIAGNOSTICS, 228

**T**

TCB CORRUPTED\* message, 283

TCP PORT BUSY message, 283

Tear Bar Dist. (Distance), PRINTER CONTROL, 219

Terminating resistor configurations, 241



---

Terminating resistors  
location of, 243

Test Width, DIAGNOSTICS, 228

Ticket Lifetime, WLAN Kerberos menu, 100

Timeout, Auto Switching submenu, 74

TOF Action  
Centronics (Parallel) submenu, 78  
Dataproducts submenu, 80  
IEEE 1284 Parallel (Bidirectional) Submenu, 75

Translate Table, 113

Translation Tbl, 108, 133  
SPC Twx Params, 136  
3270 Params menu, 123  
5250 Params menu, 130

Transmit Data (TD), RS-232, 245

Transmit Power, WLAN PARAMS menu, 97

Trickle Time  
Centronics (Parallel) submenu, 78  
Dataproducts submenu, 81  
IEEE 1284 Parallel (Bidirectional) Submenu, 76

Trickle Time, Auto Switching submenu, 74

True Form Slew, 186

True Vert 1/10, 196

Trunc Dyn Data, 187

Truncate Alpha, 196

Truncate PI Slew, ANSI Emulation menu, 174

Twinax Params menu, 115  
Active Char Set, 117  
Buffer Print, 120  
Cancel IGP/DCU, 117  
Char Set Select, 117  
Device Address, 117  
Device ID, 117  
Format Control, 120  
Graphic Chek Cod, 119  
Graphic Chek Err, 118  
Host Override, 119  
LAC Approx., 119  
LAC Option, 119  
Max. Print Width, 120  
Prt Partial Line, 117  
PTX Transparent, 118

Set Text Orientn, 119  
5225 World Trade, 117

## U

UNDEF INTERRUPT\* message, 283

UNDFNED OP CODE\* message, 283

Unidirectional, PRINTER CONTROL, 219

UNKNOWN RBN1 message, 284

UNKNOWN RBN2 message, 284

Unload paper, 39

Unsolicited Rpt, LG Emulation, 217

UP DRV. SHORT\* message, 284

UP or DOWN key, 28

UP + DOWN key, 28

UPC Descenders, 182, 197

Upr. Case Select, P-Series XQ Emulation, 154

User-Def Ratio, 183

Usr Defined HTRN, 110, 133

Usr Defined HTRN, PTX Transparent, 118

Usr Defined HTRN, SPC Type, 136

UTF-8, 188

## V

Var Form Adjust, 184

Var Form Type, 184

Vert Forms, 67

Vert Forms, LG Emulation, 215

VFU Select, 147

VFU Select, P-Series XQ Emulation, 153

VGL SFCC, 195

View Function, PRINTER CONTROL, 219

VIEW/EJECT key, 27

Voltage, 289

VPA Check, IPDS Emulation, 208

## W

WAITING FOR ETHERNET ADAPTER  
message, 284

Warnings, 15

Weight, printer, 287

WEP Key 1, WLAN PARAMS menu, 98

WEP Key 2, WLAN PARAMS menu, 98

WEP Key 3, WLAN PARAMS menu, 98

WEP Key 4, WLAN PARAMS menu, 98  
 Width Limit, 199  
 WLAN Address, 64  
 WLAN ADDRESS menu, 94  
     DHCP, 94  
     Gateway address, 94  
     IP address, 94  
     MAC address, 94  
     Subnet mask, 94  
 WLAN Kerberos menu  
     Clock Skew, 100  
     KDC Port Number, 100  
     Kerberos Enable, 99  
     Kerb. Passwrd, 100  
     Renew Lifetime, 100  
     Reset Kerb. Pwd, 100  
     Ticket Lifetime, 100  
 WLAN LEAP menu  
     Auth Method, 101  
     LEAP Password, 101  
     LEAP Username, 101  
     Reset LEAP Password, 101  
     Reset LEAP User, 101  
 WLAN PARAMS menu, 95  
     Antenna, 97  
     Ant. Diversity, 97  
     Auth Method, 98  
     Channel, 96  
     Default WEP Key, 98  
     Internat. Mode, 97  
     Min Xfer Rate, 96  
     Operation Mode, 96  
     Power Mgmt, 97  
     Preamble, 97  
     Reset SSID Name, 96  
     Reset WEP Keys, 98  
     Reset WPA P-Phs, 99  
     Signal Strength, 96  
     SSID Name, 96  
     Transmit Power, 97  
     WEP Key 1, 98  
     WEP Key 2, 98

WEP Key 3, 98  
 WEP Key 4, 98  
 WPA Cipher, 99  
 WPA Mode, 98  
 WPA P-Phs, 99  
 Word Length, Serial submenu, 84  
 WPA Cipher, WLAN PARAMS menu, 99  
 WPA Mode, WLAN PARAMS menu, 98  
 WPA P-Phs, WLAN PARAMS menu, 99

## Y

Year, DATE menu, 230

## Z

Zero Tear Pedestal (ZTP)  
     adjust paper guides, 294  
     clear paper jams, 303  
     control panel menus, 301  
     forms type, 302  
     load paper, 296  
     overview, 293  
     paper jams, 303  
     position paper, 294  
     position paper out sensor, 298  
     set tear bar distance, 299  
     set top of form, 300  
     ZTP DateTime, 301  
     ZTP Function, 301  
     ZTP Platen Open, 301  
     ZTP TearDist, 301  
     ZTP WaitTime, 301  
 ZTP Data Time, 65, 69  
 ZTP DateTime, 301  
 ZTP Function, 68, 301  
 ZTP Platen Open, 69, 301  
 ZTP SETTINGS menu, 68  
     ZTP Data Time, 69  
     ZTP Function, 68  
     ZTP Platen Open, 69  
     ZTP TearDistance, 68  
     ZTP Wait Time, 69  
 ZTP TearDist, 301  
 ZTP TearDistance, 65, 68

---

ZTP Wait Time, 65, 69  
ZTP WaitTime, 301  
06 HOST REQUEST message, 254  
08 HOLD PRINT TIMEOUT message, 254  
15 COMM CHECK message, 255  
15V PWR FAIL \* message, 255  
20 CPI Condensed  
    Epson FX Emulation, 164  
    Proprinter XL Emulation, 160  
22 INVALID ADDR message, 255  
23.5V PWR FAIL \* message, 255  
31 PAPER OUT TIMEOUT message, 255  
32 PAPER JAM TIMEOUT message, 255  
3270 Params, 121  
3270 Params menu  
    Active Char Set, 123  
    Change Case, 124  
    Compatibility Op, 125  
    Early Print Cmpl, 123  
    Format Control, 127  
    Host Override, 126  
    Intervention Req, 124  
    Max. Print Width, 127  
    Prt Partial Line, 123  
    PTX Transparent, 123  
    Set Text Orientn, 124  
    Translation Tbl, 123  
33 PLATEN OPEN TIMOUT message, 255  
34 RIBBON STALL TIMOUT message, 255  
426 BC READ ERR message, 256  
48V CIRCUIT\* message, 255  
48V PWR FAIL \* message, 255  
5225 World Trade, 117  
5250 Params, 128  
5250 Params menu  
    Active Char Set, 130  
    Format Control, 132  
    Graphic Chek Cod, 131  
    Graphic Chek Err, 131  
    Host Override, 131  
    Max. Print Width, 132  
    Prt Partial Line, 130  
    PTX Transparent, 130  
    Set Text Orientn, 131  
    Translation Tbl, 130  
733 DP FIFO Busy\* message, 256  
8.5V PWR FAIL \* message, 254







178660-001E